

# **Volkswagen/Audi Vehicle Communication Software Manual**

**February 2009**

**EAZ0031B01C Rev. C**

---

## **Trademarks Acknowledgements**

Snap-on, Scanner, MODIS, and SOLUS are trademarks of Snap-on Incorporated.

All other marks are trademarks of their respective holders.

## **Copyright Information**

©2009 Snap-on Incorporated

All rights reserved.

## **Disclaimer**

The information, specifications and illustrations in this manual are based on the latest information available at the time of printing.

Snap-on reserves the right to make changes at any time without notice.

**For Technical Assistance Call:**  
**1-800-332-2526 (US only)**  
**1-800-424-7226 (North America)**

---

# Safety Information

For your own safety and the safety of others, and to prevent damage to the equipment and vehicles upon which it is used, it is important that the accompanying *Safety Information* be read and understood by all persons operating, or coming into contact with, the equipment. We suggest you store a copy near the unit in sight of the operator

This product is intended for use by properly trained and skilled professional automotive technicians. The safety messages presented throughout this manual are reminders to the operator to exercise extreme care when using this test instrument.

There are many variations in procedures, techniques, tools, and parts for servicing vehicles, as well as in the skill of the individual doing the work. Because of the vast number of test applications and variations in the products that can be tested with this instrument, we cannot possibly anticipate or provide advice or safety messages to cover every situation. It is the automotive technician's responsibility to be knowledgeable of the system being tested. It is essential to use proper service methods and test procedures. It is important to perform tests in an appropriate and acceptable manner that does not endanger your safety, the safety of others in the work area, the equipment being used, or the vehicle being tested.

It is assumed that the operator has a thorough understanding of vehicle systems before using this product. Understanding of these system principles and operating theories is necessary for competent, safe and accurate use of this instrument.

Before using the equipment, always refer to and follow the safety messages and applicable test procedures provided by the manufacturer of the vehicle or equipment being tested. Use the equipment only as described in this manual.

Read, understand and follow all safety messages and instructions in this manual, the accompanying safety manual, and on the test equipment.

## Safety Message Conventions

Safety messages are provided to help prevent personal injury and equipment damage. All safety messages are introduced by a signal word indicating the hazard level.

### **DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury to the operator or to bystanders.

### **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to the operator or to bystanders.

**⚠ CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in moderate or minor injury to the operator or to bystanders.

Safety messages contain three different type styles.

- Normal type states the hazard.
- Bold type states how to avoid the hazard.
- Italic type states the possible consequences of not avoiding the hazard.

An icon, when present, gives a graphical description of the potential hazard.

Example:

**⚠ WARNING**

Risk of unexpected vehicle movement.

- **Block drive wheels before performing a test with engine running.**  
*A moving vehicle can cause injury.*

## Important Safety Instructions

For a complete list of safety messages, refer to the accompanying safety manual.

# SAVE THESE INSTRUCTIONS

# Table of Contents

|   |            |
|---|------------|
| <b>Safety Information</b> .....                                   | <b>iii</b> |
| Safety Message Conventions .....                                  | iii        |
| Important Safety Instructions .....                               | iv         |
| <b>Chapter 1: Using This Manual</b> .....                         | <b>1</b>   |
| Conventions .....   | 1          |
| Bold Text .....   | 1          |
| Terminology .....   | 1          |
| Notes and Important Messages .....                                | 2          |
| <b>Chapter 2: Introduction</b> .....                              | <b>3</b>   |
| <b>Chapter 3: Operations</b> .....                                | <b>4</b>   |
| Identifying the Vehicle .....                                     | 4          |
| Engine ID Codes .....   | 4          |
| Vehicle Identification .....                                      | 10         |
| Connecting to a Vehicle .....                                     | 11         |
| Selecting a System .....  | 14         |
| Demonstration Programs .....                                      | 16         |
| <b>Chapter 4: Expert Mode</b> .....                               | <b>17</b>  |
| Using Expert Mode .....   | 17         |
| Initiating Expert Mode .....                                      | 17         |
| Selecting a System .....  | 18         |
| Expert Mode Function Selection Menu .....                         | 19         |
| Testing in Expert Mode .....                                      | 28         |
| <b>Chapter 5: Testing</b> .....                                   | <b>29</b>  |
| VW/Audi Software Application List .....                           | 29         |
| Testing Engine Systems .....                                      | 31         |
| VW/Audi Application Coverage .....                                | 31         |
| Clearing Codes .....  | 39         |
| Data .....  | 41         |
| Functional Tests .....  | 42         |
| Testing Transmission Systems .....                                | 52         |
| Digimat Control Module Identification—Golf & Jetta, 1993–97 ..... | 57         |
| 4-Speed Automatic Transmission—01N .....                          | 59         |
| VW Series—095, 096, 01M .....                                     | 59         |
| Audi Transmission—01F, 01K .....                                  | 60         |
| Important Tips for Transmission Codes .....                       | 61         |
| Transmission Basic Settings .....                                 | 62         |
| Functional Tests—VW Passat 01V .....                              | 63         |
| VW/Audi Transmission Emergency Operation—01V .....                | 65         |
| Testing Electronic Throttle Systems .....                         | 66         |
| Throttle Valve Control Module Adaptation .....                    | 66         |

|  |            |
|--|------------|
| Electronic Throttle Types .....                                  | 68         |
| Testing ABS Systems .....  | 71         |
| ABS Basic Settings .....   | 74         |
| Testing Immobilizer Systems .....                                | 74         |
| Important Tips for Testing Immobilizer III Systems.....          | 75         |
| Audi Immobilizers.....   | 76         |
| Immobilizer Adaptation Procedures .....                          | 76         |
| Radio Frequency Remote Control Functions .....                   | 80         |
| Immobilizer Frequently Asked Questions.....                      | 81         |
| Testing Electronic Instrument Panel Systems .....                | 82         |
| Electronic Instrument Panel Types.....                           | 82         |
| Testing Airbag (SRS) Systems .....                               | 87         |
| Testing CAN Data Bus Systems .....                               | 88         |
| Sources of Interference.....                                     | 88         |
| Powertrain CAN Bus .....   | 88         |
| CAN Data Bus in the Convenience System .....                     | 89         |
| <b>Chapter 6: Data Parameters .....</b>                          | <b>91</b>  |
| Alphabetical Parameter List.....                                 | 92         |
| Gas Engine Parameters .....                                      | 104        |
| Diesel Engine Parameters.....                                    | 135        |
| Transmission Parameters.....                                     | 139        |
| Transmission Expert Mode Parameters .....                        | 147        |
| ABS Parameters.....  | 149        |
| <b>Appendix A: Terms and Acronyms .....</b>                      | <b>150</b> |
| Terms.....   | 150        |
| Acronyms.....  | 150        |
| <b>Appendix B: Troubleshooting .....</b>                         | <b>153</b> |
| Communication Problems .....                                     | 153        |
| The Aftermarket Radio Problem .....                              | 153        |
| The Problem .....  | 153        |
| Testing for this Problem .....                                   | 154        |
| <b>Appendix C: Fuel Control Learning/Adaptation Values .....</b> | <b>156</b> |
| Long-Term Fuel Control.....                                      | 156        |
| Additive Adaptation .....  | 156        |
| Multiplicative Adaptation .....                                  | 157        |
| Examples of Display Groups for Long Term FT Adaptive Value ..... | 157        |
| Important Tips for Long Term Fuel Control.....                   | 159        |
| Short-Term Fuel Control .....                                    | 159        |
| Examples Short Term FT O2 Regulation .....                       | 159        |
| Important Tips for Short-Term Fuel Control.....                  | 160        |
| Oxygen Sensor Voltage.....                                       | 161        |
| Early Vehicle Oxygen Sensor Reading.....                         | 161        |
| Example: Motronic 2.9 (1993–1995).....                           | 162        |
| Late Model Oxygen Sensor Reading.....                            | 162        |
| Oxygen Sensor Aging Test .....                                   | 163        |
| Oxygen Sensor Control-Dwell Time Test .....                      | 164        |

CAT Test Parameters ..... 164

**Index ..... 169**

This manual contains instructions for testing Volkswagen and Audi vehicles. Some of the illustrations shown in this manual may contain modules and optional equipment that are not included on your system. Contact a sales representative for availability of other modules and optional equipment.

## 1.1 Conventions

This manual uses the conventions described below.

### 1.1.1 Bold Text

Bold text is used for emphasis and to highlight selectable items such as buttons and menu options.

Example:

- Press the **Y** button.

### 1.1.2 Terminology

Certain terms are used to command specific actions throughout this manual. Those terms are described below.

#### **Select**

The term “select” means scrolling to a menu item or other option with the Thumbwheel or Thumb Pad and pressing the **Y** button to confirm the selection.

Example:

- Select **FUNCTIONAL TESTS**.

#### **Scroll**

The term “scroll” means moving the cursor or changing data by turning the Thumbwheel or pressing the Thumb Pad.

Example:

- Scroll to see any other codes and the data list.



## Scan Tool

The term “scan tool” refers to your Snap-on diagnostic tool. When necessary, the term “Scanner” will be used to distinguish Snap-on equipment from another diagnostic device, such as the Volkswagen or Audi factory scan tool.

### 1.1.3 Notes and Important Messages

The following messages appear throughout this manual.

#### Notes

A NOTE provides helpful information such as explanations, tips, and comments.

Example:

**NOTE:**

For additional information refer to...

---

#### Important

IMPORTANT indicates a situation which, if not avoided, may result in damage to the test equipment or vehicle.

Example:

---

**IMPORTANT:**

To avoid incorrect TPS adjustment or component damage, be sure to follow the on-screen instructions. Refer to a vehicle service manual for complete test or adjustment procedures.

---

This manual contains instructions for testing Volkswagen and Audi vehicles.

Some of the illustrations shown in this manual may contain modules and optional equipment that are not included on your system. Contact a Snap-on Sales Representative for availability of other modules and optional equipment.

This chapter provides an overview of the conventions used in this manual. The remainder of this guide is divided in to the following chapters:

- [Chapter 3 Operations](#)—explains how to begin using the basic scan tool test functions, such as identifying a vehicle, selecting a system for testing, and connecting to a vehicle.
- [Chapter 4 Expert Mode](#)—details enhanced factory tool capabilities and special functions, such as setting adaptations and control module coding.
- [Chapter 5 Testing](#)—provides information and procedures for using the scan tool with specific control systems.
- [Chapter 6 Data Parameters](#)—provides definitions and operating ranges for the Volkswagen and Audi vehicle data stream parameters.
- [Appendix A Terms and Acronyms](#)—defines common terms and acronyms used in this manual.
- [Appendix B Troubleshooting](#)—contains information for troubleshooting specific problems that may arise when using the scan tool.
- [Appendix C Fuel Control Learning/Adaptation Values](#)—explains OBD-II short and long term FT terminology applied to VW/Audi fuel control terminology.

This chapter explains how to begin using the basic scan tool test functions, such as identifying a vehicle, selecting a system for testing, and connecting to a vehicle. This information is specific to VW/Audi vehicles. For general scan tool functionality, see the user's manual appropriate to your diagnostic tool.

## 3.1 Identifying the Vehicle

The scan tool typically identifies a vehicle using certain characters of the vehicle identification number (VIN). The scan tool vehicle identification (ID) process prompts to you enter VIN characters and answer questions about the vehicle to be tested.

### 3.1.1 Engine ID Codes

The vehicle identification process includes entering the test vehicle's engine ID code. The exact engine ID code selection is usually not required for vehicle communications, however, in order for the scan tool to communicate with all installed systems, we recommend that you identify the correct engine code. The scan tool has to match all possible control module identities with the exact control module installed in the vehicle. In addition, the engine ID code is required to select the correct OBD-II Readiness Monitor setting procedures. See the *Volkswagen/Audi OBD-II Readiness Charts* for more information.

VW/Audi specific engine differences are determined by a three-digit engine ID code. In any particular year, there could be multiple engine ID codes for any one engine. The engine codes may represent different horsepower, torque rating or emission package.

Engine ID codes are stamped on the engine block in three-digit alpha characters followed by a series of numbers (usually six), for example, "AEG 029452". If more than 999,999 engines with the same engine code are produced, the first number is replaced by a letter. Newer models may also have an adhesive label located on the timing belt cover. The engine ID code can be difficult to locate on older engines with excessive oil and grease. Here are typical older model 4- and 6-cylinder locations:

- **4-cylinder engine codes** and numbers are usually, stamped into the rear of the cylinder block casting near the oil filter flange near the engine/transmission joint.
- **6-cylinder engine codes** are usually located on the left side of the engine block below the camshaft timing chain tensioner. The code numbers should be visible when looking down between the throttle valve control module and the valve cover.

**Note the following when looking for an engine ID code:**

- Alternatively, look in the owners "maintenance" manual for an adhesive sticker.
- For most engines, the engine ID code is also included on the vehicle data plate, typically located in the trunk near the spare tire. This may be the easiest way to find the engine code.

Table 3-1 contains engine ID code locations for Audi models.

**Table 3-1** Volkswagen engine ID code locations (part 1 of 3)

| Model          | Year           | Engine            | Code Location  |  |
|----------------|----------------|-------------------|--|--|
| Beetle         | 1999 and later | 1.8L              | <b>APH, AWP, AWV:</b> Near the engine/transmission joint. Also on a sticker on the toothed belt guard.   |  |
|                | 1998–2002      | 1.9L 4-cyl 2V TDI | <b>ALH:</b> Between the diesel injection pump and the exhaust manifold on the engine block. Also on a sticker on the timing belt guard.  |  |
|                | 2003           | 2.0L 4-cyl 2V     | <b>BBW, BDC:</b> On the front of the engine near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.   |  |
|                | 2004 and later | 1.8L Turbo        | <b>AWU:</b> Unknown at this time.  |  |
|                |                | 1.8L Turbo        | <b>BKF:</b> The engine number can be found on the joint between engine/gearbox.  |  |
|                |                | 1.8L Turbo        | <b>BNU:</b> The engine number can be found on the joint between engine/gearbox.  |  |
|                |                | 1.9L TDI          | <b>BEW:</b> The engine number can be found on the joint between engine/gearbox.  |  |
|                | 2004 and later | 2.0L              | <p><b>AZG:</b> Near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.</p> <p><b>BDC:</b> On front of the engine near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.</p> <p><b>BER:</b> Unknown at this time.</p> <p><b>BEV:</b> The engine number can be found on the flange between engine/transmission.</p> <p><b>AEG:</b> Near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.</p> <p><b>AVH:</b> Near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.</p> <p><b>BHP:</b> Unknown at this time.</p> <p><b>BGD:</b> The engine number can be found at the front next to the joint between engine/transmission</p> |  |
|                | Eurovan        | 1999 and earlier  | 2.5L   | <b>AAF, ACU:</b> Between cylinders 1 and 3 on the cylinder block. Also on a sticker on the toothed belt guard.           |
|                |                |                   | 2.8L   | <b>AES:</b> Behind the cylinder head cover on the cylinder block. Also on a sticker attached to the cylinder head cover. |
| 2000 and later |                | 2.8L              | <b>AES:</b> On the cylinder block next to the vibration damper.  |  |
| 2001 to 2004   |                | 2.8L              | <b>AXK:</b> The engine code is located next to the vibration damper on the cylinder head.  |  |

**Table 3-1** Volkswagen engine ID code locations (part 2 of 3)

| Model               | Year             | Engine                 | Code Location   |
|---------------------|------------------|------------------------|---|
| Golf, Jetta,<br>GTI | 1999 and earlier | 2.8L VR6<br>2V         | <b>AFP:</b> On the engine block next to the vibration damper. The engine ID number is found here from 06.27.99 production and from engine AFP-019059.<br>Also on a sticker on the back of the intake manifold upper section close to the vacuum connection. Remove the engine cover to view this sticker. |
|                     | 1999 and later   | 1.8L 4-cyl<br>5V Turbo | <b>AWD, AWP, AWW:</b> Near the engine/transmission joint. Also on a sticker on the toothed belt guard.  |
|                     |                  | 1.9L 4-cyl<br>2V TDI   | <b>ALH:</b> Between the diesel injection pump and the exhaust manifold on the engine block. Also on a sticker on the toothed belt guard.  |
|                     |                  | 2.0L 4-cyl<br>2V       | <b>AEG, AVH, AZG:</b> Near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.  |
|                     |                  | 2.8L                   | <b>BDF:</b> Next to the vibration damper on the cylinder block. Also on a sticker on the intake manifold.   |
|                     | 2000 and later   | 2.8L VR6<br>2V         | <b>AFP:</b> On the engine block next to the cylinder head, beneath the chain tensioner for the camshaft roller chain. It can be seen by looking down between heating resistor N79 and the throttle valve control unit. Also on a sticker on the valve cover.  |
|                     | 2003             | 2.0L                   | <b>BBW:</b> Near the engine/transmission joint. Also on a sticker on the cylinder head cover and vehicle data plate.  |
|                     | 2004 and later   | 1.8L<br>Turbo          | <b>BEK:</b> Unknown at this time.   |
|                     |                  | 1.9L TDI               | <b>BEW:</b> The engine number can be found on the joint between engine/gearbox.<br><b>BKC:</b> Unknown at this time.<br><b>BRM:</b> Unknown at this time.   |
|                     | 2004 and later   | 2.0L                   | <b>BEV:</b> The engine number can be found on the flange between engine/transmission.<br><b>BER:</b> Unknown at this time.<br><b>BHP:</b> Unknown at this time.   |
|                     |                  | 3.2L                   | <b>BFM:</b> Unknown at this time.<br><b>BML:</b> Unknown at this time.<br><b>BJS:</b> The engine number is located next to the vibration damper on cylinder block under coolant pump.   |
|                     | 2005 and later   | 2.5L                   | <b>BGQ:</b> Unknown at this time.<br><b>BGP:</b> Unknown at this time.  |

**Table 3-1** Volkswagen engine ID code locations (part 3 of 3)

| Model     | Year              | Engine                 | Code Location  |
|-----------|-------------------|------------------------|--|
| Passat    | 1995–97           | 1.9L 4-cyl<br>2V TDI   | <b>AAZ, 1Z:</b> On the cylinder block between the diesel injection pump and the exhaust. Also on a sticker on the toothed belt guard.  |
|           |                   | 2.8L VR6<br>2V         | <b>AAA:</b> On the vibration damper end of the cylinder block. Also on a sticker on the cylinder head cover.   |
|           | 1998 and<br>later | 1.8L 4-cyl<br>5V Turbo | <b>AEB, ATW, AUG, AWM:</b> On the left side of the cylinder block. Also on a sticker on the cylinder head cover. The engine code is also stamped on the front of the engine lifting eye (visible after removing the cover above the fuel injectors).   |
|           |                   | 2.8L V6<br>5V          | <b>AHA, ATQ:</b> On the flat surface of the cylinder block, on the front of the right cylinder head.   |
|           |                   | W8, 4.0L               | <b>BDP:</b> On the left of the cylinder block. Also on a sticker on the cylinder head cover.   |
|           | 2004 and<br>later | 2.0L                   | <b>BHW:</b> The engine number can be found on the joint between engine/transmission.<br><b>BGW:</b> Unknown at this time.  |
|           |                   | 2.8L                   | <b>AMX:</b> Unknown at this time.<br><b>BBG:</b> Unknown at this time.   |
|           |                   | 4.0L                   | <b>BDN:</b> Unknown at this time.  |
|           |                   | 3.2L                   | <b>AZZ:</b> Unknown at this time<br><b>BKJ:</b> Unknown at this time<br><b>BAA:</b> The engine number is located next to the vibration damper on cylinder block under coolant pump.<br><b>BMX:</b> The engine number is located next to the harmonic balancer on the cylinder block under the coolant pump                         |
|           | Touareg           | 2004 and<br>later      | 4.2L   |
| 5.0L TDI  |                   |                        | <b>AYH:</b> Unknown at this time.<br><b>BKW:</b> The engine number is located on the cylinder below the cylinder head of cylinder bank 2.  |
| Phaeton   | 2004 and<br>later | 4.2L                   | <b>BGJ:</b> The engine number is stamped on the right side of the cylinder block<br><b>BGH:</b> The engine number is stamped on the right side of the cylinder block   |
|           |                   | 6.0L                   | <b>BAP:</b> The engine number is located at left on cylinder block<br><b>BAN:</b> Unknown at this time.<br><b>BRP:</b> The engine number is located at left on cylinder block  |
| New Jetta | 2005 and<br>later | 1.9L TDI               | <b>BRM:</b> The engine number can be found on the joint between engine/transmission.   |
|           |                   | 2.5L                   | <b>BGP:</b> The engine code and serial number are located on the backside of the engine, above the separation point of the engine block/upper point of oil pan.<br><b>BGQ:</b> The engine code and serial number are located on the backside of the engine, above the separation point of the engine block/upper point of oil pan. |

**Table 3-2** Audi engine ID code locations (part 1 of 3)

| Model | Year           | Engine                 | Code Location  |
|-------|----------------|------------------------|--|
| A4    | 1998 and later | 1.8L 4-cyl<br>5V Turbo | <b>AUG, AWM:</b> On the left side, on the cylinder head. Also on a sticker with the on the cylinder head. The engine ID code is also stamped on the front of the engine lifting eye (visible after removing the cover above the fuel injectors).   |
|       | 2001           | 1.8L                   | <b>AEB, ATW:</b> On the left side of the cylinder block between the transmission and above the oil filter. Also on a sticker on the timing belt guard. The engine ID is also stamped on the front of the engine mounting bracket (visible after removing cover above fuel injectors).  |
|       |                | 2.8L                   | <b>AFC:</b> On the right-hand side of the engine block between the cylinder head and the power steering pump. Also on a sticker on the drive belt cover.<br><b>AHA, ATQ:</b> On the block in front of the right cylinder head.<br><b>AHA Only:</b> In vehicles with VINs up to 8D-V-205 000, the oil pump is mounted on the front of the engine and driven directly by the crankshaft. In vehicles with VINs from 8D-V-205 001 on, the oil pump is driven via a chain by the crankshaft and mounted inside the oil pan. Also, oil supply lines are mounted on the camshaft bearing caps.   |
|       | 2003 and later | 1.8L                   | <b>AMB:</b> On the rear left of the cylinder block. Also on a sticker on the toothed belt guard and stamped on the front lifting eye (visible when engine cover panel is removed).   |
|       |                | 3.0L                   | <b>AVK:</b> Remove the front engine cover; there is a sticker with the engine code and production number on the housing for vacuum diaphragm for intake manifold adjustment. If the sticker is not present and the engine identification is required, remove the rear engine cover; engine codes are stamped on the rear of the cylinder block, left side.<br>If there is no sticker and the engine identification <i>and</i> production number are required, remove the bolts and the vacuum diaphragm for intake manifold adjustment, then remove the compression spring which is behind it and set off to the side of the vacuum diaphragm with connected lines; the engine code and production number are located at the front of the cylinder head, on top. |
|       | 2003           | 4.2L                   | <b>BHF:</b> On the right of the intake manifold.   |
|       | 2004 and later | 1.8 L<br>Turbo         | <b>BKB:</b> Unknown at this time.<br><b>BFB:</b> Unknown at this time.<br><b>BEX:</b> Unknown at this time.  |
|       |                | 1.8 L<br>Turbo         | <b>AMB:</b> The engine number can be found on the rear left of the cylinder block.   |
|       |                | 2.0L                   | <b>BPG:</b> The engine number can be found on the joint between engine/transmission.   |
|       |                | 3.0L                   | <b>ASN:</b> Unknown at this time.<br><b>BBJ:</b> Unknown at this time.   |
|       |                | 3.2L                   | <b>BKH:</b> The engine number is located on the front of the cylinder block below the right cylinder head.   |
|       |                | 4.2L                   | <b>BBK:</b> Unknown at this time.  |
|       |                | 4.2L                   | <b>BHF:</b> A sticker arrow with engine code and serial number is located on the intake manifold on the right side.  |

**Table 3-2** Audi engine ID code locations (part 2 of 3)

| Model           | Year           | Engine          | Code Location   |  |
|-----------------|----------------|-----------------|---|--|
| A6              | 1998 and later | 2.7L, 2.8L      | <b>APB, AHA, ATQ:</b> On the machined surface on the cylinder block, at the front of the right cylinder bank.   |  |
|                 |                | 4.2L            | <b>ART, AWN, BBD:</b> On the left side of the cylinder block. Also on a sticker on the belt cover.  |  |
|                 | 2000 and later | 3.0L            | <b>AVK:</b> Remove the front engine cover; there is a sticker on the housing for the vacuum diagram for intake manifold adjustment. Also if the rear engine cover is removed engine codes are stamped on the rear of the cylinder block, left side. |  |
|                 |                | 4.2L            | <b>AWN:</b> Unknown at this time.<br><b>BBD:</b> The engine number is located at left on the cylinder block.  |  |
|                 | 2002 and later | 3.0L            | <b>ASN:</b> Unknown at this time.<br><b>BBJ:</b> Unknown at this time.  |  |
|                 |                | 3.2L            | <b>BKH:</b> The engine number is located on the front of the cylinder block below the right cylinder head.  |  |
|                 | 2004 and later | 2.7L            | <b>BES:</b> Unknown at this time.   |  |
|                 |                | 4.2L            | <b>ANK:</b> Unknown at this time.<br><b>ASG:</b> Unknown at this time.<br><b>BNK:</b> A sticker with the engine and serial number is affixed to the cylinder head cover on the right hand side.   |  |
|                 | A6/S6          | Sedan (1995–97) | 2.2L  | <b>AAN:</b> On the right-hand side at the rear of the cylinder head.       |
|                 |                |                 | 2.7L  | <b>BEL:</b> On the cylinder block at the front of the right cylinder bank. |
| Wagon (1995–98) |                | 2.2L            | <b>AAN:</b> On the right-hand side at the rear of the cylinder head.  |  |
|                 |                | 2.7L            | <b>BEL:</b> On the cylinder block at the front of the right cylinder bank.  |  |
| 2003            |                | 4.2L            | <b>BAS:</b> On the right-hand side at the rear of the cylinder head.<br><b>BCY:</b> On top of the cylinder block. Also on a sticker on the drive belt cover.  |  |
|                 |                |                 |   |  |
| A8              | 2004 and later | 4.2L            | <b>BFM:</b> The engine number is located at left on cylinder block.<br><b>BHT:</b> Unknown at this time.  |  |
|                 |                | 6.0L            | <b>BSB:</b> The engine number is located on the front of the cylinder block below the left cylinder head  |  |
| A8/S8           |                | 4.2L            | <b>AKB, AUX, AYS:</b> On the left side of the cylinder block. Also on a sticker on the belt cover.  |  |
|                 |                | 3.7L, 4.2L      | <b>ABZ, AEW:</b> On the left side of the cylinder block directly above the power steering pump. Also on a sticker on the toothed belt guard.  |  |
| Cabriolet       |                | 2.8L            | <b>AAH, AFC:</b> On the right-hand side of the engine block between the cylinder head and the power steering pump. Also on a sticker on the drive belt cover.   |  |



**Table 3-2** Audi engine ID code locations (part 3 of 3)

| Model             | Year                | Engine        | Code Location  |
|-------------------|---------------------|---------------|--|
| S4                | 2000                | 1.8L          | <b>AEB, ATW:</b> On the left side of the cylinder block between the transmission and above the oil filter. Also on a sticker on the timing belt guard and stamped on the front of the engine mounting bracket (visible after removing cover above fuel injectors).   |
|                   |                     | 2.8L          | <b>AFC:</b> On the right-hand side of the engine block between the cylinder head and the power steering pump. Also on a sticker on the drive belt cover.<br><b>AHA, ATQ:</b> On the flat surface of the cylinder block in front of the right cylinder head.<br><b>AHA Only:</b> In vehicles with VINs up to 8D-V-205 000 the oil pump is mounted on the front of the engine and driven directly by the crankshaft. In vehicles with VINs from 8D-V-205 001 on, the oil pump is driven via a chain by the crankshaft and mounted inside the oil pan. Also, oil supply lines are mounted on the camshaft bearing caps. |
| S4<br>(continued) | 2004 and<br>later   | 1.8L<br>Turbo | <b>AMB:</b> Unknown at this time.<br><b>BKB:</b> Unknown at this time.<br><b>BFB:</b> Unknown at this time.  |
|                   |                     | 3.0L          | <b>ASN:</b> Unknown at this time.<br><b>BGN:</b> Remove the front engine cover; there is a sticker on the housing for the vacuum diagram for intake manifold adjustment. Also if the rear engine cover is removed engine codes are stamped on the rear of the cylinder block, left side.<br><b>BBJ:</b> Unknown at this time.<br><b>AVK:</b> Remove the front engine cover; there is a sticker on the housing for the vacuum diagram for intake manifold adjustment. Also if the rear engine cover is removed engine codes are stamped on the rear of the cylinder block, left side.                                 |
|                   |                     | 4.2L          | <b>BBK:</b> Unknown at this time.<br><b>BHF:</b> On the right of the intake manifold.  |
| TT                | 2003 and<br>earlier | 1.8L,<br>3.2L | <b>AMW, ATC, AWP, BEA, BHE:</b> At the front next to the joint between engine and transmission. Also on a sticker on the cylinder head cover.  |
|                   | 2004 and<br>later   | 1.8L          | <b>BAM:</b> Unknown at this time.  |
|                   |                     | 3.2L          | <b>BHE:</b> The engine number can be found on the joint between engine/transmission.   |

### 3.1.2 Vehicle Identification

If you are powering up the scan tool after just installing the VAG software, or if you pressed **N** from the Current Vehicle Identification screen, the Software Selection screen displays.



**To enter vehicle identification:**

1. Press **Y** to continue.  
The Manufacturer Selection menu displays.
2. Select the manufacturer.

Though you are able to select Seat or Skoda, these options apply to European vehicles only. Select Audi or Volkswagen for US vehicles.

When you select a manufacturer, a systems selection screen displays.

**NOTE:**

This is also the screen where you may select Expert Mode. See “Chapter 4 Expert Mode” on page 17 for instructions on using Expert Mode, or continue on to the next step for standard scan tool operations.

---

**3. Select Vehicle Systems US.**

The Vehicle Identification screen displays.

When testing vehicles in the United States, always choose the option with “US” at the end when available, unless you are in Expert Mode.

**4. Select the correct year for the vehicle.**

The display now shows the model year you just selected and asks for the selection of the model type.

**5. Enter any further VIN character requests and answer any yes or no questions.**

At the end of vehicle identification, the scan tool displays the complete model and engine identification.

**6. If the ID is correct, press Y to store the identification in memory. If the ID is not completely correct, press N to return to the start of the identification steps.**

## 3.2 Connecting to a Vehicle

Once a vehicle has been identified, a scan tool connection message appears, instructing you to use the supplied vehicle test adapters to connect the scan tool for testing.

---

**IMPORTANT:**

Before connecting the scan tool to 1997 and later vehicles, read “The Aftermarket Radio Problem” on page 153 in order to avoid seriously damaging your scan tool.

---

The following adapters are available to connect the scan tool to VW/Audi vehicles:

- **VW-1**—test adapter for 1991–94 VW and Audi vehicles. Hooks up to the white/black connector only (Connector for 1991–94 vehicles requires VW1 adapter).
- **DL-16**—test adapter with Personality Key S-7 for 1994 and later vehicles (DL). This OBD-II style connector is used for all vehicles. The S-44 key is used for CAN communications.

The following vehicle connectors are found on VW/Audi vehicles.

**A—White connector**

**B—Black connector**

**C—Blue (“K”)**

**D—Yellow (“L”)**

**E—Red (+12)**

**F—Black or Brown (ground)**

**NOTE:**

There may be other connectors with the white/black connector. Audi may have a yellow (A/T blink codes) or blue (not used) connector, and VW may have a red connector for Airbag I systems. It may be possible to hook the white connector of the VW-1 adapter to these other connectors and read codes (without definitions).

Refer to [Table 3-3](#) for Volkswagen diagnostic connector locations and to [Table 3-4](#) for Audi diagnostic connector locations.

Follow the on-screen connection instructions to connect to the vehicle.

**Table 3-3** Volkswagen diagnostic connector locations (part 1 of 2)

| Model                                      | Year                         | Connector Location   |
|--|------------------------------|--|
| Cabrio                                     | 1994–97                      | On the instrument panel center section, on the right side of the ashtray, behind the cover. To access, remove the ashtray and slide the cover off.   |
| Cabriolet                                  | 1991–93<br>(California only) | <b>Manual transmission:</b> On the center console under the shifter boot. To access, pull firmly to dislodge the boot.<br><b>Automatic transmission:</b> On the center console under the selector indicator cover. To access, remove the handle from the shifter, and then unsnap the indicator cover. The shifter can also be lifted up and turned without removing the handle. |
| Corrado                                    | All                          | <b>Manual transmission:</b> On the center console under the shifter boot. To access, pull firmly to dislodge the boot.<br><b>Automatic transmission:</b> On the center console under the selector indicator cover. To access, remove the handle from the shifter, and then unsnap the indicator cover. The shifter can also be lifted up and turned without removing the handle. |
| Eurovan                                    | 1992–93                      | Behind the parcel shelf. To access, release the catch button, pull the shelf out from top, and lift out.   |
|  | 1994                         | One of three locations: (1) behind the fold-down storage panel in front of the relay/fuse panel, (2) behind the panel in the dashboard, or (3) under the steering column.  |
|  | 1995–2003                    | Under the steering column.   |
| Eurovan<br>Winnebago<br>Camper &<br>Rialta | 1995                         | Behind the parcel shelf. To access, release the catch button, pull the shelf out from top, and lift out.   |
| Fox  | 1991–93<br>(California only) | On the center console under the shifter boot. To access, pull firmly to dislodge the boot.   |

**Table 3-3** Volkswagen diagnostic connector locations (part 2 of 2)

| Model          | Year      | Connector Location   |
|----------------|-----------|--|
| Golf/Jetta/GTI | 1990–92   | <b>Manual transmission:</b> On the center console under the shifter boot. To access, pull firmly to dislodge the boot.<br><b>Automatic transmission:</b> On the center console under the selector indicator cover. To access, remove the handle from the shifter, and then unsnap the indicator cover. The shifter can also be lifted up and turned without removing the handle. |
|                | 1993      | On the instrument panel center section, below the heater controls behind the blank switch covers.  |
|                | 1994      | One of two locations: (1) on the instrument panel center section, below the heater controls behind the blank switch covers, or (2) on the instrument panel center section, on the right side of the ashtray, behind the cover.   |
|                | 1995–97   | On the instrument panel center section, on the right side of the ashtray, behind the cover. To access, remove the ashtray and slide the cover off.   |
|                | 1998–2004 | One of two locations: (1) below the dashboard near the hood release, or (2) on the instrument panel center section, below heater controls behind blank switch covers.  |
| Passat         | 1993–94   | <b>Manual transmission:</b> On the center console under the shifter boot. To access, pull firmly to dislodge the boot.<br><b>Automatic transmission:</b> On the center console under the selector indicator cover. To access, remove the handle from the shifter, and then unsnap the indicator cover. The shifter can also be lifted up and turned without removing the handle. |
|                | 1995–97   | On the instrument panel, on the right side of the steering wheel, behind the cover.  |
|                | 1998–2005 | One of two locations: (1) below the dashboard near the hood release, or (2) between the front seats near the parking brake under a rubber cover.   |
| New Jetta      | 2004-2005 | Connector located near bonnet release handle.  |
| Touareg        | 2004-2005 | Connector located near bonnet release handle, behind cover.  |
| Phaeton        | 2004-2005 | Connector located near bonnet release handle.  |
| New Beetle     | 1998-2005 | Connector located near bonnet release handle.  |

**Table 3-4** Audi diagnostic connector locations (part 1 of 2)

| Model  | Year    | Connector Location   |
|--------|---------|--|
| 100/A6 | 1992–97 | One of two locations: (1) in the fuse box under the hood near the firewall, or (2) between the front seats near the parking brake under a rubber cover.  |
| 200/V8 | 1990–94 | One of three locations:<br>(1) under the carpet in the passenger side footwell<br>(2) in the fuse box under the hood near the firewall<br>(3) between the front seats near the parking brake under a rubber cover. |

**Table 3-4** Audi diagnostic connector locations (part 2 of 2)

| Model             | Year      | Connector Location  |
|-------------------|-----------|---|
| 90                | 1993–95   | In the fuse box under the hood near the firewall.   |
| A3                | 1997–2003 | Under the dashboard.  |
| A4                | 1996–2001 | One of two locations: (1) under the dashboard, or (2) under the sliding cover in the rear ashtray.  |
|                   | 2002–05   | Under the dashboard.  |
| A6/Allroad/S6/RS6 | 1998–2005 | One of two locations: (1) under the dashboard, or (2) between the front seats near the parking brake under rubber cover.                                      |
| A8                | 1997–2005 | Under the dashboard.  |
| Cabriolet         | 1994–1999 | One of three locations: (1) in the fuse box under the hood near the firewall, or (2) under the sliding cover in the rear ashtray, or (3) under the dashboard. |
|                   | 2004–2005 | Connector located near bonnet release handle.   |
| S3                | 1999–2003 | Under the dashboard.  |
| S4/S6             | 1992–95   | One of two locations: (1) in the fuse box under the hood near the firewall, or (2) between the front seats near the parking brake under a rubber cover.       |
| S4/RS4            | 2000–02   | One of two locations: (1) under the dashboard, or (2) under the sliding cover in the rear ashtray.  |
|                   | 2003      | Under the dashboard.  |
| S8                | 2001–02   | Under the dashboard.  |
| TT                | 2000–03   | Under the dashboard.  |

**Note the following when connecting to VW/Audi vehicles:**

- “Bonnet” is European for hood.
- *Do not* assume that the scan tool ID screen is correct if the scan tool communicates. If there are multiple selections, the scan tool will automatically identify the electronic control module, which means that scan tool communication does not depend on a correct engine ID code selection.

### 3.3 Selecting a System

Once you have confirmed a vehicle identification and connected to a vehicle (see previous sections), the Select System menu displays.

The items that appear on this menu vary depending on the vehicle you are testing, however, not all of the systems will be present—some of them are optional and others are mutually exclusive. For example, when an integrated immobilizer is present, there will be no separate immobilizer available.

**NOTE:**

Some early control modules may require an engine speed below 2000 RPM and a closed throttle (closed CTP switch) to initialize communication. However, once communication has initialized, higher engine speeds have no effect.

The following systems can be selected for VW/Audi vehicles:

- Engine Management
- Electronic Instrument Panel
- Abs/eds/esp/tcs
- Airbag/pretensioners
- Airbag Usa Golf-cabrio
- Air-conditioning
- Alarm System Interior
- Audio System
- Automatic Transmission
- Central Door Lock System
- Immobilizer (Separated)
- Immobilizer (If Not Separated)
- Steering Wheel Electronics
- Steering Help (Separated)
- Steering Help (If Not Separated)
- 4wd Electronics
- Comfort Systems
- Seat Adjustment Driver's Side
- Seat & Mirror Adjusting
- Central Electronic Unit
- Can Bus Interface
- Add. Heater/parking Heater
- Electronic Level Control
- Level Control Xenon Lights
- Tire Pressure Monitoring
- Parking Help
- Radio
- Navigation Systems
- Electronic Roof Control
- Distance Control
- Suspension Electronics
- Back Spoiler
- Emergency Control
- Speech Control
- Light Control Left
- Light Control Right
- Auto Light Switch

**Note the following when selecting a VW/Audi system for testing:**

- If a system is listed on the Select System menu, that does not mean it is installed on the vehicle. To determine the installed systems, perform an Automatic System Test in Expert Mode (see "00-Automatic System Test" on page 18).

- “Separated” means a standalone control module. “Not Separated” means that the system is integrated with another control module.
- The 25-Immobilizer (Separated) and 44-Steering Help (Separated) systems can give the following ECU identification: “Bitte Adresse 17 eingeben”. This means that the selected system is integrated in the instrument panel and that you need to select 17-Electronic Instrument Panel for diagnostics. Although it is possible to continue and select the functions, the information retrieved is not valid.
- The numbers that precede each system selection (i.e., “01” in front of “Engine Management”) are for use with the manufacturer scan tool only. These numbers are not used for Snap-on® scan tool operations.

**To select a system for testing:**

1. Select the system you would like to test.  
An instructions screen displays.
2. Follow the on-screen instructions and press **Y**.  
The Connection In Progress screen displays while the scan tool attempts to communicate with the vehicle.
3. When the scan tool communicates with the vehicle, press **Y** repeatedly until the Main Menu displays.

## 3.4 Demonstration Programs

The Volkswagen/Audi software contains programs that demonstrate test capabilities without connecting to a vehicle. The demonstration program can help you become familiar with scan tool menus and operation by providing mock data and test results for a sample vehicle ID.

The demonstration program is accessed at the vehicle identification phase of scan tool operations.

**To access a demonstration:**

1. Select **Demonstration US**.  
A screen displays, prompting you to identify a vehicle with “Demo” on line 1.
2. Press **Y** repeatedly to select the defaults until the System Selection menu displays.  
You are now in demonstration mode.

In addition to providing the same capability as standard or vehicle ID mode, Expert Mode has enhanced factory tool capabilities, giving the user special functions, such as setting adaptations and control module coding. Scan tool display screens in Expert Mode give no information about the specific procedures nor how to perform these special functions. Aftermarket information is limited in performing these functions. Expert Mode should only be used if the user is experienced in Volkswagen or Audi diagnostics and has the required information.

---

**IMPORTANT:**

It is possible to change and clear system settings with this function. Some functions can be disabled and/or the control module could be corrupted by incorrect use!

---

---

**IMPORTANT:**

Expert Mode functionality in this manual describes only the basic operation of some of the capabilities. Factory procedures for specific vehicles and systems must be followed to prevent any damage or inadvertent change in critical driveability, security and safety settings. For example, adaptation functions can disable or enable airbags, a major liability to a shop should there be a future accident with this vehicle.

---

## 4.1 Using Expert Mode

This section explains how to start using Expert Mode. The following is an outline of scan tool Expert Mode operation, starting with identifying the vehicle. Step 2 is described in “Chapter 3 Operations” on page 4. The remaining steps are described in greater detail in this chapter.

1. **Select Expert Mode**—Instead of selecting Vehicle Systems US as you would for standard scan tool operations, select Expert Mode. See “Initiating Expert Mode” on page 17.
2. **Connect the scan tool**—Follow the connection instructions displayed after selecting Expert Mode to connect the scan tool with the vehicle. See “Connecting to a Vehicle” on page 11.
3. **Select the system**—Enter the system to be tested (engine, transmission, ABS, etc.). See “Selecting a System” on page 18.
4. **Select the Expert Mode function**—The scan tool displays the functions available on the identified vehicle electronic control module. Select the appropriate functions for the vehicle you have identified. See “Expert Mode Function Selection Menu” on page 19.

### 4.1.1 Initiating Expert Mode

After you have selected a manufacturer, you can initiate Expert Mode.



**To initiate Expert Mode:**

1. Select **Expert Mode**.  
A warning screen displays.
2. Press **Y** to continue.  
Instructions to connect the scan tool to the vehicle display.  
See “Connecting to a Vehicle” on page 11 for information about connecting the scan tool to VW/Audi diagnostic connectors, or ID the vehicle in standard mode (see “Identifying the Vehicle” on page 4) until model-specific connection instructions display.
3. Connect to the correct diagnostic connector on the vehicle and press **Y**.  
The System Selection menu displays.

### 4.1.2 Selecting a System

There are two special items on the Expert Mode System Selection menu that do not display on the standard System Selection menu:

- 00-Automatic System Test
- 01-Engine Management Master (11-Engine Management Slave is not used for US vehicles)

The rest of the items on the menu are the same as in standard mode (“Selecting a System” on page 14).

**To select a system for testing:**

1. Select the system you would like to test.  
The communication instruction screen displays.

**NOTE:**

Selecting 00-Automatic System Test displays a different screen (see 00-Automatic System Test below).

2. Press **Y**.  
A warning message displays.
3. Press **Y**.  
The scan tool displays the vehicle’s electronic control module identification.
4. Press **Y** to go to the Expert Mode Function Selection menu (see “Expert Mode Function Selection Menu” on page 19).

### 00-Automatic System Test

The Automatic System Test is always the first menu choice in Expert Mode. This selection interrogates all installed controllers and automatically prints out all control module IDs and any DTCs stored there.

**NOTE:**

A printer must be connected for an Automatic System Test to run.

This test may take ten minutes or longer depending on the number of control modules. DTCs may be set in multiple controllers, therefore, all control modules need to be checked for DTCs and have DTCs cleared after repairs. Automatic System Test is a good way to know which controllers are installed on the vehicle and to obtain DTC information.



**To perform an Automatic System Test:**

1. Select 00-Automatic System Test from the System Selection menu. A screen displays, prompting you to select Y to begin the test or N to return to the previous menu.
2. Press Y to begin the Automatic System Test. The Printing in progress screen displays.

The scan tool prints the result when the test is finished.

### 4.1.3 Expert Mode Function Selection Menu

When the scan tool has established a connection with the vehicle, the scan tool displays a Function Selection menu, such as the Expert Mode Function Selection menu.

The Expert Mode Function Selection menu allows you to select from the following general functions:

- **01-Read ECU Identification**—displays the control module identification string, the control module coding, and Work Shop Code (see page 20).
- **02-Check DTC Memory**—displays all current diagnostic trouble codes present (see page 20).
- **03-Actuator Tests**—activates different actuator tests for about 30 seconds in sequence (see page 20).
- **04-Basic Setting**—performs a Basic Setting, depending on the entered block number (000–255) (see page 21).
- **05-Clear DTC Memory**—clears any existing trouble codes and checks if the trouble codes are really cleared (see page 21).
- **06-Stop Communication**—stops the communication and exits Expert Mode (see page 21).
- **07-ECU Coding**—changes the existing control module coding by entering a new coding (see page 21).
- **08-Read Measuring Value Block**—displays measuring value blocks after entering a valid block number (see page 22).
- **09-Read ADC Channel**—displays data from a single ADC channel (see page 26).
- **10-Adaptation**—changes adaptation values from the control module (see page 26).
- **11-Login Request**—performs a login request to the control module after entering a valid login code (see page 27).
- **15-Check Readiness Code Setting**—displays a readiness code and whether it is set or not (see page 27).
- **16-Security Access**—performs a security access request to the control module (see page 27).

**Note the following when using Expert Mode:**

- There is no Custom Setup available in Expert Mode (for example, you cannot change the temperature readings from Celsius to Fahrenheit).

- There are no Movie or Print Frame options, only Print Screen and Print Codes. Printer communication settings must be configured in standard mode using vehicle ID or in Demonstration mode to have the possibility to print. Expert Mode also will not work with Snap-link™ or ScanGrafix PC graphing programs.
- When using Expert Mode, supplemental information found in VAG service manuals is necessary to interpret displayed data values and to know the proper procedure to perform a specific test, coding, or adaptation.

## 01-Read ECU Information

This function displays the control module identification string, the control module coding, and Work Shop Code. Also, some systems will display some extra control module identification if selected. Pressing **N** prints the control module information.

VW/Audi part numbers for this controller contain a version number for the controller's internal firmware. Shop number identifies the Work Shop Code stored in the scan tool that last recoded this control module.



### NOTE:

Some older control modules are not “codeable” and you may see a Bosch part number or other information in these fields.

---

The Extra ECU identification fields can store VIN and immobilizer information on some vehicles.

## Work Shop Code

World Wide, every VW/Audi dealer is assigned a unique Work Shop Code (WSC). Factory scan tools require a valid WSC to function, and once it has been entered, it cannot be changed. Whenever a control module is coded, or adaptations are performed, the scan tool sends its WSC to the control module and the control module records it. If a factory scan tool was used to perform specific functions, such as disabling an airbag through the WSC, it may be possible to identify which dealer performed this procedure.



### NOTE:

The Snap-on® VAG software does not change or alter the WSC. It reads the existing WSC and sends it back unchanged after a procedure has been performed.

---

## 02-Check DTC Memory

This function displays all diagnostic trouble codes (DTCs) currently present or stored in memory.

## 03-Actuator Tests

This function activates different actuator tests for about 30 seconds in sequence, or depending on the ECU you may select which available test to run. The user can abort or continue to the next test.

Some tests display a command to the user. For example, if “Press Brake Pedal” displays, the user has to press and hold the brake pedal and then continue. The sequence, number, and type of tests are dictated by the control module.

To perform the actuator tests, the entry conditions must be correct. For the correct entry conditions refer to the VAG system specific workshop manual. On some systems, the actuator tests cannot be restarted until the ignition key is switched off for some time. Alternatively, briefly start and run the engine, shut down, turn the ignition to the run position, then re-initiate the actuator tests.

## 04-Basic Settings

This function can put a system in basic mode or performs a Basic Setting. This depends on the entered block number (000–255). After entering a valid block number, data values or text can be displayed. There is no description of the data value, only the value and unit is displayed. For interpretation of the values, refer to the VAG system-specific workshop manual. See “Basic Settings” on page 45 for more information.

## 05-Clear DTC Memory

This function attempts to clear all current and stored DTCs. After clearing, the scan tool rechecks for DTCs, and any that reset from current problems will re-display.

## 06-Stop Communication

This function stops the communication and leaves the Expert Mode. If the scan tool gets accidentally disconnected, go back to the same controller and then exit properly using 06. This is the equivalent of selecting Other Systems in standard mode.

---

### **IMPORTANT:**

Always exit out of any one module using 06-Stop Communication before selecting another module. Failure to do so may cause communication problems, corrupt data, or cause a parasitic draw on the battery.

---

## 07-ECU Coding

This function can change the existing control module coding by entering a new coding. The range of coding can be 0–127, 0–32767 or 0–1048575. The coding number can tell a control module about the configuration, for example, if cruise control is available or not.

After entering a new coding, it is sent to the control module and the scan tool reports if the new coding is accepted or not. A coding will not be accepted if it is an unknown number or if a control module cannot be coded. However, be aware that a control module usually does accept an incorrect coding number.

Some special codings require an unlocked control module. The control module can be unlocked with a Log-in or Security Access request.

### **Note the following regarding control module coding:**

- The following login information is subject to change and is not guaranteed to work on every application. A common VW login is 01283; a common Audi login is 13861. Specific vehicle logins are found in that vehicle’s service manual.

- 2002 vehicles using the new CAN Bus communication network may not require control modules to be version coded, as the version coding information is obtained from the other controllers sharing the CAN Bus. However, if the engine control module is replaced it will need to be adapted to the immobilizer (see “Testing Immobilizer Systems” on page 74 for more information).

## 08-Read Measuring Value Block

This function displays measuring value blocks. After entering a valid block number, data values or text are displayed. There is no description of the data value, only the value and unit is displayed. For interpretation of the values, refer to the VAG system specific workshop manual. Press **N** to enter the print exit menu. Scroll to change the block number. The displayed data is the actual data received from the control module.

### VW/Audi Display Group Data

Instead of one long data list, VW and Audi data is organized into display groups (Table 4-1). However, these groups are not determined by a scan tool. Instead, these are manufacturer predetermined groups which change depending on the vehicle and engine. Table 4-1 provides some examples of group categories available on a late model VW and Audi.

**Table 4-1** VW/Audi display group categories

| Display Group Number | Display Group Category       |
|----------------------|------------------------------|
| 1–9                  | General engine activity data |
| 10–19                | Ignition                     |
| 20–29                | Knock control                |
| 30–39                | O2 sensor control system     |
| 40–49                | Three-way CAT                |
| 50–59                | Engine speed control         |
| 60–69                | Throttle drive               |
| 70–79                | Emissions reduction          |
| 80–89                | Special function             |
| 90–97                | Power increase               |
| 98–100               | Compatibility                |
| 101–109              | Fuel Ignition                |
| 110–119              | Boost pressure control       |
| 120–129              | Control unit communication   |
| 130–150              | Special info                 |

The following sections provide information that give examples of engine data interpretation. Note that data available varies by year, engine, engine code, and management system.



#### NOTE:

The display groups available using vehicle ID may vary from the total number of display groups available in Expert Mode. Display groups in standard vehicle ID mode are preselected based on priority of use. All possible display groups can be viewed using Expert Mode. Remember that to view a particular display group in Expert Mode, the specific group number must be manually scrolled in.

The following examples may have additional display groups available in Expert Mode.

***Example 1: 2002 VW Jetta Drive-by-Wire, Bosch ME 7.5 Engine Management Control System***

- Group=1, Basic Functions (1)
- Group=2, Basic Functions (2)
- Group=3, Basic Functions (3)
- Group=4, Basic Functions (4)
- Group=5, Operating Mode Engine
- Group=6, Altitude Correction
- Group=10 Ignition
- Group=20, Ignition, Knock Control Cyl 1-4
- Group=22, Ignition, Knock Control Cyl 1+2
- Group=23, Ignition, Knock Control Cyl 3+4
- Group=28, Knock Control
- Group=30, O2 Status
- Group=32, Learn Values O2
- Group=33, O2 Regulation Before Cat
- Group=37, Diagnose O2 Control System
- Group=41, O2 Sensor Heater
- Group=50, Idle Speed Control
- Group=54, Idle Speed Control
- Group=55, Idling Stabilization (1)
- Group=56, Idling Stabilization (2)
- Group=60, Adaptation Epc-system
- Group=61, Epc-system (1)
- Group=62, Epc-system (2)
- Group=99, O2 Loop

***Example 2: 2002 Audi TT Drive-by-Wire, Bosch ME 7.1 Engine Management Control System***

- Group=1, Basic Functions (1)
- Group=2, Basic Functions (2)
- Group=4, Basic Functions (3)
- Group=5, Basic Functions (4)
- Group=6, Basic Functions (4)
- Group=10, Ignition
- Group=22, Ignition, Knock Control Cyl 1+2
- Group=23, Ignition, Knock Control Cyl 3+4
- Group=28, Diagnose Knock Sensors
- Group=30, O2 Status

- Group=32, Learn Values O2
- Group=33, O2 Regulation
- Group=41, O2 Sensor Heater
- Group=50, Idle Speed Control
- Group=54, Idle Speed Control
- Group=55, Idling Stabilization
- Group=56, Idling Stabilization
- Group=60, Adaptation Epc-system
- Group=60, Throttle Valve Adjuster
- Group=61, Throttle Valve Adjuster
- Group=62, Epc-system
- Group=63, Kickdown Function
- Group=66, Cruise Control Status
- Group=99, O2 Loop
- Group=113, Control Turbo Pressure
- Group=114, Control Turbo Pressure
- Group=115, Control Turbo Pressure
- Group=117, Control Turbo Pressure
- Group=118, Control Turbo Pressure
- Group=120, Tcs System
- Group=125, Can Bus Communication

### ***Example 3: Motronic 2.9 (1993–1995)***

Display group 000 has 10 channels or display fields, listed below.

1. Coolant temperature
2. Engine load
3. RPM
4. O2 factor
5. Idle Adapt
6. Part throttle adapt
7. Low load adapt
8. IAC adapt
9. Not used
10. IGN timing

The display fields are output in binary numbers. To understand the binary number, visualize a clock with 0 at the top center. The number 128 is at the center bottom. The binary clock counts from 0 to 255, a rich/lean correction from base midpoint (0).

In binary output 0–255, based on O2S output, numbers fluctuate between rich (high numbers) and lean (low numbers).

The number can theoretically range from 0 to 255 with 0 as the midpoint. A number of 13 to 128 indicates that the control module has commanded an overall lean mixture correction. A number of 128 to 243 indicates that the control module has commanded an overall rich mixture correction.

**Example 4: Late Model Motronic 7.5**

The following example concerns display group 000 for 1-bank systems:

1. Engine coolant temperature
2. Load
3. RPM
4. Voltage
5. Throttle valve potentiometer
6. Idle air control valve
7. Idle air control valve learning value
8. Lambda control
9. Lambda control learning value idle
10. Lambda control learning value partial load

Display group 000 for 2-bank systems:

1. Engine coolant temperature
2. Load
3. RPM
4. Throttle valve angle
5. Idle air control
6. Idle air control valve learning value
7. Lambda control Bank 1
8. Lambda control Bank 2
9. Lambda adaptation (add) Bank 1
10. Lambda adaptation (add) Bank 2

**Example 5: Central Electronic Unit (09)**

The four display fields for display group 012 indicate the following:

- **Display field 1: Check bus**—This field indicates whether the data bus is OK or faulty (e.g. fault in single wire).
- **Display field 2: Equipment front**—This field indicates which front control units are fitted and participate in data transfer.
- **Display field 3: Equipment rear**—This field indicates which rear control units are fitted and participate in data transfer.
- **Display field 4: Accessories**—This field indicates whether the seat and mirror adjustment memory system is fitted. Both systems (convenience system and memory system) interchange data.

**NOTE:**

Inter-module CAN data transfer currently cannot be checked.

---



## 09-Read ADC Channel (Except KW2000<sup>1</sup>)

This function displays data from a single ADC channel. This function allows you to look at real-time data from control modules that support it. Currently, this data has no interpretation or scaling information.



### To set the Read ADC Channel function:

1. Enter a valid channel number  
A number from 0 to 65535 displays.
2. Scroll to change the channel number.
3. Press **N** to display the Exit menu for printing.

## 10-Adaptation

This function can change adaptation values from the control module and allows you to alter certain values and/or settings in control modules which support it.

---

### IMPORTANT:

Function 10 changes baseline settings. Do not proceed with this function unless you know the exact procedure. Be aware that some Channels may not be documented.

---

Examples of things you can do with the adaptation selection:

- Alter the Idle Speed (e.g., 01-Engine Management > 10-Adaptation > 000/0001).
- Change the Service Intervals and resetting the Service Reminder Indicators (newer instrument clusters).
- Disable/enable various components of the airbag (SRS) system.
- Change the sensitivity of the Interior Monitor (Sonar Scan) component of the alarm system in many newer Audi models.
- Swap control modules and rematch keys (newer immobilizer-equipped cars).
- Select certain Central Locking options in newer vehicles.

### To change adaptation values:

1. Read the adaptation.
2. Test the adaptation.
3. Save the adaptation.

### To set an adaptation:

1. Select a valid channel.  
The actual adaptation value is displayed. On some adaptation channels, there will be data displayed on the last line.
2. Scroll or press **N** for manual input.

---

<sup>1</sup> "KW2000" stands for Key Word 2000, and refers to a communication protocol which was used beginning in 2002 on limited vehicles, such as the VW Passat 1.8L turbo, the Audi A4 1.8L and 3.0L, and the Audi A6 3.0L.

The new adaptation value can be tested or changed. For example, the engine speed is raised to numbers greater than 128 or lowered to numbers less than 128.

3. To exit and store a new value, press **Y** to confirm or press **N** to abort.

Selecting channel 000 clears all adaptation values after pressing **Y** to confirm the request.

### 11-Login Request (Except KW2000)

This function performs a login request to the control module. After entering a valid login code, the control module is ready to perform a special coding or adaptation function.

Used on some (mostly 1996 and later) control modules, Login Request is necessary before you can recode or change adaptation values. On others, it “enables” certain features like cruise control. Valid login codes can be found in the workshop manual for the car.

The following login information is subject to change and is not guaranteed to work on every application:

- A common VW login is 01283
- A common Audi login is 13861



#### NOTE:

You get only one chance to enter the correct login number. If you enter the wrong number, turn off the ignition and wait 10 seconds before another attempt.

---

### 11-ECU Coding 2 (KW2000 Only)

This function can change the special control module coding by entering a new valid coding.

### 15-Check Readiness Code Setting (Except KW2000)

If the system has a readiness code, this function displays that readiness code and whether it is set or not. If the system has no special readiness block, sometimes the same information can be found in function 08 by selecting group 86 and checking Channel 1.

### 16-Security Access (KW2000 Only)

This function performs a security access request to the control module. After entering a valid code, the control module is ready to perform a special coding or adaptation function.

#### Note the following when using 16-Security Access:

- The Snap-on scan tool currently performs only 5-digit security codes.
- Some early systems cannot communicate if the engine is running.
- Some early systems cannot communicate or communication is lost if engine or vehicle speed exceeds a certain specification. Refer to the VAG system-specific manual for details.

## 4.2 Testing in Expert Mode

The functions available depend on the communication protocol. Functions that can be executed depend on the system and entry conditions. Some functions need a login or security access before executing the particular function. Not all systems support all functions.



**NOTE:**

The 25-Immobilizer (Separated) and 44-Steering Help (Separated) systems give the following control module identification: Bitte Adresse 17 eingeben. Although it is possible to continue and select the functions, the information retrieved is not valid and should be discarded. The selected system is integrated in the instrument panel. Please select 17-Electronic Instrument Panel for diagnostics.

---

For more testing information, see "Chapter 5 Testing" on page 29.

This chapter provides information and procedures for using the scan tool with specific control systems. Control systems discussed in this chapter are:

- Engine on page 31
- Transmission on page 52
- Electronic Throttle on page 66
- ABS and traction control on page 71
- Immobilizer on page 74
- Electronic Instrument Panel on page 82
- Airbag (SRS) on page 87
- CAN data bus on page 88

## 5.1 VW/Audi Software Application List

Table 5-1 provides VW/Audi systems covered by the scan tool.

**Table 5-1** VW/Audi software application list (part 1 of 2)

| Control Systems            | Codes                  | Data             | Advanced Functions |
|----------------------------|------------------------|------------------|--------------------|
| ABS/EDL/ESP/TCS            | Standard & Expert Mode |                  | Expert Mode Only   |
| Add. Heater/Parking heater | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Airbag/Pretensioners       | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Air-conditioning           | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Alarm System Interior      | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Anti-slip Control          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Audio System               | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Auto Light Switch          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Automatic Transmission     | Standard & Expert Mode |                  |                    |
| Back Spoiler               | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| CAN Bus Interface          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Central Door Lock          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |
| Central Electronic Unit    | Standard & Expert Mode | Expert Mode Only | Expert Mode Only   |

**Table 5-1** VW/Audi software application list (part 2 of 2)

| Control Systems             | Codes                  | Data             | Advanced Functions     |
|-----------------------------|------------------------|------------------|------------------------|
| Clutch Electronics          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Comfort Systems             | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Distance Control            | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Electronic Instrument Panel | Standard & Expert Mode | Expert Mode Only | Standard & Expert Mode |
| Electronic Level Control    | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Electronic Roof Control     | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Emergency Unit              | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Engine Management           | Standard & Expert Mode |                  |                        |
| Immobilizer                 | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Level Control Xenon Lights  | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Light Control Left          | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Light Control Right         | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Navigation                  | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Parking Help                | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Radio                       | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Seat Adjustment Driver Side | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Seat and Mirror Adjustment  | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Speech Control              | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Steering Help               | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Steering Wheel Electronics  | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Suspension Electronics      | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| Tire Pressure Monitoring    | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |
| 4WD Electronics             | Standard & Expert Mode | Expert Mode Only | Expert Mode Only       |

## 5.2 Testing Engine Systems

The following sections contain scan tool testing information for engine systems. Testing Engine Systems first lists the VW/Audi engines that communicate with the scan tool, and continues to provide procedures and tips for certain testing functions.

### 5.2.1 VW/Audi Application Coverage

The following sections contain US vehicle coverage for 1991–2005 VW and Audi.

**Table 5-2** VW/Audi application coverage

| Volkswagen                        | Audi                              |
|-----------------------------------|-----------------------------------|
| CIS-E or K-Jetronic/CIS (1990–92) | CIS-E or K-Jetronic/CIS (1990–92) |
| Digifant 1 (CA only) (1991–93)    | MPI (1990–95)                     |
| Motronic M2.9 (1993–95)           | Motronic M2.3 (1991–94)           |
| Motronic M5.9 (1995–2000)         | Motronic M2.3.2 (1993–95)         |
| Motronic M5.9.2 (1997–2005)       | Motronic M2.4 (1990–94)           |
| Motronic M7.0 (1999–2001)         | Motronic M2.9 (1993–95)           |
| Motronic M7.1 (2000–01)           | Motronic M5.4.2 (1995–96)         |
| Motronic M7.1.1 (2002–05)         | Motronic M5.9 (1996–98)           |
| Motronic M7.5 (2001–05)           | Motronic M5.9.2 (1998–2000)       |
| Motronic M7.5.1 (2002)            | Motronic ME7.1 (2000–01)          |
| Diesel TDI (1996–2003)            | Motronic ME7.5.1 (2002–03)        |

### US Volkswagen Application Coverage

Table 5-3 provides application coverage for US Volkswagen engines.

**Table 5-3** US VW application coverage (part 1 of 4)

| Model          | Year      | Volume | Engine Code | Engine Info | Supported | Notes                             |
|----------------|-----------|--------|-------------|-------------|-----------|-----------------------------------|
| Cabriolet (15) | 1990–92   | 1.8    | 2H          |             | YES       | CA Only                           |
| Cabriolet (1E) | 1995–2001 | 2.0    | ABA         |             | YES       |                                   |
| Cabriolet (1V) | 2000–02   | 2.0    | ABA         |             | YES       |                                   |
| Corrado (50)   | 1992–1995 | 2.8    | AAA         |             | YES       |                                   |
|                | 1991–92   | 1.8    | PG          | G60         | YES       | CA Only                           |
| Eurovan (70)   | 1992–95   | 2.5    | AAF         | 5L          | YES       | 1992 Canada Only                  |
|                | 1995      | 2.5    | ACU         | 5L          | YES       | 1995 Only<br>Winnebago/<br>Rialta |
|                | 1997–2000 | 2.8    | AES         | VR6         | YES       |                                   |
|                | 2001–04   | 2.8    | AXK         | VR6         | YES       |                                   |
| Fox (30)       | 1991–93   | 1.8    | ABG         |             | YES       | CA Only                           |

**Table 5-3** US VW application coverage (part 2 of 4)

| Model                      | Year            | Volume    | Engine Code | Engine Info | Supported | Notes       |  |
|----------------------------|-----------------|-----------|-------------|-------------|-----------|-------------|--|
| Golf/Jetta/GTI (1G) MK II  | 1991–92         | 2.0       | 9A          | 16V         | YES       |             |  |
|                            |                 | 1.8       | PF          |             | NO        |             |  |
|                            |                 | 1.8       | RV          |             | YES       | CA Only     |  |
| Golf/Jetta/GTI (1H) MK III | 1993–99         | 2.8       | AAA         | VR6         | YES       |             |  |
|                            |                 | 2.0       | ABA         |             | YES       |             |  |
|                            | 1993–97         | 1.8       | ACC         |             | YES       | Canada Only |  |
|                            | 1998–99         | 1.9       | IZ          | TDI         | YES       |             |  |
|                            |                 |           | AHU         | TDI         | YES       |             |  |
| Golf/Jetta/GTI (1J) MKIV   | 1999–2002       | 2.8       | AFP         | VR6         | YES       |             |  |
|                            | 1999–2001       | 2.0       | AEG         |             | YES       |             |  |
|                            | 1999–2003       | 1.9       | ALH         | TDI         | YES       |             |  |
|                            | 2000–01         | 1.8       | AWD         | Turbo       | YES       |             |  |
|                            | 2001–03         | 2.0       | AVH         |             | YES       |             |  |
|                            |                 |           | 1.8         | AWW         | Turbo     | YES         |  |
|                            | 2002            | 2.8       | AFP         | VR6         | YES       |             |  |
|                            | 2003–05         | 1.8       | AWP         | Turbo       | YES       |             |  |
|                            |                 |           | AZG         |             | YES       |             |  |
|                            |                 |           | 2.0         | BBW         | SULEV     | YES         |  |
|                            |                 |           | 2.8         | BDF         | VR6       | YES         |  |
|                            | 2004–05         | 1.8       | BEK         | Turbo       | YES       |             |  |
|                            |                 |           | BEW         | TDI         | YES       |             |  |
|                            |                 | 2.0       | AZG         |             | YES       |             |  |
|                            |                 |           | BEV         |             | YES       |             |  |
|                            |                 |           | BER         |             | YES       |             |  |
|                            |                 | 3.2       | BJS         |             | YES       |             |  |
|                            |                 |           | BML         |             | YES       |             |  |
|                            | BFM             |           |             | YES         |           |             |  |
|                            | New Beetle (1C) | 1999–2000 | 1.8         | APH         | Turbo     | YES         |  |
| 2001–05                    |                 | 1.8       | AWV         | Turbo       | YES       |             |  |
| 1998–2005                  |                 | 1.9       | ALH         | TDI         | YES       |             |  |
| 1998–2002                  |                 | 2.0       | AEG         |             | YES       |             |  |
| 2000–03                    |                 | 2.0       | AVH         |             | YES       |             |  |
| 2001–05                    |                 | 2.0       | AZG         |             | YES       |             |  |
| 2003                       |                 | 2.0       | BDC         | Convertible | YES       |             |  |
| 2004–05                    |                 | 1.8       | AWU         | Turbo       | YES       |             |  |
|                            |                 |           | AWP         | Turbo       | YES       |             |  |
|                            |                 | 1.9       | BEW         | TDI         | YES       |             |  |
|                            |                 | 2.0       | AZJ         |             | YES       |             |  |
|                            | BDC             |           |             | YES         |           |             |  |
| BEV                        |                 |           | YES         |             |           |             |  |

**Table 5-3** US VW application coverage (part 3 of 4)

| Model                             | Year      | Volume | Engine Code | Engine Info                            | Supported | Notes |     |
|-----------------------------------|-----------|--------|-------------|--|-----------|-------|-----|
| New Beetle<br>(1C)<br>(continued) | 2004–05   | 2.0    | BER         |  | YES       |       |     |
|                                   |           |        | BGD         |  | YES       |       |     |
|                                   |           |        | BHP         |  | YES       |       |     |
|                                   | 1999–2001 | 1.8    | AWD         | Turbo                                  | YES       |       |     |
|                                   | 1999–2005 | 1.9    | ALH         | TDI                                    | YES       |       |     |
|                                   | 1999–2001 | 2.0    | AEG         |  | YES       |       |     |
|                                   | 2000–03   | 2.0    | AVH         |  | YES       |       |     |
|                                   |           |        | AZG         |  | YES       |       |     |
|                                   | 1999–2002 | 2.8    | AFP         | VR6                                    | YES       |       |     |
|                                   | 2003      | 2.8    | BDF         |  | YES       |       |     |
| 2004–05                           | 1.9       | BEW    | TDI         | YES                                    |           |       |     |
| New Jetta<br>(9M) MK IV           | 2005      | 1.9    | BKC         | TDI                                    | YES       |       |     |
|                                   |           |        | BRM         | TDI                                    | YES       |       |     |
|                                   | 2000–05   | 2.0    | AVH         |  | YES       |       |     |
|                                   |           |        | AZG         |  | YES       |       |     |
|                                   | 2004–05   | 2.0    | BBW         |  | YES       |       |     |
|                                   |           |        | BER         |  | YES       |       |     |
|                                   |           |        | BEV         |  | YES       |       |     |
|                                   |           |        | BHP         |  | YES       |       |     |
|                                   | 2003–2005 | 2.8    | BDF         |  | YES       |       |     |
|                                   | 2005      | 2.5    | BGP         |  | YES       |       |     |
| BGQ                               |           |        |             | YES                                    |           |       |     |
| Passat (31)                       | 1991–93   | 2.0    | 9A          | 16V                                    | YES       |       |     |
|                                   | 1993–94   | 2.8    | AAA         | VR6                                    | YES       |       |     |
| Passat (3A)                       | 1996–97   | 1.9    | 1Z          | TDI                                    | YES       |       |     |
|                                   | 1995–97   | 2.8    | AAA         |  | YES       |       |     |
|                                   |           | 2.0    | ABA         |  | YES       |       |     |
| New Passat<br>(3B)                | 1998–99   | 1.8    | AEB         | Turbo                                  | YES       |       |     |
|                                   | 1998–2000 | 2.8    | AHA         | V6                                     | YES       |       |     |
|                                   | 2000–03   | 2.8    | ATQ         | V6                                     | YES       |       |     |
|                                   | 1999–2001 | 1.8    | ATW         | Turbo with<br>variable<br>valve timing | YES       |       |     |
|                                   | 2003      | 4.0    | BDP         | W8                                     | YES       |       |     |
|                                   | 2004–05   |        |             | BGW                                    |           | YES   |     |
|                                   |           | 2.0    |             | BHW                                    |           | YES   |     |
|                                   |           | 2.8    |             | AMX                                    |           | YES   |     |
|                                   |           |        |             |  | BBG       |       | YES |
| 4.0                               |           | BDN    |             | YES                                    |           |       |     |



**Table 5-3** US VW application coverage (part 4 of 4)

| Model   | Year    | Volume | Engine Code | Engine Info | Supported | Notes |
|---------|---------|--------|-------------|-------------|-----------|-------|
| Phaeton | 2004–05 | 4.2    | BGH         |             | YES       |       |
|         |         |        | BGJ         |             | YES       |       |
|         |         | 6.0    | BAN         |             | YES       |       |
|         |         |        | BAP         |             | YES       |       |
| Tourag  | 2004–05 | 3.2    | AZZ         |             | YES       |       |
|         |         |        | BAA         |             | YES       |       |
|         |         |        | BKJ         |             | YES       |       |
|         |         | 4.2    | AXQ         |             | YES       |       |
|         |         | 5.0    | AYH         | TDI         | YES       |       |
|         |         |        | BKW         | TDI         | YES       |       |

### VW/Audi On-board Diagnostic Availability: 1990–1995 Gas, 1992–2002 Diesel

The VW/Audi software starts VW/Audi US VIN ID in 1991 (US vehicle systems) and only identifies those vehicles with Codes and Data (does not retrieve blink codes). Table 5-4 on page 35 depicts many early year models with some vehicles having scan tool diagnostics depending on Emission certification or country, engine system description, including emission certification and early systems without diagnostic capability.

Starting in 1990, VW and Audi started using digital engine management systems on some models that were sold only in California.

#### Note the following when determining diagnostic availability:

- Only some of these early systems may have codes and rapid or serial data.
- There are some early blink code only systems not listed in Table 5-4 on page 35.
- For 1991–93, certain engine codes have data on California (CA) models only. Federal vehicles with the same engine code will display a “no communication” message and an additional message stating “Federal Vehicles are not capable of communicating.” Federal Vehicles may have blink codes.
- If the underhood emission label is missing, distinguishing between CA or Federal vehicles may be difficult. Also, Federal vehicles may still have the white/black diagnostic connector (under shifter boot). This connector may not be functional or may be for transmission (4-speed only) or ABS data. Only the 9A Federal emission equipped engine has engine data. To help identify a CA emission engine, check for a functional Malfunction Indicator Lamp (ignition on, engine off) or check for an exhaust gas recirculation (EGR) valve installed on the engine.
- European IDs can be used where the VIN cannot. The following systems can not be identified using US VIN ID. Use the alternate IDs below.
  - For the 1990 Golf/Jetta/GTI/Corrado/Passat using the 2.0L (9A) with CIS-E Motronic, ID as a 1991 Passat or use European ID for 1990 Golf or Jetta.
  - For the 1993–1994 Golf 1.8L (ACC), ID as a 1995 model year or use European ID and select 1993 or 1994 Golf 1.8L ACC.

**NOTE:**

The scan tool vehicle ID provides connector messages and system information but because the control modules are identified automatically, an incorrect VIN or vehicle ID does not stop scan tool communication.

In addition, be aware that Expert Mode can also be used on any vehicle with diagnostic capability and does not require any vehicle ID.

**Table 5-4** Early VW engine system coverage (part 1 of 2)

| Model     | Year    | Engine Code | Displacement                   | Engine Management   | Emission Cert. Only  | Scan Tool Diagnostics |
|-----------|---------|-------------|--------------------------------|---------------------|----------------------|-----------------------|
| Cabriolet | 1995    | ABA         | 2.0L 4-cyl                     | Motronic M2.9       |                      | YES                   |
|           | 1990–92 | 2H          | 1.8L 4-cyl                     | Digifant            | California           | YES                   |
| Corrado   | 1992–95 | AAA         | 2.8L (VR6)                     | Motronic M2.9       |                      | YES                   |
|           | 1990–92 | PG          | 1.8L 4-cyl (G60)               | Digifant            | California           | YES                   |
| Eurovan   | 1992–93 | AAF         | 2.5L 5-cyl                     | Digifant            | Canada Only for 1992 | YES                   |
|           |         | AAB         | 2.4L 5-cyl                     | Diesel              | Canada               | NO                    |
|           | 1995    | ACU         | 2.5L 5-cyl (Winnebago, Rialta) | Digifant            | Tier 1               | YES                   |
|           | 1995–97 | AAB         | 2.4L 5-cyl                     | Diesel              | Canada               | NO                    |
| Fox       | 1990    | JN          | 1.8L 4-cyl                     | CIS-E (KA Jetronic) |                      | NO                    |
|           | 1991–93 | ABG         | 1.8L 4-cyl                     | Digifant            | California           | YES                   |
| Federal   |         |             |                                |                     | NO                   |                       |
| Golf/GTI  | 1993–97 | ACC         | 1.8L 4-cyl                     | Mono-Motronic       | Canada               | YES                   |
|           | 1994–95 | AAA         | 2.8L (VR6)                     | Motronic M2.9       |                      | YES                   |
|           | 1993–95 | AAZ         | 1.9L 4-cyl                     | Turbo Diesel        | Canada               | NO                    |
|           | 1990–92 | 9A          | 2.0L 4-cyl (16V)               | CIS-E Motronic      |                      | YES                   |
|           |         | PF/RV       | 1.8L 4-cyl                     | Digifant            |                      | NO                    |
|           | 1991    | PF/RV       | 1.8L 4-cyl                     | Digifant            |                      | NO                    |
|           | 1993–99 | RV          | 1.8L 4-cyl                     | Digifant            | California           | YES                   |
| ABA       |         | 2.0L 4-cyl  | Motronic M2.9                  |                     | YES                  |                       |
| Jetta     | 1994–95 | AAA         | 2.8L 4-cyl                     | Motronic M2.9       |                      | YES                   |
|           | 1993–95 | ABA         | 2.0L 4-cyl                     | Motronic M2.9       |                      | YES                   |
|           |         | AAZ         | 1.9L 4-cyl                     | Turbo Diesel        | Canada               | NO                    |
|           | 1990–92 | PF/RV       | 1.8L 4-cyl                     | Digifant            |                      | NO                    |
|           |         | 9A          | 2.0L 4-cyl (16V)               | CIS-E Motronic      |                      | YES                   |
|           | 1991–92 | RV          | 1.8L 4-cyl                     | Digifant            | California           | YES                   |
|           | 1990–91 | ME          | 1.6L 4-cyl                     | Diesel              |                      | NO                    |
| MF        |         | 1.6L 4-cyl  | Turbo Diesel                   | Canada              | NO                   |                       |
| 1F        |         | 1.6L 4-cyl  | ECO Diesel Turbo               |                     | NO                   |                       |

**Table 5-4** Early VW engine system coverage (part 2 of 2)

| Model   | Year    | Engine Code | Displacement      | Engine Management | Emission Cert. Only | Scan Tool Diagnostics |
|---------|---------|-------------|-------------------|-------------------|---------------------|-----------------------|
| Passat  | 1995    | ABA         | 2.0L 4-cyl        | Motronic M2.9     |                     | YES                   |
|         | 1993–95 | AAA         | 2.8L (VR6)        | Motronic M2.9     |                     | YES                   |
|         |         | AAZ         | 1.9L 4-cyl        | Turbo Diesel      | Canada              | NO                    |
|         | 1991–94 | PG          | 1.8L 4-cyl (G-60) | Digifant          | Canada              | NO                    |
|         | 1990–93 | 9A          | 2.0L 4-cyl (16V)  | CIS-E Motronic    |                     | YES                   |
| Vanagon | 1990–91 | MV          | 2.1L 4-cyl        | Digifant          |                     | NO                    |

## US Audi Application Coverage

Table 5-5 provides early US Audi engines applications.

**Table 5-5** US Audi engine system application coverage (part 1 of 3)

| Model  | Year              | Volume | Engine Info  | Engine Code | Supported | Notes              |
|--------|-------------------|--------|--------------|-------------|-----------|--------------------|
| 100 S4 | 1986–91           | 2.2    | K-Jetronic   | MC Turbo    | NO        | Manual blink codes |
|        | 1986              | 2.2    | KE-Jetronic  | KZ          | NO        |                    |
|        | 1991–95           | 2.2    | Turbo 20V    | AAN         | YES       |                    |
|        | 1986–1990         | 2.3    | KE3-Jetronic | NF/NG       | NO        | Manual blink codes |
|        | 1990–94           | 2.8    | V6 12V       | AAH         | YES       |                    |
|        | 1994              | 2.8    | V6 12V       | AFC         | YES       |                    |
| 200    | 1986–91           | 2.2    | K-Jetronic   | MC Turbo    | NO        | Manual blink codes |
|        | 1989–90           | 2.2    | 20V          | 3B Turbo    | YES       |                    |
| 80     | 1988–90 (Type 89) | 2.0    | Motronic     | 3A          | NO        | Manual blink codes |
|        | 1992–94 (Type B4) | 2.3    | KE3-Jetronic | NG          |           |                    |
|        | 1988–89 (Type 89) | 2.3    | 20V          | 7A          |           |                    |
|        | 1992–94 (Type B4) | 2.8    | V6 12V       | AAH         | YES       |                    |
|        | 1993–94 (Type B4) | 2.8    | V6 12V       | AFC         | YES       |                    |
| 90     | 1987–91           | 2.3    | KE3-Jetronic | NG          | NO        | Manual blink codes |
|        | 1988              | 2.3    | 20V          | 7A          |           |                    |
|        | 1989–93           | 2.3    | 20V          | 7A          | YES       |                    |
|        | 1992–94 (Type B4) | 2.8    | V6 12V       | AAH         | YES       |                    |
|        | 1993–95           | 2.8    | V6 12V       | AFC         | YES       |                    |

**Table 5-5** US Audi engine system application coverage (part 2 of 3)

| Model | Year    | Volume | Engine Info  | Engine Code | Supported | Notes             |  |
|-------|---------|--------|--------------|-------------|-----------|-------------------|--|
| A4/S4 | 1995–99 | 1.8    | Turbo        | AEB         | YES       |                   |  |
|       | 2000    | 1.8    | Turbo        | ATW         | YES       |                   |  |
|       | 1994–97 | 2.8    | V6 12V       | AAH         | YES       |                   |  |
|       | 1995–97 | 2.8    | V6 12V       | AFC         | YES       |                   |  |
|       | 1996–97 | 2.8    | V6 30V       | AHA         | YES       |                   |  |
|       | 2000–01 | 2.8    | V6 30V       | ATQ         | YES       |                   |  |
|       | 2002–05 | 3.0    | V6 30V       | AVK         | YES       | 2003 A4 Cabriolet |  |
|       | 2002–05 | 1.8    | Turbo        | AMB         | YES       | 2003 A4 Cabriolet |  |
|       | 2001–03 | 2.7    | Turbo V6 30V | APB         | YES       |                   |  |
|       | 2004–05 | 1.8    |              | Turbo       | BEX       | YES               |  |
|       |         |        |              | Turbo       | BFB       | YES               |  |
|       |         |        |              | Turbo       | BKB       | YES               |  |
|       |         | 3.0    |              |             | ASN       | YES               |  |
|       |         |        |              |             | BBJ       | YES               |  |
|       |         |        |              |             | BBK       | YES               |  |
| 4.2   |         |        | BHF          | YES         |           |                   |  |
|       |         |        |              |             |           |                   |  |
| A6/S6 | 1993–95 | 2.8    | V6 12V       | AAH         | YES       |                   |  |
|       | 1994–96 | 2.8    | V6 12V       | AFC         | YES       |                   |  |
|       | 1997–99 | 2.8    | V6 30V       | AHA         | YES       |                   |  |
|       | 2000–01 | 2.8    | V6 30V       | ATQ         | YES       |                   |  |
|       | 2000    | 4.2    | V8           | ART         | YES       |                   |  |
|       | 2000–03 | 2.7    | Turbo V6 30V | APB         | YES       |                   |  |
|       | 2000–05 | 3.0    | V6 30V       | AVK         | YES       |                   |  |
|       |         | 4.2    | V8           | AWN         | YES       |                   |  |
|       |         | 4.2    | V8           | BBD         | YES       |                   |  |
|       | 2003–05 | 4.2    | V8           | BAS         | YES       |                   |  |
|       |         |        |              | BCY         | YES       |                   |  |
|       | 2002–05 | 3.0    |              | ASN         | YES       |                   |  |
|       |         |        |              | BBJ         | YES       |                   |  |
|       | 2004–05 | 2.7    |              | BEL         | YES       |                   |  |
|       |         |        |              | BES         | YES       |                   |  |
|       | 2002–03 | 4.2    |              | ART         | YES       |                   |  |
|       | 2004–05 | 4.2    |              | ANK         | YES       |                   |  |
|       |         |        |              | ASG         | YES       |                   |  |

**Table 5-5** US Audi engine system application coverage (part 3 of 3)

| Model            | Year      | Volume | Engine Info  | Engine Code | Supported | Notes |
|------------------|-----------|--------|--------------|-------------|-----------|-------|
| A8/S8            | 1997–99   | 4.2    | V8           | ABZ         | YES       |       |
|                  | 1999–2003 | 4.2    | V8           | AKB         | YES       |       |
|                  | 1997–99   | 3.7    | V8           | AEW         | YES       |       |
|                  | 2001–03   | 4.2    | V8           | AUX         | YES       |       |
|                  | 2002–03   | 4.2    | V8           | ABZ         | YES       |       |
|                  |           |        |              | AYS         | YES       |       |
|                  | 2004–05   | 4.2    |              | BFM         | YES       |       |
| 6.0              |           |        |              |             | BHT       | YES   |
| All-road Quattro | 2000–03   | 2.7    | Turbo V6 30V | APB         | YES       |       |
| Cabrio           | 1994–95   | 2.8    | V6 12V       | AAH         | YES       |       |
|                  | 1994–97   | 2.8    | V6 12V       | AFC         | YES       |       |
| Cabriolet        | 2004–05   | 1.8    | Turbo        | AMB         | YES       |       |
|                  |           |        |              | BFB         | YES       |       |
|                  |           |        |              | BKB         | YES       |       |
|                  | 3.0       | ASN    | YES          |             |           |       |
|                  |           | AVK    | YES          |             |           |       |
|                  |           | BBJ    | YES          |             |           |       |
|                  |           | BEN    | YES          |             |           |       |
|                  | 4.2       | BBK    | YES          |             |           |       |
|                  | BHF       | YES    |              |             |           |       |
| TT               | 2000–03   | 1.8    | Turbo        | AMU         | YES       |       |
|                  | 2000–01   | 1.8    | Turbo        | ATC         | YES       |       |
|                  | 2000–03   | 1.8    | Turbo        | AWP         | YES       |       |
|                  | 2003      | 1.8    | Turbo        | BEA         | YES       |       |
|                  | 2004–05   | 1.8    | Turbo        | BAM         | YES       |       |

**Audi Early Model Application 1990–1995**

The VW/Audi primary cartridge starts VW/Audi US VIN ID in 1991 (US vehicle systems) and only identifies those vehicles with Codes and Data (does not retrieve blink codes). The models in Table 5-6 on page 39 have diagnostic capability with the scan tool.

**Table 5-6** Audi early model application 1990–95

| Model                         | Year    | Displacement   | Engine Code | Engine Management |
|-------------------------------|---------|----------------|-------------|-------------------|
| 200/2000 Quattro<br>Turbo 20V | 1991    | Turbo 2.2L 20V | 3B          | M2.3              |
| V8 Quattro                    | 1992–94 | V8 4.2L 32V    | ABH         | M2.4              |
|                               | 1990–91 | V8 3.6L 32V    | PT          |                   |
| 100/1000 Quattro              | 1992–94 | V6 2.8L 12V    | AAH         | MPI               |
| S4                            | 1993–94 | 2.2L           | AAN         | M2.3              |
| A6                            |         |                |             |                   |
| 90/90 Quattro                 | 1993–95 | V6 2.8L 12V    | AAH         | MPI               |
| Cabrio                        | 1994–95 |                |             |                   |

## 5.2.2 Clearing Codes

This function attempts to clear all current and stored DTCs. After clearing, the scan tool re-checks for DTCs, and any that reset from current problems will re-display.



### To clear DTCs:

1. From any codes display, press **N** to display the Exit menu.
2. Select **Clear Codes**.  
The Initiate Code Clearing screen displays.
3. Press **Y** to initiate code clearing.  
A code-clearing message displays. This message varies depending on the control module.
4. Press **Y** to clear the codes automatically, if applicable for the vehicle under test.  
The display indicates that codes are cleared by displaying the No Codes screen.  
If the code-clearing operation fails for any reason, the previous codes reappear at the top of the data list when returning to Codes.
5. Press **N** to return to the Exit menu and repeat the Clear Codes operation if necessary.



### To clear multiple DTCs:

1. Record all codes.
2. Clear all codes using the previous procedure.  
Codes that re-display are current problems. Fix these first.
3. After repairs, clear codes again.
4. Perform a road test.
5. Re-check for codes.
6. Repair any codes that set.



### To test drive a VW or Audi to verify repairs after DTCs are erased:

1. Warm the engine up to normal operating temperature.
2. Allow the engine to idle (1 or 2 minutes).
3. Road test at part throttle.

4. Road test at Wide Open Throttle (attain at least 3500 RPM).
5. Decelerate.
6. Perform all steps several times.

Remember that all modules should be re-checked for codes after the test drive. Use automatic test mode to automatically print out all interrogated modules and codes ("00-Automatic System Test" on page 18).

### Important Tips for Codes

- The message on the scan tool states that to clear codes, the engine must be off. Input from field technicians indicates that this is not always necessary.
- Intermittent codes have the message "Error Occurs Intermittent" after the code description (VW calls these codes "sporadic"). Codes are considered intermittent if they occur for a maximum of five seconds. Intermittent codes do not turn the Check Engine Light on. They are automatically erased from memory after 40 drive cycles if they do not occur again. When a malfunction is first detected, it is stored as a static or pending malfunction. If the malfunction no longer exists after a pre-determined time or distance travelled, then it is labelled intermittent.
- Most 1995 and earlier Bosch control modules may show you a false DTC "00513 - Engine Speed Sensor (G28)" if the engine is not running. This fault code should disappear once the engine is started. With a defective sensor, the engine would not start. In addition, many automatic transmission control modules may show a DTC that indicates a faulty brake light switch. This usually can be ignored and usually will not appear if you press the brakes once before checking for fault codes.
- Disconnecting the battery may erase fault codes and basic settings on pre-OBD-II vehicles, which may result in driveability problems. Disconnecting the battery on OBD-II vehicles does not erase stored codes or turn the MIL off. However, intermittent codes and control unit adaptation learned values may be erased in both the engine and transmission.
- Disconnecting the battery may require resetting of convenience electronics such as alarm, interior lights, radio, etc. It is recommended to use a jumper battery or battery charger to maintain power when replacing a battery.
- Readiness Codes need to be reset after codes are cleared or the battery has been disconnected. Throttle body adaptation relearn is essential and may prevent the engine from starting. See "Testing Electronic Throttle Systems" on page 66 for more information.
- Be aware that clearing codes may not change throttle body adaptation status to "not ready" (060 or 098), but throttle body reset is highly recommended to ensure no problems. See the *Volkswagen/Audi OBD-II Readiness Code Charts* for additional information.
- Sometimes a fault code is displayed for a component which is not installed in the vehicle under test (i.e., a cruise control). This code cannot be cleared. Always make sure the component the code refers to is present when a code cannot be cleared.
- Performing activation tests may set false codes. Always check and clear codes after performing activation tests.
- Vehicles with Drive-by-Wire (no throttle cable) cannot be power-braked. The Brake On signal notifies the control module to command the throttle closed and may also set false codes.
- Vehicles with full Drive-by-Wire (no throttle cable), usually have a EPC (Electronic Power Control) indicator light. The EPC light should come on if there is any problem in the Drive-by-Wire system. Faults detected by the EPC set duplicate fault codes in the ECM.
- Electronic Instrument Clusters may store only up to four fault codes. Intermittent fault codes are automatically erased if they do not reoccur in the next 50 engine starts.

- **Diesel Only:** Late model Diesel TDI engines (1996 and newer) may have three different code-setting MILs. All three of the following lamps set codes in the ECM memory.
  - Engine Management Check Engine Lamp
  - Glow Plug Warning Lamp
 

This lamp has dual functions: the lamp is on when starting a cold engine, which normally indicates that glow plugs are on; blinking lamps indicate malfunctions that affect driveability.
  - Exhaust Warning Lamp
 

This lamp is switched on with faults that adversely affect emissions (not all exhaust gas faults turn the lamp on; always check for codes regardless of lamp).

### 5.2.3 Data

A Data selection is available from the Main Menu of most vehicles, but only when “Engine Management” is selected from the System Selection menu (see “Selecting a System” on page 14). Viewing data in standard mode with the scan tool does not affect vehicle operation.

The Data selection displays the following choices:

- **Data Groups** displays data in diagnostic groups to make problem solving easier.
- **Codes & Data** displays all data parameters and codes together but the screen data has a slower refresh rate.
- **Return To Main Menu** takes you back to the Main Menu.



**NOTE:**

Some late model vehicles may communicate with the scan tool with the ignition switched off, though communication is limited to the ECM, and data values received may be erroneous. Always communicate with the ignition on.

---

### Data Groups

The Data Groups mode first displays a Group Selection screen.

The data group items available will vary from one vehicle to another. For some vehicles, the data groups list may be as short as two groups, or it may be as long as 25 groups.



**NOTE:**

It is possible to read any display group like the factory tool by selecting Readiness Code from the Functional Tests menu or by selecting Expert Mode > 08-Read Measuring Value Block and entering the display group. Data is displayed in a four-channel format, like the factory tool.

---



**To display data groups:**

1. Select any specific group.

A Data Group screen displays.

When the scan tool first enters the group, it displays the group title and three lines of data.

Scroll down and the scan tool displays the rest of the group data, until End Of Group displays.



2. Scroll past the last line and the scan tool attempts to communicate with the next group in the list and displays the Requesting Data Group screen.
3. After communication has been reestablished, the next group for that vehicle displays. In this way it is possible to scroll through all the data groups, scrolling in the opposite direction moves through the groups in reverse order.

### **Data Group Exit Menu**

When **N** is pressed from the Data Group function the scan tool displays the Exit menu. Exit menus vary slightly, depending on vehicle identification. A typical Exit menu works as described in the user's manual for the scan tool you are using.

### **Codes & Data**

Selecting Codes & Data displays codes and data together.



#### **NOTE:**

The data in the Codes & Data display are preselected from the individual display groups. It is important to note that except for a few early models (with only one display group 000) the preselected "codes and data" represents a limited list that may not include all possible display groups. There may be more display groups available in Expert Mode than in standard mode. Check Expert Mode for any missing display groups.

---

Reading Codes & Data or individual display group data (Measuring Value Blocks 08) can be used for testing as the engine operates normally. The scan tool does not affect the control module when reading data (08). This is not true for 04-Basic Settings (see page 21).

## **5.2.4 Functional Tests**

The Functional Tests menu gives you the ability to activate components of the engine management system.

### **Initiate Actuator Tests**

Which actuators can be activated depends on the control module under test and the vehicle itself. Actuators can include the following:

- Fuel pump relay
- EVAP canister purge valve
- Injector valves (odd and even cylinders)
- Oxygen sensor (O2S) heater relay

---

#### **IMPORTANT:**

The Fuel Pump will run continuously while the Actuator tests are in progress.

---

The scan tool commands the control module to activate a component, but it does not check whether the component is actually operating correctly.

In most cases, the effect can be clearly heard: a relay clicks or a pump runs. Be aware, actuators can be mounted anywhere within the vehicle, (i.e., under the dashboard, under the hood, and even in the trunk). If no reaction can be heard at all, measure the actuator with an oscilloscope or a multimeter. This indicates whether the control module is controlling the component properly.

When Initiate Actuator Tests is selected, the scan tool sequentially activates each of the actuators for 30 seconds. For example, running actuator tests on a 2002 W8 Passat would activate the following actuators in the following sequence:

1. TAnk Vent Valve
2. Secondary Air Control
3. Secondary Air Pump
4. Bank 1 Camshaft Adjustment
5. Evaporative Emission Control System L.D.P.
6. Valve Engine Mounting
7. Bank 2 Camshaft Adjustment
8. Exhaust Cam Timing Valve B1
9. Exhaust Cam Timing Valve B2
10. Control Vacuum Pump Brake
11. Cooling Fan High Speed
12. Cooling Fan Low Speed
13. Cooling Fan Low Speed Deactivated
14. Relay Additional Coolant Pump
15. Injector 1 Activated
16. Injector 1 Deactivated
17. Injector 2 Activated
18. Injector 2 Deactivated
19. Injector 3 Activated
20. Injector 3 Deactivated
21. Injector 4 Activated
22. Injector 4 Deactivated
23. Injector 5 Activated
24. Injector 5 Deactivated
25. Injector 6 Activated
26. Injector 6 Deactivated
27. Injector 7 Activated
28. Injector 7 Deactivated
29. Injector 8 Activated
30. Injector 8 Deactivated

Before the actuator tests can be re-initiated, the vehicle ignition must be turned off. Then, start the engine, turn the engine off, then turn the ignition switch on again. If the actuator tests are re-initialized without the ignition being cycled, the Actuator Test Not Possible screen displays.

**To run actuator tests:**

1. Select **Initiate Actuator Tests** from the Functional Tests menu.  
A warning message displays.  
Selecting **N** returns to the Functional Tests menu.
2. Press **Y**.  
The scan tool proceeds directly to the first actuator test available for the current vehicle ID. This test automatically activates all the actuators applicable to the vehicle for approximately 30 seconds each. The current test displays on-screen.  
Selecting **N** cancels all actuator tests and returns to the Functional Tests menu. Selecting **Y** stops the current actuator test and starts the next available test.

**Important Tips for VW/Audi Engine Actuator Tests**

- The Output Test Function is only available when the engine is not running.
- Exiting and reselecting actuator tests will not re-initiate actuator tests on some engines. It is not recommended to interrupt the test sequence once it has been started. Exiting while an output is activated causes a "Close Controller" command to be issued. If exiting and reselecting the actuator test does not work, turn the key off for 10 seconds, then start the engine, then shut the engine off. Turn the ignition on, then reselect Initiate Actuator Tests from the Functional Test menu. Most control modules will permit the Output Test Sequence to be run only one time per session. Therefore, each new session will usually require an ignition reset and engine start. Verify that the component is present on the vehicle you are testing.
- Have the engine running only when instructed to do so by the scan tool and always follow the instructions displayed on the scan tool.
- With some engines, it is very difficult to hear the injectors click. Use a multimeter, scope, or stethoscope to make sure the injectors are activated properly (if injectors can be reached, it is sometimes possible to feel the injectors working).
- The sequence in which the tests are performed and the availability of the tests are controlled by the control module under test. Output tests available are not determined by the scan tool.
- On some engines, before the actuator test can be re-initiated, the engine has to run at least 30 seconds prior to the test.
- Some automatic transmission systems do not have actuator tests. If Initiate Actuator Tests is selected one of these systems, an Actuator Test Not Possible message displays.
- Some outputs require additional action before they become active. Fuel injectors are a common example. To activate a fuel injector, you must press (and in some cases release) the accelerator pedal.

**⚠ WARNING**

Risk of erratic vehicle response.

- **Do not use the Output Tests function on any system while the car is in motion.**  
*Erratic vehicle response can cause serious injury.*

**Review ECU ID**

This menu item displays the identification data of the control module under test. The data displayed may be required when ordering replacement components for the vehicle.

Supplemental control module information may be available, if so, it can consist of the VIN number, module numbers for additional control units, or other information sent by the control module.

The Review ECU ID screen should display when selected, follow screen instructions.

## Basic Settings

Basic Settings has different functions depending on the year, make, and model. Generally, it involves invoking a specific control module to run in a special mode of operation that either sets the conditions to perform an adjustment or internally run a test. When in Basic Settings, the user may be required to:

- Command the scan tool by entering the correct numbers and making the correct on-screen selections.
- Create the correct vehicle conditions for a diagnostic test to run.
- Operate the vehicle for Accelerated Adaptive Learning.
- Perform an adjustment procedure.



### NOTE:

Basic Setting mode is also used to run system or subsystem Readiness Codes, which verify repair work (see Readiness Code supplement for more information).

---

You can select BASIC SETTING from three different menu choices on the scan tool:

- **Functional Test menu > Basic Settings**—This Basic Setting selection will only have one or two preselected tests with help screens.  
This selection for Basic Settings is different from the “Expert Mode” Basic Settings. This selection will list only one or two important procedures with help screens to guide you through the process. Note that in “Expert mode” neither Basic Settings nor any other selection have any help screens available.
- **Functional Test menu > Readiness Code > 04-Basic Setting**—This Readiness Code mini Expert Mode has some but not all of the functions available under the main Expert Mode.
- **Expert Mode > 01-Engine Management Master > 04-Basic Setting**—Viewing data in Basic Settings (04) is very similar to viewing data in display group mode (08, Measuring Value Blocks). The display group numbers and the specific data displayed are the same, however, the difference is that in Basic Settings the Control Module performs various calibrations or activates certain tests which should be reflected in the readings.

## Engine Management Functional Test Menu

The following Basic Settings can be selected if available:

- **Throttle Valve Adjuster/Idling Control/Adaptation EPC-System (Electronic Throttle Body Adaptation).** In this Basic Setting, the control module relearns the throttle position using an automatic procedure. See “Testing Electronic Throttle Systems” on page 66.



### NOTE:

If possible, the factory procedure recommends performing this test with the engine cold.

---

- **Kickdown Function.** In this Basic Setting, the control module relearns the kickdown position for the automatic transmission. The procedure must be followed exactly. Hold the throttle for

3 seconds, by pressing down the throttle fully to the floor, then release (make sure you feel the kickdown switch engage).

- Always check for kickdown selection in the Engine Functional Test menu, as kickdown adaptation is not always included in the Readiness Code Charts.
- Kickdown may also be selected in Expert Mode. In engine or transmission, select basic settings 04/000. Remember that in Expert mode there are no help screens. Once in Basic Settings, depress the throttle to the floor for three seconds, then release. Press **N** to exit. New kickdown learn settings should be set (no feedback on-screen).

On some models, kickdown relearn may not set properly using Basic Settings in the transmission controller. There is no way to verify that the kickdown reset test has been completed by looking at the transmission data. A test drive before and after may verify that the test was completed. Alternately, select engine management data and select display group 063. If kickdown adaptation status reports an error, go back and select Basic Settings in the Engine Management Functional Tests menu, then select kickdown as stated above.

- **Ignition Timing.** While in Basic Settings mode the ignition timing is fixed; the control module will not attempt to compensate for any variation in ignition timing or idle speed. After any adjustments, press **N** to return engine control to the control module.
- **Start of Delivery (Diesel Engines).** In this Basic Setting, the engine is set in a mode so the start of delivery can be checked or manually adjusted. The actual value as well as the minimum and maximum values are displayed (values displayed depend on temperature).

### ***Basic Setting Screen***

With most Basic Settings, data displays with the required instructions.

Always end the Basic Setting session by selecting Other Systems to be sure that the settings are stored. Turn the ignition key off and wait 60 seconds, to ensure that adaptation has occurred.

---

#### **IMPORTANT:**

You should refer to the Service Manual for a specific vehicle and engine before attempting to use the Basic Settings function. Using an incorrect procedure can have negative consequences.

---

In Basic Settings, certain functions are disabled or stabilized to avoid learning interference and to allow specific tests to run or adaptive learning to happen. Learning usually starts 20 seconds after the initiation of Basic Settings if the engine is at normal operating temperature. Exactly what Basic Setting controls varies by year, vehicle and engine.

Example 1: 1993–1995 engine code AAA or ABA

1. Stabilizes ignition
2. Stabilizes Idle Speed
3. Disables the A/C
4. Disables the Evaporative Control System

Example 2: All Late Model OBD-II

1. A/C is shut off
2. No idle stabilization
3. Disables the Evaporative Control System
4. Runs Readiness Code Monitors
5. Enables accelerated learning

**NOTE:**

In Basic Settings, Evaporative and Leak Detection functions are usually only temporarily disabled depending on the function.

***Basic Settings and Adaptive Learned Values***

Operating parameter values are preprogrammed into the control module as default values. Control module adaptive learning adjusts to these default values as changes in engine conditions occur. If the battery or control module is disconnected or fault codes are erased, learned values are erased and the control module reverts back to the default values. The engine runs, but the default values may not match the current needs of the engine, which can result in poor performance. Also, when repairs are made, the default values may not match the current needs of the engine. The control module has to relearn new adaptive values over time as the vehicle is driven. To expedite the learning process, the scan tool in Basic Settings can force the control module to learn current conditions in several minutes compared to normally taking several days of extended driving to meet all the different conditions.

***Basic Settings and Fuel Trim Accelerated Learning***

After repairs, Long Term Fuel Trim adaptation settings need to be relearned or the vehicle may not operate properly. Basic Settings can be used to accelerate learning, greatly reducing the normal time under standard operating conditions that it would take for adaptation to readjust itself. Note that Audi repair strategy usually includes basic settings accelerated learning, but VW is limited to specific models and systems. However, because VW and Audi share the same technology, Basic Settings may work similarly on VW. For Fuel Trim accelerated Learning on both VW and Audi, initiate basic settings for accelerated learning in the appropriate fuel trim display group (see “Appendix C Fuel Control Learning/Adaptation Values” on page 156). After selecting a display group in Basic Settings, check that the scan tool does not report an error, which usually indicates that Basic Settings is not available for that display group. If no error is reported and the engine is fully warmed up, perform a short road test and monitor if the readings change. If an error is reported, then Basic Settings cannot be used for accelerated learning and a longer road test will be necessary for proper fuel control learning to occur.

***Example: Using basic settings for accelerated learning to assist in diagnosis.***

After replacement of a faulty Mass Air Flow (MAF) sensor on a late model Audi, a technician wants to validate the repair and reset the Long-term fuel trim values. Being careful not to clear codes before road testing because this resets the learned values to 0, the technician records the fuel trim adaptation values (idle and part throttle adaptation) for after repair comparison. With the engine is at operating temperature, Basic Setting in display group 032 is selected, and idle for 3–5 minutes. Then a short road test (1–2 miles) is performed, which includes a few stop-and-go part throttle accelerations. The new MAF should substantially change the fuel trim adaptation values. If values are normal, clear codes and then set all the readiness codes to the OK status. If they all set OK, the technician is very confident that there are no other problems. A final road test is always a good idea, checking for any possible intermittent problems.

**NOTE:**

Out-of-range adaptation readings resulting from a faulty component like a MAF sensor usually will not set a code or turn the MIL on until values are excessive ( $\pm 14$ ). Normal adaptation readings with a good MAF sensor should not exceed  $\pm 5\%$ . Clearing codes or initializing Basic Settings resets the adaptation values back to base or zero. Recording the previous reset readings for comparison is helpful to verify that the repair has corrected the problem.

***Basic Settings and Readiness Codes on OBD-II Vehicles***

Basic Settings is also used on OBD-II vehicles to set Readiness Codes. These are OBD-II Readiness monitor tests that are commanded by the scan tool using Basic Settings.

All Readiness Code tests are run using Basic Settings. OBD-II Readiness Code tests automate many of the previous OBD-I and some early Audi OBD-II adaptation learn procedures that previously required driving the vehicle. Now many of these relearn procedures can be accomplished in the shop without a complex test drive.

On OBD-II vehicles with electronic throttle bodies, the most common use for the Basic Settings function is to recalibrate the throttle position sensors. This is accomplished using Group 098 (electronic throttle with a cable) or 060 (electronic throttle without a cable—full, Drive-by-Wire).

Basic Settings learning is prohibited when:

- Malfunction codes are stored.
- Engine idle is uneven (surging).
- Engine coolant temperature is below 176°F (80°C) or above 230°F (110°C).
- Fuel Mixture is too rich or lean (an excessive difference between the richest and leanest oxygen sensor learning values).
- During acceleration and at Wide Open Throttle. Learning takes place only at idle (650–900 RPM) and at 1500–3000 RPM. Road test the vehicle at steady cruise to set the part throttle fuel trim adaptation.

**NOTE:**

During the diagnosis, if a vehicle has a possible fuel control related problem, it is recommended to record both the idle and part throttle adaptation values (usually display group 032) before clearing codes or performing basic settings. Out of specification adaptation readings may not always set a code. Clearing codes resets the adaptation values and basic settings initiates accelerated learning. Using the previous readings for comparison is helpful to verify that the repair has corrected the problem.

**NOTE:**

Always end the Basic Settings session by selecting Other Systems in standard mode or 06-Stop Communication in Expert Mode to be sure that the settings are stored. Turn the ignition key off and wait 60 seconds.

***Other Basic Setting System Functions***

**Crankshaft Sensor Wheel Learning.** Correction for flywheel gear teeth inconsistency for misfire detection. When the scan tool is connected to the vehicle during a road test in Basic Settings with

the appropriate display group for a specific vehicle, the CKP Sensor wheel is tested during a deceleration fuel shutoff at 2200–4000 RPM. After the learning has occurred, Channel 4 changes to “OK” or learned status “YES”.

**Basic Ignition Timing Check.** Available on most late 1980s to mid-1990s vehicles with adjustable ignition timing. In 04-Basic Setting, the DIS (digital Idle stabilization) is shut down. Base ignition timing can now be checked. On some early vehicles, Basic Setting may also force an open loop operation to allow for mixture adjustment.

**Xenon Lights base setting level control adjustment.** Basic setting is required for Automatic vertical headlight aim control which keeps the tilt angle of the low beam constant regardless of acceleration or load shift.

### ***Problems with Basic Settings***

If the adaptation status displays Error, or other problems occur, read the trouble codes for more information. Check the required conditions and try the basic setting again.

## **Service Interval Reset**

This section includes different service reset procedures for various types of electronic instrument clusters. However, most of these will apply to Audi only and also depend on whether a high or low end cluster is installed (optional equipment on some models).

---

### **NOTE:**



Use Expert Mode for communication problems with the Electronic Instrument service interval reset or if Service Interval Reset is not on the menu. Select 17-Electronic Instrument Panel > 10-Adaptation, then select channel 5 (005), scroll in the 8 for 8,000 kilometers (5,000 miles). Channel 6 is the distance value (24 = 24,000 kilometers or 15,000 miles). Channel 7 is the time value until the next Inspection 1 (36 = 360 days). Channel 8 is the time to Inspection 2 (72 = 720 days). See “Chapter 4 Expert Mode” on page 17 for more information.

---

### ***Vehicles with Manual Mechanical SRI Reset (1995–2000)***

Most VWs have mechanical SRI reset; Audi may have electronic SRI reset depending on model and instrument cluster.



#### **To mechanically reset the oil light:**

1. Switch the ignition on.
2. Press and hold the odometer reset button located below the speedometer.
3. Switch the ignition off and release the odometer reset button.  
OEL (Oil Engine Lamp) appears in the SRI display.
4. Press and hold the lower digital clock reset button or the analog clock reset button until 5 dashes (-----) appear in the display.  
OEL SRI is now reset to 7500 miles or 6 months.

---

### **NOTE:**



Once the OEL is reset, the other displays can be reset without switching the ignition on.

---



**To reset the service light:**

1. Press the odometer reset button to perform the inspection 01.  
IN 01 should be displayed in the SRI display.
2. Reset by pressing the clock button.
3. If necessary, repeat the procedure for Inspection 02.
4. Turn ignition on.  
When IN 01 appears in the SRI display, switch the ignition off, procedure is completed.

***Vehicles with Electronic Service Interval Reset***

On VW/Audi vehicles with electronic dashboards, the following functions may be available from the Functional Tests menu:

- Reset Service Interval
- Reset Service Interval Oil(Km)
- Reset Service Interval Insp1(Km)
- Reset Service Interval Insp1(Days)
- Reset Service Interval Insp2(Days)
- Reset Days And Km After Service
- Pre-set Value Oil(Km)
- Pre-set Value Oil(Days)
- Pre-set Value Insp1(Km)
- Pre-set Value Insp1(Days)
- Pre-set Value Insp2(Km)
- Pre-set Value Min Oil(Km)
- Pre-set Value Max Oil(Km)
- Pre-set Value Oil Quality(Km)
- Read, Set Km Remaining To Oil Service
- Read, Set Days Remaining To Oil Service
- Read, Set Km Remaining To Insp1
- Read, Set Days Remaining To Insp1
- Read, Reset Km After Oil Service
- Read, Reset Days After Oil Serv.
- Read, Reset Days After Insp1
- Read, Reset Km After Insp2

**Note the following when performing an electronic service interval reset.**

- Depending on the type of Electronic Instrument Panel, there are 4 to 9 functions available for Service Resetting.
- The service intervals are measured/set/reset in kilometers even when the speedometer shows miles. The scan tool will calculate the equivalence in miles when showing kilometers.
- Remember that the service intervals can be changed in steps of 100 or 1000 kilometers only. It is not always possible to set them to a round number of miles. The only exceptions are some new instrument panels, Type H and J, which use miles as base value.

- Depending on the type of Instrument Panel, up to three different types of service intervals are available:
  - Oil Service— Oil Change
  - Inspection 1— Yearly Inspection
  - Inspection 2— Bi-yearly Inspection
- Depending on the type of Instrument Panel, the limit values for the above type of inspections are in kilometers and/or days.

**To perform an electronic service interval reset:**

1. Select **17-Electronic Instrument Panel** from the System Selection menu.
2. From the Main Menu, select **Functional Tests**.  
The Functional Tests menu displays.
3. Select **Reset Service Interval**.  
The scan tool displays a warning message.
4. Press **Y** to continue or **N** to abort.  
After pressing **Y**, the Reset Service Interval screen displays.
5. If the value does not need to be changed, press **N** and return to the Functional Tests menu. If the appropriate service has been carried out and the value requires resetting, press **Y**.  
The scan tool displays the Reset Service Interval screen with value changes.  
The number displayed is the recommended value by the factory. This value can be changed by scrolling.
6. Select the correct amount.  
The new value is entered into the control module and the scan tool returns to the Functional Tests menu when **Y** is pressed. If **N** is pressed, the new value is discarded and the scan tool returns to the Functional Tests menu.

**Pre-set Functions**

The Pre-Set functions are used to specify the total length in kilometers and or days between the service intervals. These functions only specify the time or distance between intervals, they do not reset the interval.

**To use pre-set functions:**

1. Select the desired function from the Functional Tests menu.  
The scan tool displays a warning message.
2. Press **Y** to continue or **N** to abort.  
The number displayed after pressing **Y** is the current value.
3. If the value is not to be changed, press **N** return to the Functional Tests menu. If the value requires changing, press **Y** to open the Change Confirmation screen.
4. Press **Y**.  
The Change Preset Value screen displays.  
The number displayed is the current value. When it has never been changed, it is the factory setting. This value can be changed by scrolling.
5. Select the correct amount.

The new value is entered into the control module and the scan tool returns to the Functional Tests menu. If **N** is pressed, the new value is discarded and the scan tool returns to the Functional Tests menu.

### Read, Set/Reset Functions

The Read, Set and Read, Reset functions can be used to read the kilometers or days since the last service set them to the required value. These functions are only needed when an inspection has been carried out prematurely (before the service interval is required). These functions work the same as the Pre-Set functions. See “Pre-set Functions” on page 51.

## 5.3 Testing Transmission Systems

The VAG software cartridge covers the following transmissions:

- AG4 Getriebe 001
- AG4 Getriebe 018
- AG4 Getriebe 01F
- AG4 Getriebe 01K
- AG4 Getriebe 01M
- AG4 Getriebe 01N
- AG4 Getriebe 01P
- AG4 Getriebe 096
- AG4 Getriebe 097
- AG4 Getriebe 098
- AG5 Getriebe 01L
- AG5 Getriebe 01V
- AG5 Getriebe 09A
- AG5 Getriebe 09B
- Digimat 0842
- Direkt-Schaltgetriebe DS085
- Multitronic V30 01J

VW automatic transmission controllers started using digital diagnostics in 1989 on the Passat with the 095 transmission (4-speed) and continued with 096/01M and 098/01P. 5-speeds include the 01V and 09A. All VW transmissions use digital controllers with codes.

Audi started with the 097 transmission (4-speed) in 1990 on 80/90/100 models and continued with 01F, 01K, 01N 5-speeds, which includes the 01L and 01V transmissions. The newest transmission called the Constant Velocity Transmission (CVT) is designated the 01J.

The VW/Audi vehicle communication software starts VIN ID in 1991 (US vehicle systems). On early 1990–1992 vehicles, using VIN ID regular mode the scan tool may display codes only.

Using regular mode, transmission data may not be available until 1993, but you can use Expert Mode to read transmission data on pre-1993 vehicles. See Table 5-8 for coverage.

Table 5-7 lists Volkswagen/Audi transmissions from 1988 to 2003 and their features, and Table 5-8 on page 56 lists Volkswagen/Audi transmissions with the models where they are found.

**Table 5-7** *Transmission types and system descriptions (part 1 of 3)*

| Transmission  | Transmission Features  | Notes  |
|---------------|--|--|
| 018 (ZF4HP24) | <ul style="list-style-type: none"> <li>• 4-speed longitudinal AWD</li> <li>• TCC On/Off Solenoid</li> </ul>  |  |
| 01F (ZF4HP18) | <ul style="list-style-type: none"> <li>• 4-speed longitudinal AWD</li> <li>• TCC variable lockup</li> <li>• TCM: 54-pin, 55-pin, or 88-pin connector</li> <li>• 5 shift programs</li> <li>• 2 emergency running modes</li> </ul>   |  |
| 01J           | <ul style="list-style-type: none"> <li>• CVT longitudinal FWD</li> <li>• TCM inside transmission rear cover</li> </ul>   |  |
| 01K (ZF4HP18) | <ul style="list-style-type: none"> <li>• 4-speed longitudinal FWD</li> <li>• TCC variable lockup</li> <li>• TCM: 54-pin, 55-pin, or 88-pin connector</li> </ul>  |  |
| 01L (ZF5HP24) | <ul style="list-style-type: none"> <li>• 5-speed longitudinal AWD</li> <li>• TCC variable lockup</li> <li>• Lifetime oil</li> <li>• TCM: 88-pin connector</li> </ul>   | Tiptronic appeared on some models in 1998. E17 was the earliest control system. E18/2 started late 1998 on some models. CAN bus appear in some models in 1998. |
| 01M           | <ul style="list-style-type: none"> <li>• 4-speed transverse FWD</li> <li>• Fuzzy logic, 253 constantly adapting shift strategies</li> <li>• Cold start &amp; limp home programs</li> <li>• TCM: 68-pin connector</li> <li>• Converter clutch in torque converter and uses PWM solenoid for variable lockup</li> <li>• Sun shell speed sensor (trans VSS) added for shift timing</li> <li>• Trans ID stamped in case at top of starter boss</li> <li>• Dipstick replaced with fluid level plug</li> </ul> | 096 was renamed 01M and used from mid-1995 to present; year model 1995 may have 096 Phase 1 or 01M Phase 2 trans.  |
| 01N           | <ul style="list-style-type: none"> <li>• 4-speed longitudinal FWD</li> <li>• Used mid-1995 to present</li> <li>• Lifetime oil</li> <li>• TCM: 68-pin connector</li> <li>• Dynamic shift program</li> <li>• Converter clutch in torque converter and Uses PWM solenoid for variable lockup</li> <li>• Sun shell speed sensor added for shift timing</li> <li>• Dipstick replaced with fluid level plug</li> </ul>   | 097 was renamed 01N in mid-1995; year model 1995 may have 097 Phase 1 or 01N Phase 2 trans.  |

**Table 5-7** Transmission types and system descriptions (part 2 of 3)

| Transmission  | Transmission Features  | Notes   |
|---------------|--|---|
| 01P           | <ul style="list-style-type: none"> <li>• 4-speed transverse FWD</li> <li>• Fuzzy logic, 253 constantly adapting shift strategies</li> <li>• Cold start &amp; limp home programs</li> <li>• TCM: 68-pin connector</li> <li>• TCC-PWM</li> <li>• Sun shell speed sensor</li> <li>• Used mid-year 1995 to present</li> <li>• 098 renamed 01P.</li> <li>• Converter clutch in torque converter and uses PWM solenoid</li> <li>• Sun shell speed sensor added for shift timing</li> <li>• Dipstick replaced with fluid level plug</li> </ul>  | Model year 1995 may have either 098 Phase 1 or 01P Phase 2 trans.   |
| 01V (ZF5HP19) | <ul style="list-style-type: none"> <li>• 5-speed longitudinal</li> <li>• FWD or AWD</li> <li>• TCC variable lockup</li> <li>• Lifetime oil</li> <li>• TCM: 88-pin connector</li> </ul>   | <p>(Used for VW and Audi)<br/> FL = FWD, FLA = AWD<br/> VW/Audi: Tiptronic appeared on some models in 1998. E17 was the earliest control system. E18/2 control system started late 1998 on some models. CAN bus appear in some models in 1998.<br/> VW Only: Replaces 01M transmission starting 1998 Passat model year.</p> |
| 095           | <ul style="list-style-type: none"> <li>• 4-speed transverse FWD</li> <li>• Economy/Sport switch on console near shift lever.</li> <li>• K3 clutch locks gear train one to one with torque converter for lockup with On/Off solenoid.</li> <li>• Trans ID stamped at top of bell housing on some.</li> <li>• External transmission oil filter (If not updated "removed" with bulletin #37-91-03).</li> </ul>  | VW introduced the transverse 4-speed, electronically-controlled 095 automatic transmission in model year 1989. It was soon replaced by the 096 transmission in mid-1990.  |
| 096           | <ul style="list-style-type: none"> <li>• 4-speed transverse FWD</li> </ul> <p>Phase 0</p> <ul style="list-style-type: none"> <li>• Used to mid-1993</li> <li>• TCM: 38-pin connector</li> <li>• Economy/Sport switch on console near shift lever</li> <li>• K3 clutch locks gear train one to one with torque converter for lockup with On/Off solenoid</li> <li>• Trans ID stamped at top of bell housing</li> </ul> <p>Phase 1</p> <ul style="list-style-type: none"> <li>• Used mid-year 1993 to mid year 1995</li> <li>• Fuzzy logic, 253 constantly adapting shift strategies</li> <li>• Cold start &amp; limp home programs</li> <li>• TCM: 38-pin or 68-pin connector</li> <li>• K3 clutch locks gear train one to one with torque converter for lockup with On/Off solenoid</li> <li>• Economy/Sport switch deleted</li> <li>• Sport shift map in TCM</li> </ul> | 096 replaced the 095 transmission in mid-1990; year model 1993 may have 096 Phase 0 or Phase 1 trans; 1995 may have 096 phase 1 or 01M phase 2.   |

**Table 5-7** *Transmission types and system descriptions (part 3 of 3)*

| Transmission | Transmission Features  | Notes  |
|--------------|--|--|
| 097          | <ul style="list-style-type: none"> <li>• 4-speed longitudinal FWD</li> </ul> Phase 0: <ul style="list-style-type: none"> <li>• TCM: 38-pin connector</li> <li>• Used to mid-1993</li> <li>• Economy/Sport switch on console near shift lever</li> <li>• K3 clutch locks gear train one to one with torque converter hub for lockup with On/Off solenoid</li> </ul> Phase 1: <ul style="list-style-type: none"> <li>• TCM: 38-pin connector</li> <li>• Used mid-1993 to mid-1995</li> <li>• K3 clutch locks gear train one to one with torque converter for lockup. Uses On/Off solenoid</li> <li>• Economy/Sport switch deleted</li> <li>• Sport shift map in TCM</li> </ul>   | Model year 1993 may have either 097 Phase 0 or Phase 1 trans.; 1995 may have either 097 or 01N.                              |
| 098          | <ul style="list-style-type: none"> <li>• 4-speed transverse FWD</li> <li>• Fuzzy logic, 253 constantly adapting shift strategies</li> <li>• Cold start &amp; limp home programs</li> <li>• TCC On/Off</li> </ul> Phase 0: <ul style="list-style-type: none"> <li>• TCM has 38-pin connector</li> <li>• Used to mid-1993</li> <li>• Economy/Sport switch on console near shift lever</li> <li>• K3 clutch locks gear train one to one with torque converter hub for lockup with On/Off solenoid</li> </ul> Phase 1: <ul style="list-style-type: none"> <li>• TCM: 38-pin or 68-pin connector</li> <li>• Used mid-1993 to mid-1995</li> <li>• K3 clutch locks gear train one to one with torque converter for lockup and Uses On/Off solenoid</li> <li>• Economy/Sport switch deleted</li> <li>• Sport shift map in TCM</li> </ul> | Introduced when Eurovan replaced Vanagon in 1992; year model 1993 may have 098 Phase 0 or Phase 1 trans.; 1995 also has 01P. |
| 09A          | <ul style="list-style-type: none"> <li>• 5-speed transverse FWD</li> <li>• Lifetime oil</li> <li>• TCM: 68-pin connector</li> </ul>  | 2002 Golf/Jetta has either 01M or 09A  |
| 09G          | <ul style="list-style-type: none"> <li>• 6-speed automatic transmission</li> <li>• 6 hydraulically activated forward gears</li> <li>• 2nd, 3rd, 4th, and 6th gears mechanically driven with TCC locked.</li> <li>• ATF oil is filled for life and is not changed.</li> <li>• Uses fuzzy logic adaptation to driving with infinitely variable gear switch points.</li> </ul>  |  |

**Table 5-8** Transmission applications (part 1 of 2)

| Transmission  | Model                        | Engine                                   | Year      | Control System Version     |
|---------------|------------------------------|--|-----------|----------------------------|
| 018 (ZF4HP24) | V8                           | 3.6L                                     | 1990–92   |                            |
|               |                              | 4.2L                                     | 1993–94   |                            |
| 01F (ZF4HP18) | A6                           | 2.8L                                     | 1995–98   |                            |
|               | 100                          | 2.8L                                     | 1992–94   |                            |
| 01J           | A4                           | 1.8L, 1.9L,<br>2.0L, 2.4L,<br>2.5L, 3.0L | 2003–05   | Multitronic                |
|               | A6                           | 3.0L                                     |           |                            |
| 01K (ZF4HP18) | A6                           | 2.8L                                     | 1994–98   |                            |
|               | 100                          | 2.8L                                     | 1992–94   |                            |
| 01L (ZF5HP24) | A6                           | 4.2L                                     | 1999–2005 | E17–E18/2                  |
|               | A8                           | 4.2L                                     | 1997–2005 |                            |
|               | Phaeton                      | 4.2L                                     | 2004–05   |                            |
|               |                              | 6.0L                                     | 2004–05   |                            |
| 01M           | VW Cabrio                    | 2.0L                                     | 1995–2002 | All 01M trans. are Phase 2 |
|               | Golf/Jetta/GTI               | L4 1.8L                                  | 1995–2005 |                            |
|               |                              | 1.9L TD                                  | 1995–2005 |                            |
|               |                              | 2.0L, V6 2.8L                            | 1995–2005 |                            |
|               | New Beetle                   | 1.8L, 1.9L,<br>2.0L                      | 1998–2005 |                            |
| Passat        | 1.8L, 1.9L,<br>2.0L, V6 2.8L | 1995–97                                  |           |                            |
| 01N           | Audi Cabriolet               | 2.8L                                     | 1995–98   | All 01N trans. are Phase 2 |
|               | 90                           | 2.8L                                     | 1995      |                            |
| 01P           | Eurovan                      | 2.4L, L5 2.5L,<br>2.8L                   | 1995–2005 | All 01P trans. are Phase 2 |
| 01V (ZF5HP19) | A4                           | 1.8L                                     | 1997–2003 | E17–E18/2                  |
|               |                              | 2.7L                                     | 1998–2003 |                            |
|               |                              | 2.8L                                     | 1996–2001 |                            |
|               |                              | 3.0L                                     | 2002      | E18/2                      |
|               | A6                           | 2.7L                                     | 2000–03   |                            |
|               |                              | 2.8L                                     | 1998–2003 |                            |
|               | A8                           | 3.7L                                     | 1997–99   | E17–E18/2                  |
|               | Golf/GTI/Jetta               | 1.8L, 2.8L                               | 2001–03   |                            |
|               | Passat FWD                   | 1.8L, 2.8L,<br>4.0L                      | 1998–2005 | E17, E18/2                 |
|               | Passat AWD                   | 2.8L<br>4.0L                             |           |                            |
| 095           | Corrado/<br>Passat           |  | 1989–90   | Phase 0                    |

**Table 5-8** Transmission applications (part 2 of 2)

| Transmission | Model                                   | Engine                                      | Year                       | Control System Version |
|--------------|---|---|----------------------------|------------------------|
| 096          | Corrado                                 | 1.8L  | 1989–92                    | Phase 0                |
|              |   | 2.8L  | 1992–93                    |                        |
|              |   |   | 1993–95                    | Phase 1                |
|              | Golf/Jetta                              | 1.8L  | 1993                       | Phase 0                |
|              |   |   | 1993–95                    | Phase 1                |
|              |   | 2.0L  | 1993                       | Phase 0                |
|              |   |   | 1993–95                    | Phase 1                |
|              |   | 2.8L  | 1993                       | Phase 0                |
|              |   |   | 1993–95                    | Phase 1                |
|              | Passat                                  | 2.0L  | 1990–93                    | Phase 0                |
|              |   |   | 1993–95                    | Phase 1                |
|              |   | V6 2.8L                                     | 1993                       | Phase 0                |
| 1993–95      |   |   | Phase 1                    |                        |
| VW Cabrio    | 2.0L                                    | early 1995                                  |                            |                        |
| 097          | Audi Cabriolet                          | 2.8L  | 1994–95                    | Phase 1                |
|              | 80                                      | 2.3L  | 1990–92                    | Phase 0                |
|              | 90                                      | 2.3L  |                            |                        |
|              |   | 2.8L  | 1992–mid-93                |                        |
|              | mid-1993–95                             |   | Phase 1                    |                        |
|              | 100                                     |   | 1990–92                    | Phase 0                |
| 098          | Eurovan                                 | L5 2.5L                                     | 1992–93                    | Phase 0                |
|              |   |   | 1993–95                    | Phase 1                |
|              |   | 2.4L  | 1993–95                    |                        |
| 09A          | Golf/Jetta                              | 1.8L 132 KW,<br>2.8L 147 KW,<br>2.8L 150 KW | 2002                       |                        |
|              | Golf GTI<br>Jetta<br>Jetta Wagon<br>R32 | 1.8L, 2.0L,<br>1.9TDI, 2.8L,<br>3.2 VR6     | 1999–05                    |                        |
| 09G          | VW New Beetle/Audi TT<br>Passat, Jetta  | 1.8/2.0L,<br>1.9 TDI, 2.5L,<br>3.6L         | 1998 (Beetle)<br>2005 (TT) | 6-speed                |

### 5.3.1 Digimat Control Module Identification—Golf & Jetta, 1993–97

Use Table 5-9 and Table 5-10 to identify which TCMs are available for various 50 state ECM/TCM combinations. Do not update a vehicle unless a specific condition has been identified.



When replacing a TCM for any reason, the TCM must be paired with the ECM according to the chart. VIN numbers are for general reference only. Most VINs shown are approximate.

When multiple TCM part numbers are listed for a particular ECM/TCM combination, they are shown in order of development, the earliest TCM at the top. Part numbers are for reference only. Always check a Volkswagen parts department for the latest information.

**Table 5-9** Engine code AAA

| Model Year              | ECU Part Number   | Vin                                   | TCM Part Number            | Digimat    | Trans Code & Phase | Valve Body Code |
|-------------------------|---|---------------------------------------|----------------------------|------------|--------------------|-----------------|
| 1995                    | 021906258BM<br>021906258EA<br>021906258CR<br>California | From: 1H_S_012883<br>To: 1H_S_012952* | 096927731CE                | 1.0        | CFF Phase 1        | QBA             |
|                         |   | From: 1H_S_012883<br>To: 1H_S_072798  | 096927733AC<br>096927733BA | 2.0        |                    |                 |
|                         |   | From: 1H_S_072799<br>To: 1H_S_999000  | 01M927733F<br>01M927733FJ  | 2.0<br>2.1 | CLB Phase 2        | 7DK<br>QCA      |
| 1996                    | 021906259A  | From: 1H_T_000001                     | 01M927733AC                | 2.0        |                    |                 |
|                         |   |                                       | 01M927733CB                | 2.1        |                    |                 |
| 1997                    | 021906259K  | From: 1H_V_000001<br>To: 1H_V_073027  | 01M927733CB                | 2.1        | DMA Phase 2        | QEA             |
|                         | 021906259AA   | From: 1H_V_073028<br>To: 1H_V_999000  | 01M927733DM                |            |                    |                 |
| * German-built vehicles |   |                                       |                            |            |                    |                 |

**Table 5-10** Engine code ABA (part 1 of 2)

| Model Year | ECU Part Number   | Vin                                  | TCM Part Number            | Digimat | Trans Code & Phase         | Valve Body Code |
|------------|---|--------------------------------------|----------------------------|---------|----------------------------|-----------------|
| 1993       | 037906258T<br>037906258AA<br>037906258AH<br>037906258AE | From: 1H_P_012601<br>To: 1H_P_999000 | 096927731BH                | 1.0     | CFH Phase 1                | QBA             |
|            |   | From: 1H_R_000001<br>To: 1H_R_999000 |                            |         |                            |                 |
| 1995       | 037906258T<br>037906258AA<br>037906258AH<br>037906258AE | From: 1H_S_000001<br>To: 1H_S_012952 | 096927731BH                | 1.0     | CFH Phase 1<br>CNK Phase 1 |                 |
|            |   | From: 1H_S_012953<br>To: 1H_S_066798 | 096927733AB<br>096927733AT | 2.0     |                            |                 |
|            |   | From: 1H_S_066799<br>To: 1H_S_999000 | 01M927733BA<br>01M927733CD | 2.0     | CLK Phase 2<br>CLA Phase 2 | 7DK<br>QCA      |
|            |   | 01M927733EB                          | 2.1                        |         |                            |                 |

**Table 5-10** Engine code ABA (part 2 of 2)

| Model Year | ECU Part Number                         | Vin                                   | TCM Part Number                          | Digimat | Trans Code & Phase   | Valve Body Code |
|------------|---|---------------------------------------|--|---------|----------------------|-----------------|
| 1996       | 037906259<br>037906259X<br>037906259JX  | From: 1H_T_000001<br>To: See footnote | 01M927733M<br>01M927733DN<br>01M927733EA | 2.0     | CLK Phase 2          | 7DK             |
|            | 037906259D<br>Tier 1 (w/LDP)*           | From: 1H_T_118928<br>To: 1H_T_999000  | 01M927733CA                              | 2.1     |                      |                 |
|            | 037906259E<br>TLEV (w/air pumps & LDP)* | From: 1H_T_117284<br>To: 1H_T_999000  |  |         |                      |                 |
| 1997       | 037906259D<br>Tier 1 (w/LDP)*           | From: 1H_V_000001<br>To: See footnote | 01M927733CA                              | 2.1     | CLK Phase 2          | 7DK             |
|            | 037906259E<br>TLEV (w/air pumps & LDP)* |                                       |  |         |                      |                 |
|            | 037906259M<br>Tier 1 (w/LDP)*           | From: 1H_V_070133<br>To: 1H_V_999000  | 01M927733DL                              |         | DLZ Phase 2<br>"ETA" | QEA             |
|            | 037906259N<br>TLEV (w/air pumps & LDP)* | From: 1H_V_074116<br>To: 1H_V_999000  |  |         |                      |                 |

### 5.3.2 4-Speed Automatic Transmission—01N

The 01N transmission is an electronically-controlled transmission with adaptive control. Shift points are automatically regulated to provide three distinct operating characteristics:

- Comfort driving, maximum fuel economy (shift points are kept low)
- Average driving (shift points are slightly raised)
- High-performance driving (shift points increase to allow higher engine speed between gears)

The transmission control module can tune the shift program incrementally between these modes with up to 244 variations. This is referred to as the DSP (Dynamic Shift Program). Each of these 244 variations can be seen using the scan tool. Tapping the accelerator twice will raise the program one level, which means that the transmission shift points will occur at a higher engine RPM. These increments are indicated on the scan tool by numbers 0–244, with 0 representing the lowest RPM shift points and 244 indicating the highest.

### 5.3.3 VW Series—095, 096, 01M

These TCMs have gear changes based on driving situation (Fuzzy Logic). Depending on the driving situation and driving force resistance, gear change points are determined automatically.

These transmissions have the following advantages:

- Gear changes are fuel consumption orientated.
- Maximum engine output is always available.

- Individual adaptation of gear change points in all driving situations.
- Gear change points are infinitely variable.

A gear change map automatically selects gear changes for gradients depending on accelerator pedal position and driving speed, which has the following advantages:

- Gear change map for extreme uphill stretches is matched to engine output.
- Gear change map for extreme downhill stretches is matched to the engine braking effect.

### 5.3.4 Audi Transmission—01F, 01K



---

**NOTE:**

Audi transmission Fuzzy Logic Shift Adaptation features are usually more complicated than Volkswagen transmissions.

---

The Dynamic Selection Program (DSP) represents a new form of intelligent switching logic. DSP eliminates the program switch. It can choose automatically between five different selection programs and makes for optimum adaptation of the gear selection characteristic to vehicle handling and usage conditions. The signals for Throttle-valve Opening, Engine Speed, Road Speed and Vehicle Longitudinal Acceleration/deceleration are used by the TCM to determine a characteristic response number which forms the basis for selection of one of the five programs. Control of the shift points can be a long-term or a short-term function.

DSP offers the following advantages:

- Better adaptation of shift points to driving habits and traffic situations (five instead of two selection programs).
- No driver-selected program switch.
- Better handling in extreme situations, for example when towing a trailer or on a steep hill.
- Greater fuel economy than previous “Economy” driving program in urban traffic.
- Further improved power potential in selection program 5 as opposed to the previous “sport” driving program.

Long-term functions include the following:

- A normal driving style results in a low characteristic response number which results in a more fuel-economic selection program where the gears are shifted in average time.
- A sporty driving style results in a high characteristic response number and a selection program where switching up a gear is delayed and switching down a gear is done sooner.

Short-term functions include the following:

- Instant selection program at a road speed in excess of 34 MPH (55 KPH).
- With rapid acceleration, a shift-down to the lowest possible gear without fully depressing the kickdown switch.
- Returns to the original selection program following initiation of an upward gearshift or after dropping below a fixed throttle-valve value.

### 5.3.5 Important Tips for Transmission Codes

- For both VW and Audi, on 1996 and newer models, when emission or limp-home related transmission faults are stored, all the dash transmission gear selector indicator lights may turn on and stay on until fault is cleared. For some pre-OBD-II models, the PRND321 light may turn on or flash. Some may reverse video foreground/background (black background/white letters) when transmission codes are stored.
- For both VW and Audi, transmission limp-home mode defaults to a fixed gear (2nd or 3rd gear). Certain stored codes initiate limp-home mode. The transmission stays in limp-home until the fault or faults are repaired.
- Multifunction switch-related faults usually turn the transmission MIL on. Other faults are less predictable.
- Transmission codes affecting emissions may not turn on the transmission MIL.
- For some sensor-related faults, the transmission control unit may substitute a fixed value.
- Not all faults initiate limp-home mode. There are different degrees of limp-home mode depending on the problem.
- After repairs, solenoid-related faults usually clear failsafe mode. Other faults usually require a clear codes function before the failsafe clears. In addition, the transmission may not shift correctly until codes are cleared. Always clear codes after repairs which reset any modified shift operation or failsafe mode.
- On 1996 or newer models, disconnecting the vehicle battery will not turn out the engine or the transmission MIL.
- Intermittent faults have “Error Occurs Intermittent” after the code description. Intermittent codes are faults usually not reoccurring within a minimum of 3 miles or 6 minutes and a maximum of 12 miles or 24 minutes. When a malfunction is first detected, it is stored as a static or pending malfunction. If the malfunction no longer exists after the above listed pre-determined time or distance traveled, then it is labeled intermittent. Intermittent faults usually auto erase after 625 miles or 20 hours of operation.
- Codes may set if the vehicle battery is disconnected or if the transmission is removed from vehicle for service.
- Most 1995 and earlier Bosch control modules may display a false DTC, such as “00513-Engine Speed Sensor (G28)” or “00526-Brake Light Implausible Signal” if the engine is not running. These fault codes should disappear once the engine is started. With a defective sensor, the engine would not start.
- If DTC memory cannot be cleared, check that the ignition switch position was not altered during DTC retrieval. The ignition switch must remain on during DTC retrieval and the clearing procedure.
- DTCs need to have the test followed exactly. First, check DTC memory and repair malfunctions. Next, erase DTC memory.
- On early transmissions (1989–1992), use Expert Mode for data parameters. With some 1989 models with the scan tool hooked up, the vehicle may only accelerate to 1900 RPM. This is normal vehicle software operation. Use Expert mode to obtain the data group binary readings and get help with interpretation in “Transmission Expert Mode Parameters” on page 147.

### 5.3.6 Transmission Basic Settings

This selection for Basic Settings is different from the “Expert Mode” Basic Settings. This selection will only list up to two adaptation tests with help. See “Basic Settings” on page 45 for a complete description of Basic Settings.

The following selections are available from the Basic Setting menu. The first selection, Throttle Body Adaptation, must be done in Engine testing (see “Engine Management Functional Test Menu” on page 45). Kickdown Function may be done in Transmission testing.

Restore a system to Basic Setting (adaptation) after performing the following repairs:

- Engine exchange
- Throttle position adjustment
- Throttle valve conversion
- Replacement of throttle position sensor
- Replacement of transmission control module
- Transaxle shifting concern

**NOTE:**

Check for any codes present and clear before starting this procedure.

---

- **Throttle Body Adaptation.** In this Basic Setting, the control module learns the throttle position with an automatic procedure. The electronic throttle body needs to be readapted every time codes are cleared or control module power is disconnected.
- Throttle Body and Transmission kickdown adaptations (also included as part of Readiness Codes) must be set to avoid driveability problems. The other OBD-II Readiness Codes will set on their own eventually and not produce driveability problems. Clearing codes may not necessarily change throttle body adaptation status to NOT OK, however, driveability problems may occur after an extended road test.
- **Kickdown Function.** In this Basic Setting, the control module relearns the kickdown position for the automatic transmission. In addition, shift learned values are reset to base settings. Resetting can be very useful for various driving styles causing learned erratic shifting. The procedure must be followed exactly. Hold the throttle for 3 seconds, by pressing down the throttle fully to the floor, then release (make sure you feel the kickdown switch engage).
  - Always check for kickdown selection in the Engine Functional Test menu, as kickdown adaptation is not always included in the Readiness Code Charts.
  - Kickdown may also be selected in Expert Mode. In engine or transmission, select Basic Setting 04/000. Remember that in Expert mode there are no screen prompts. Once in Basic Settings, depress the throttle to floor for three seconds, then release. Press **N** to exit. New kickdown learn settings should be set (no feedback on-screen).
  - On some models, kickdown relearn may not set properly using Basic Settings in the transmission controller. There is no way to verify that the kickdown reset test has been completed by looking at the transmission data. A test drive before and after may verify that the test was completed or select engine management data and select display group 063. If kickdown adaptation status reports an error, go back and select Basic Settings in the Engine Management Functional Tests menu, then select kickdown as stated above.

**NOTE:**

VW added a resistor to the brake pedal circuit that activates the kickdown relearn procedure when the brake pedal has been depressed. This resets transmission adaptation on some models during brake apply.

**Important Tips for Transmission Basic Settings**

- Basic Settings 04/000 also resets transmission learned shifting adaptation to 0 or base point. Some early transmissions have no Basic Setting selection. To reset adaptation on these, switch the ignition on without starting the engine and press the accelerator all the way to the floor, turn ignition off, let up on accelerator, restart engine. Drive the car and monitor shifting. It should shift at default with no learning. Early transmissions may require an extended road test to learn new shift adaptation.

**5.3.7 Functional Tests—VW Passat 01V**

A differentiation is made between two types 01V transmissions:

- **Type I** has the transmission input speed sensor (inductive sensor) secured to the underside of the valve body (E17).
- **Type II** has the input speed sensor secured behind the valve body at the transmission housing (E 18-2).

Both types have the following output diagnostic tests available in Functional Tests:

- The output diagnostic test mode is a part of a system electric test. The output diagnostic test mode checks the solenoid valves, the shift lock solenoid, the kickdown switch, and the relay for the solenoid valves.
- The output diagnostic test mode can only be performed when the selector lever is position “P”, the engine is not running and the vehicle is stationary.
- The output diagnostic will be terminated if the engine is started.
- The function of the solenoid valves 1-N88-, 2-N89-, 3-N90- and the solenoids for the selector lever lock are checked acoustically during the output diagnostic test mode. Avoid noise in the surrounding area during the acoustic check because the switching noise (clicking) of the final controls is very quiet.
- The solenoid valves 4 –N91-, 5-N92-, 6-N93- and 7 –N94- are activated during the output diagnostic test mode. A direct functional check of these valves is not possible. But a possible electrical fault, which occurs during the activation, will be recognized by the on-board diagnostic (OBD) and stored in the DTC memory.
- Only one complete output diagnostic test mode is possible after switching the ignition on. To repeat the output diagnostic test mode, the ignition must be switched off and on again (sometimes this may require engine to be started).

## Type I Transmission (E17) Solenoid Activation

### Activation sequence:

1. Solenoid valve 1 –N88-
2. Solenoid valve 2 –N89-
3. Solenoid valve 3 –N90
4. Shift lock solenoid –N110-
5. Solenoid valve 4 –N91-
6. Solenoid valve 5 –N92-
7. Solenoid valve 6 –N93-
8. Solenoid valve 7 –N94-
9. Kickdown switch –F8- (Kickdown for air conditioner)
10. Solenoid valves relay



### NOTE:

If the kickdown switch is operated, the transmission control module briefly switches off the air conditioner compressor.

---

## Type II Transmission (E18/2) Solenoid Activation

### Activation sequence:

1. Solenoid valve 1 –N88-
2. Solenoid valve 2 –N89-
3. Solenoid valve 3 –N90
4. Shift lock solenoid –N110-
5. Pressure control valve 1 –N215-
6. Pressure control valve 2 –N216-
7. Pressure control valve 3 –N217-
8. Pressure control valve 4 –N218-
9. Voltage supply for Solenoid valves



### NOTE:

Pressure-regulating valve –5- for automatic transmission –N233- could be displayed erroneously—valve –5- does not exist on the –N233-.

---

## Fail-safe Functions of the TCM

If individual or several components or sensors fail, the transmission control module (TCM) activates corresponding substitute functions or backup programs to ensure the automatic transmission operates, allowing a vehicle to be driven to a safe location. The respective effect is noticeable on the operation and quality of the gearshifts.

If critical malfunctions occur and the TCM is active, the gear engaged at that moment is maintained initially. The TCM activates the “Fail-safe mode with active control module” as soon as the driving situation permits it while ensuring transmission security and road safety.

#### ***Fail-safe Mode with Active Control Module***

- Transmission shifts out of all forward gears into hydraulic 4th gear. Torque converter clutch is open. All solenoid valves are de-energized.
- Maximum shift pressure applied to the power-transmitting elements.
- Reverse gear can be engaged. Selector lever lock is inactive (In “P” and “N”)
- All the segments of the gear display light up completely.

If the TCM fails, the transmission immediately continues to operate in “Fail-safe mode with non-active control module”.

#### ***Fail-safe Mode with Non-active Control Module***

- Transmission shifts out of all forward gears into hydraulic 4th gear. Torque converter clutch is open. All solenoid valves are de-energized.
- Maximum shift pressure applied to the power-transmitting elements.
- Reverse gear can be engaged. Selector lever lock is inactive (“P” and “N”).
- All the segments of the gear display are dark.
- The TCM is completely inoperative and it is not possible to initiate the on-board diagnostic.

### **5.3.8 VW/Audi Transmission Emergency Operation—01V**

If an electrical fault occurs, and depending on the TCM, emergency operation may use two different limp-home programs to prevent transmission damage while retaining the ability of the vehicle to move. In either mode, all segments of gear indicator usually light up.

#### **Emergency Operation 1**

In the absence of certain signals, the TCM switches to maximum modulation pressure (pressure for actuating shift elements). Clutches and brakes in the transmission are rapidly operated and protected against damage. The transmission will shift harshly in this mode.

#### **Emergency Operation 2**

In the absence of certain signals or actuator circuits, the TCM de-energizes the relay for the solenoid valves. The solenoid valves in the valve assembly are deactivated, thus preventing gear selection. If this occurs while the engine is running, 4th gear is engaged. If the vehicle is braked to a standstill, the engine cuts out since 4th gear is a direct mechanical drive with no converter action. On restarting the engine, it is possible to drive in 2nd gear and reverse.



**NOTE:**

Two important relays are housed in the control module. The solenoid-valve relay serves as a safety relay and is de-energized in limp-home mode as is the relay for the cruise control system.

## 5.4 Testing Electronic Throttle Systems

The following sections contain scan tool testing information for VW/Audi electronic throttle systems.

### 5.4.1 Throttle Valve Control Module Adaptation

All 1996 VW/Audi electronic throttle systems require adaptation. There are different electronic throttle types as described further in this section, but all types require the adaptation procedure whenever one of the following has occurred:

- Throttle Valve Control Module, ECM, or TCM is removed or replaced.
- Power supply to control module is interrupted.
- Low or disconnected battery.
- Codes are cleared.

#### What the Adaptation Process Does

The adaptation process involves the control module learning the different throttle valve positions so that it knows the exact throttle position. It compares previous voltage readings with new voltage reading inputs from two angle position sensors located inside the throttle actuator housing. If the adaptation procedure is successful, these new positions are stored in the control module. Simply put, throttle adaptation is the control module learning exact throttle positions against previous preprogrammed values. If the two sets of readings exceed the range of tolerance, an error is reported.

Typical conditions before throttle adaptation include the following:

- Key on engine off.
- No stored DTCs.
- Battery Voltage of at least 11.5 volts.
- All electrical consumers switched off (lights, heater fan, etc.).
- Throttle must be in closed position (foot off accelerator pedal).
- Engine coolant temperature between 41–212°F (5–100°C). Certain vehicles may require above 176°F (80°C).
- Intake temperature less than 212°F (100°C).

#### Performing throttle body adaptation

Throttle body adaptation is performed using Basic Settings listed under the Functional Test menu (“Basic Settings” on page 45) or in Expert Mode (“04-Basic Settings” on page 21). If selected in

Functional Tests, the automated menu will prompt you through the process. If using Expert Mode, see the Readiness Code Chart Manual for the exact application procedure. If applicable, throttle adaptation is always one of the first steps in the chart.

Readiness Codes always need to be reset after codes are cleared or the battery has been disconnected. Throttle body adaptation relearn (part of Readiness Code procedure) is essential and may prevent the engine from starting (it can also cause MIL to go on or cause driveability problems). Clearing codes using a Generic OBD-II scan tool has the same effect.

**NOTE:**

Clearing codes may not change throttle body adaptation status to NOT READY (060 or 098), but performing a throttle body adaptation after clearing codes is recommended to ensure no problems. See the *Volkswagen/Audi OBD-II Readiness Code Charts* for more information.

---

An unsuccessful adaptation may be caused by any of the following:

- Throttle valve is unable to close because of dirt or carbon buildup.
- Battery voltage is too low.
- Throttle body actuator connector is loose or contacts are corroded or damaged.
- Throttle valve housing is distorted (check bolts for proper torque).
- Engine was started or throttle was depressed during the adaptation.

The scan tool performs the adaptation process by sending the correct command to the control module using a special operation mode called Basic Settings (see “Basic Settings” on page 45). After the scan tool sends the command to start the test, the control module sends the test measurements and the final adaptation result back to the scan tool.

---

**NOTE:**

Throttle body faults may also cause misfire faults.

---

If a throttle body faults occur, try to set adaptation again. If errors still occur, check and clean the throttle body. Attempt to set the adaptation again. If errors are still present, check for wiring and connection problems between the throttle body and the control module.

### What should I do if I get pedal position faults?

If pedal position faults occur, first check the wiring by using scan tool in measuring block 62, which will allow you to see both pedal sensors. Look for one pedal position sensor not responding.

Next, check the connectors at throttle body and the control module. Check the wiring for continuity.

Throttle body or pedal position faults may be caused by any of the following:

- If the MIL stays on after the engine starts, the throttle body may be failing self-test at startup.
- Cell phone antennas and cables can cause electromagnetic interference problems.

Electronic throttle systems are sensitive to a low or disconnected battery, especially if the ignition was left on. With a low battery, adaptation settings may erase, which may cause poor idle or poor throttle response (emergency run mode). On the 2000/2001 Type III throttle actuator, this may cause a start and die condition. With this condition, the MIL may be on with a fault code set. The fault code will not clear until throttle body adaptation is performed. Throttle body adaptation reset procedure is done in Basic Settings Mode (04). See “Basic Settings” on page 45.

In an emergency, there is an alternative, less reliable method. Turn the ignition on for at least six seconds without operating the starter or depressing the accelerator pedal. The control module must register a Learning Requirement in order for this procedure to work because previously stored voltage readings from the angle sensors do not correspond to the new voltage readings.

Electronic throttle valves are sealed units and are not serviceable. Internal component failure means replacing a complete unit.

## 5.4.2 Electronic Throttle Types

Due to availability at the time of this writing, the information below references VW, but the information regarding the three electronic throttle control systems is applicable to Audi (throttle system type by years is the same for Audi). The types listed below were developed for VW only.

### Type I

VW Electronic Throttle Valve Control started in 1996 with the M5.9 management system. This first design replaced the separate Throttle Position Sensor and Idle Air Control Valve. This first electronic throttle body module still has a throttle cable (not full Drive-by-Wire system). This early style controls idle speed only by means of a movable throttle stop controlled by an electric servo motor which is connected to the throttle plate. Within the sealed housing (no adjustment capability) are the following 4 components:

- Throttle Position Sensor (G69)
- Closed Throttle Position (CTP) switch (F60)
- Throttle Position (TP) sensor (G88)
- Throttle Position (TP) actuator (V60)

The G69 sensor has a full range (reads actual throttle plate position) 0.5–5.0V reference signal (called Throttle Position Sensor (V) on the scan tool). Voltage is high at idle, about 4.0–4.5V and low, about 0.3–0.8V, at wide open throttle (WOT).

The G88 sensor reads the position of the idle or bottom throttle stop position of the actuator. On this sensor (called Throttle Valve Adjuster (V) on the scan tool), voltage normally reads in the 3–4 V range. This type of sensor provides feedback on the throttle position actuator and the throttle stop position. Input voltage is crosschecked against the input voltage from the G69 sensor for plausibility. This G88 sensor, which has a reduced voltage range, changes minimally when the throttle is moved and the engine is running. The actuator only controls idle speed and opens during deceleration. Scan tool display group 060 or 098 (Throttle Valve Adjuster) at idle, part-throttle, and WOT:

#### Idle:

|                                      |       |
|--------------------------------------|-------|
| THROTTLE POSITION SENSOR (V) _____   | 4.380 |
| THROTTLE VALVE ADJUSTER (IDLE) _____ | 3.680 |
| THROTTLE ADJUSTER MODE _____         | IDLE  |
| ADAPTATION STATUS _____              | OK    |

**Part-throttle:**

|                                    |      |
|------------------------------------|------|
| THROTTLE POSITION SENSOR (V)       | 3.90 |
| THROTTLE VALVE ADJUSTER (IDLE) (V) | 2.28 |
| THROTTLE ADJUSTER MODE             | PART |
| ADAPTATION STATUS                  | OK   |

**WOT:**

|                                    |        |
|------------------------------------|--------|
| THROTTLE POSITION SENSOR (V)       | 0.8    |
| THROTTLE VALVE ADJUSTER (IDLE) (V) | 1.66   |
| THROTTLE ADJUSTER MODE             | ENRICH |
| ADAPTATION STATUS                  | OK     |

With the key on and the engine off, Throttle Valve Adjuster (Idle) (V) voltage does not change with throttle movement. With the engine running and throttle movement, voltage change is minimal and lags behind the actual Throttle Position Sensor. Also note that actual Throttle Position Sensor has opposite voltage graph pattern to engine speed (high at idle and low at WOT).

**Type II**

The next type of electronic throttle system came out in 1998 with the VW M5.9.2 engine management system. It is similar to Type 1 (still has a throttle cable) except that cruise control is now integrated into the throttle valve control module. The important difference from Type I is that the scan tool does not display throttle position voltages. Instead, the scan tool display reads throttle angle (degrees) and percent. Also different from Type I, Throttle Valve Angle now increases with engine speed (moves up and down in the same direction), while Thr Valve Adjuster moves in the opposite direction to throttle or engine speed.

Some vehicles may also read Display group 054 (Idle control) which includes Thr Valve Adjuster in degrees (THR ADJ (°) in a Codes & Data screen). Scan tool display group 060 (Throttle Valve Adjuster):

|                                |      |
|--------------------------------|------|
| THROTTLE VALVE ANGLE (degrees) | 2    |
| THR VALVE ADJUSTER (%)         | 75.2 |
| OPERATING MODE ENGINE          | IDLE |
| ADAPTATION STATUS              | OK   |
| THROTTLE VALVE ANGLE (degrees) | 36   |
| THR VALVE ADJUSTER (%)         | 57.6 |
| OPERATING MODE ENGINE          | PART |
| ADAPTATION STATUS              | OK   |
| THROTTLE VALVE ANGLE (degrees) | 85   |
| THR VALVE ADJUSTER (%)         | 39.2 |
| OPERATING MODE ENGINE          | FULL |
| ADAPTATION STATUS              | OK   |

**Type III**

The third type is the full Drive-by-Wire electronic throttle module that came out in 2000 (VW) on the M7.0, M7.1, M7.5.1 engine management systems. This system is easily recognized by the absence of a throttle cable. The accelerator pedal has two position sensors (variable resistors) both installed in a single housing and connected to the accelerator pedal. The throttle valve is actuated by a servo motor (throttle valve positioner) which is control module-controlled. There are two throttle valve angle sensors which measure throttle valve position. Each one sends its own

signal to the control module. Dual sensors are used for backup plausibility on both the accelerator position and throttle actuator position sensors in case one fails.

### Emergency Running or Limp-Home Mode

There are two emergency running modes for accelerator pedal sensor failure; one for when one accelerator pedal sensor fails, and one for when both accelerator pedal sensors fail.

When one accelerator pedal sensor fails:

- Accelerator position is limited to a predefined value.
- Brake pedal switch on indicates idling speed.
- If there are implausible signals between sensors, then the lower value is used.
- Comfort functions are disabled.
- Electronic Engine Power (EPC) light is illuminated.

When both accelerator pedal sensors fail:

- EPC light is illuminated.
- Engine runs only at idle speed.

There are three emergency running modes for throttle actuator module failure. One for when one throttle valve angle sensor fails, one for when the throttle valve actuator fails or malfunctions, and one for when throttle valve position is not recognized.

When one throttle valve angle sensor fails, engine power output is greatly reduced.

When the throttle valve actuator fails or malfunctions (both angle sensors are good) and when throttle valve position is not recognized (implausible signals):

- Voltage to the actuator is shutoff.
- Throttle valve defaults to mechanical stop position.
- Engine speed is limited to 1200 RPM.

It is important to note that the control module can open and close the throttle valve independently of the driver. For example, under certain conditions, such as during traction control or electronic transmission shift optimization controlling engine torque, the driver's foot may have little or no affect on acceleration. This system is an integrated subsystem, complete with its own on-board monitoring system and EPC indicator light.

### EPC Indicator Light Operation

The EPC dash warning lamp is used for the Electronic Throttle Control System (Drive-by-Wire). The control module checks the throttle control system and turns the EPC light off if all checks out OK. It also turns the EPC light on if it detects a malfunction. Codes are stored and read at the control module.



---

**NOTE:**

Field technicians note that in addition to Drive-by-Wire faults, the EPC light may also be turned on for other engine non-emission related faults. If a fault is emission-related and EPC-related, then both MIL and EPC lights may be on.

---

**NOTE:**

At idle, neither the Throttle Valve Angle Sensor nor the Accelerator Pedal Position Sensor are monitored for faults. If the accelerator pedal module becomes disconnected, it may not set a code nor turn the EPC light on (field reports indicate that in some cases a throttle body code may set). In this condition, the engine only idles and does not respond to accelerator input.

Here is an example of a late model Drive-by-Wire data as read on the scan tool in display group 062 (EPCSYSTEM):

**IDLE:**

|                                |    |
|--------------------------------|----|
| THROTTLE VALVE ANGLE SNS 1 (%) | 11 |
| THROTTLE VALVE ANGLE SNS 2 (%) | 87 |
| ACCEL.PEDAL POSITION SNS 1 (%) | 14 |
| ACCEL.PEDAL POSITION SNS 2 (%) | 7  |

**WOT:**

|                                |    |
|--------------------------------|----|
| THROTTLE VALVE ANGLE SNS 1 (%) | 87 |
| THROTTLE VALVE ANGLE SNS 2 (%) | 11 |
| ACCEL.PEDAL POSITION SNS 1 (%) | 76 |
| ACCEL.PEDAL POSITION SNS 2 (%) | 38 |

Readings for Throttle Valve Angle Sns 1 & 2 are inverse to each other at idle and WOT. Also note that Accel Pedal Position Sns 1 is double Accel Pedal Position Sns 2 (this is true for any pedal position).

## 5.5 Testing ABS Systems

The following sections contain scan tool testing information for VW/Audi antilock brake systems (ABS).

**NOTE:**

The VW/Audi vehicle communication software starts VW/Audi US VIN ID in 1991 and only identifies those ABS systems with Codes and Data (does not retrieve blink codes).

The scan tool communicates with the VW ABS systems in Table 5-11.

**Table 5-11** VW ABS system applications (part 1 of 2)

| ABS Systems       | Codes | Data |
|-------------------|-------|------|
| ABS 20 IE CAN     | YES   | YES  |
| ABS 30 IE CAN     | YES   | YES  |
| ABS 5.3 Front     | YES   | YES  |
| ABS 5.7 Front     | YES   | YES  |
| ABS Bosch 5       | YES   | YES  |
| ABS Front MK60    | YES   | YES  |
| ABS ITTAE 20 DI   | YES   | YES  |
| ABS Teves 04      | YES   | NO   |
| ABS/ASR 5.3 Front | YES   | YES  |

**Table 5-11** VW ABS system applications (part 2 of 2)

| ABS Systems         | Codes | Data |
|---------------------|-------|------|
| ABS/EDS 20 IE CAN   | YES   | YES  |
| ABS/EDS 5.3         | YES   | YES  |
| ABS/EDS 5.3 Front   | YES   | YES  |
| ABS/EDS 5.3 Quattro | YES   | YES  |
| ABS/EDS Bosch 5     | YES   | YES  |
| ABS/EDS ITTAE 20 GI | YES   | YES  |
| ABS/EDS Teves 02    | YES   | NO   |
| ABS/EDS Teves 04    | YES   | NO   |
| ABS/ESP Allrad      | YES   | YES  |
| ABS/ESP Front       | YES   | YES  |
| ASR 20 IE CAN       | YES   | YES  |
| ASR Front MK60      | YES   | YES  |
| Bremson-Elektronik  | YES   | YES  |
| ESP 20 CAN          | YES   | YES  |
| ESP 5.3 T4 Front    | YES   | YES  |
| ESP 5.7 Allrad      | YES   | YES  |
| ESP 5.7 Front       | YES   | YES  |
| ESP 5.7 RS          | YES   | YES  |
| ESP Allrad MK60     | YES   | YES  |
| ESP Front MK60      | YES   | YES  |

Table 5-12 lists VW ABS systems and Table 5-13 lists Audi ABS systems.

**Table 5-12** VW ABS types and system descriptions (part 1 of 2)

| ABS Type   | Year/Model  | Codes/Data     | Connector   |
|--|---|----------------|---|
| TEVES MK II<br>ABS/EDL   | • 1990 Jetta GLI (9A)   | Blink codes    | Gear lever box under<br>shift lever cover. White/<br>Black connector  |
|  | • 1991–92 Jetta GLI (9A)  | Codes and Data |   |
|  | • 1989–91 Corrado (PG)  | Blink codes    |   |
|  | • 1992 Corrado (AAA)  | Codes and Data |   |
| TEVES MK IV<br>ABS/EDL   | <ul style="list-style-type: none"> <li>• 1994–95 Jetta VR6 (AAA)</li> <li>• 1995 Cabriolet (ABA)</li> <li>• 1993–95 Golf (ABA)</li> <li>• 1995 Golf/GTI VR6 (AAA)</li> <li>• 1993–94 Corrado (AAA)</li> <li>• 1992–95 Passat (AAA)</li> </ul> | Codes and Data | The connector may be<br>in one of three<br>locations. See<br>Table 3-3 on page 12<br>for connector location<br>information. |
| EDL = Electronic Differential Lock; ASR = Anti-Slip Regulation; ESP = Electronic Stability Program |   |                |   |

**Table 5-12** VW ABS types and system descriptions (part 2 of 2)

| ABS Type   | Year/Model  | Codes/Data     | Connector                          |
|--|---|----------------|------------------------------------|
| TEVES ITT MARK 20 IE<br>ABS/EDL<br>Smaller pump than TEVES MK IV                                   | <ul style="list-style-type: none"> <li>• 1996 Passat (AAA)</li> <li>• 1997/8–2000 all models</li> <li>• 1998–2005 New Beetle</li> </ul>   | Codes and Data | OBD-II DLC under left side of dash |
| TEVES 60 IE/EDL/<br>ASR/ESP/Front wheel drive or 4 Motion  | <ul style="list-style-type: none"> <li>• All 2003 models</li> <li>• 2005 New Golf GTI</li> </ul>  | Codes and Data | OBD-II DLC under left side of dash |
| ABS/EDL/ASR/ESP<br>No mechanical brake pressure regulator  | <ul style="list-style-type: none"> <li>• 1997–2003 Eurovan (Bosch 5.0/5.3)</li> <li>• Up to 2001 Passat (Bosch 5.3)</li> <li>• 2002–03 Passat (Bosch 5.7)</li> <li>• 2004–05 Phaeton (Bosch 5.7)</li> </ul> | Codes and Data | OBD-II DLC under left side of dash |
| EDL = Electronic Differential Lock; ASR = Anti-Slip Regulation; ESP = Electronic Stability Program |   |                |                                    |

**Table 5-13** Audi ABS types and system descriptions

| ABS Type                            | Year/Model   | Codes/Data     | Connector   |
|-------------------------------------|--|----------------|---|
| BOSCH II ABS                        | <ul style="list-style-type: none"> <li>• 1996–88 5000 Quattro</li> <li>• 1988–92 90/90 Quattro</li> <li>• 1992–94 80</li> </ul>        | None           | None  |
|                                     | <ul style="list-style-type: none"> <li>• 1992–94 S4</li> <li>• 1994 100</li> <li>• 1995 A6/A6 Quattro</li> </ul>                       | Codes          | Auxiliary relay station 1 at rear of engine compartment |
| BOSCH 5.0<br>ABS/EDL                | <ul style="list-style-type: none"> <li>• 1996–97 A6</li> </ul>   | Codes and Data |   |
| BOSCH 5.3<br>ABS/EDL/ASR/ESP        | <ul style="list-style-type: none"> <li>• 1998–2002 A4/A6/A8</li> </ul>   | Codes and Data | OBD-II DLC under left side of dash                      |
| BOSCH 5.7<br>ABS/EDL/ASR/ESP        | <ul style="list-style-type: none"> <li>• 2002-2004 A4</li> <li>• 2003-2004 A4 Cabrio</li> <li>• 2004 S4</li> <li>• 2004 A8L</li> </ul> |                |   |
| ABS/EDL/ASR ITT<br>Mark 20 IE       | <ul style="list-style-type: none"> <li>• 2001–02 A4</li> <li>• 2001–04 A6</li> <li>• 2005 TT</li> </ul>                                |                |   |
| MARK 60 IE<br>ABS/EDP/ESP ITT       | <ul style="list-style-type: none"> <li>• 2003–05 TT</li> <li>• 2005 A3</li> </ul>  |                |   |
| EDP = Electronic Brake Distribution |  |                |   |



### Important Tips for Audi ABS Testing

- In many of the newer models, there will be a series of beeps from the dash when you access the ABS controller (and the ABS light will be on during diagnostics). This is normal and is done to notify the driver that the ABS is nonfunctional while in diagnostic mode.

#### **WARNING**

Risk of erratic vehicle response.

- **Do not use the Output Tests function on any system while the car is in motion. Running Output Tests on the ABS can temporarily disable brakes entirely and cause individual wheels to lock and unlock.**

*Erratic vehicle response can cause serious injury.*

### 5.5.1 ABS Basic Settings

Basic Setting must be selected from Expert Mode to perform the following for late model traction and stability control:

- Zero position adjustment of steering angle sensor.
- Test the plausibility of sensor signals (yaw and press) for transverse acceleration.
- Any brake bleeding on systems equipped with Electronic Stability Control (ESP) (ESP hydraulic pump requires basic settings to bleed).



---

**NOTE:**

ABS/ESP Basic Setting brake bleeding usually requires login.

---

**To login for ABS/ESP Basic Setting brake bleeding:**

1. Select 03-ABS/EDL/ESP/TCS.
2. Select 11 Login.
3. Enter Login Code from Service Manual (varies with model and year).
4. Select channel 002.
5. Follow procedure from the Service Manual.

## 5.6 Testing Immobilizer Systems



---

**NOTE:**

All Immobilizer functions must be done in Expert Mode.

---

In the US, Volkswagen has three generations of antitheft systems.

The **first system** was used in the early 1990s. The 1996–99 Golf/Jetta may have a key fob with a transmitter used for remote activation of the Pneumatic Central Locking System. This system has no self-diagnostic capability and is nothing more than series of micro switches in the doors, hood and trunk and a starter lockout. When armed, the alarm would sound if a door, hood or trunk was opened and the starter circuit would be deactivated. The important aspect to remember here is that this system does not have an ignition key immobilizer, it is an alarm system only.

The **second system**, Immobilizer II. It came out on some 1999 models, but was used only on the 2000/2001 Golf, Jetta and New Beetle. Immobilizer II uses an electronic key that prevents the engine from starting without a matching key microchip. There is a symbol in the instrument cluster showing a key inside a car. If a new (or different control module) is installed in the vehicle, the Immobilizer prevents the engine from running and causes the symbol to flash. The scan tool performs all of the adaptation functions on the Immobilizer II system including new key adaptation, but only if the 4-digit security code is available for that specific vehicle. This security code may be found under a scratch-off tag on the key fob or a scratch-off tab on the instrument cluster (which has to be removed to inspect).

The **third system**, called Immobilizer III, came out on some VW models in approximately 1999. Electric door locks replaced the pneumatic locks and Radio Remote Key fobs are replaced with either a straight or switchblade-type key that has an embedded transmitter. Immobilizer III also uses an electronic key. The Immobilizer prevents the engine from running without a matching key microchip. There is a symbol in the instrument cluster showing a key inside a car. If a new (or different control module) is installed in the vehicle, the Immobilizer prevents the car from running and causes the symbol to flash. The Immobilizer III system has self-diagnostic capability for both the remote and Locking Security System. The Immobilizer III system incorporates 4 systems:

- Central Door Lock System (35)
- Comfort System (46)
- Electronic Instrument Panel (17)
- Engine Control Module (01)

### 5.6.1 Important Tips for Testing Immobilizer III Systems

- Key matching is performed using an adaptation function in the Comfort System (46). With this system, a 7-digit secret key code (SKC) is required in order to perform any adaptation routine on most models. However, some early (1999) models use the 4-digit security code from the Immobilizer II system.
- The 7 digit security code routine changes depending on whether you are using a brand new control module that has never been in any other car, or if you are using a used control module that has been previously matched to another car. See “Immobilizer II Engine Control Module Replacement Adaptation” on page 76.
- The scan tool does not perform the Immobilizer III key adaptation function. The system requires a special 7-digit secret key code (SKC) currently only obtained from the VW or Audi dealer. In the future, the factory tool may be hooked directly to a VW site and eliminate the need for the dealer to obtain the code. However, the scan tool does read the 14-digit Immobilizer control module identification number which must be provided along with the VIN to obtain the 7-digit security code. The scan tool also can perform ignition key matching to the key remote control system (see “Radio Frequency Remote Control Functions” on page 80). The information on Immobilizer III key adaptation is only to help you understand the process given the extreme importance and need. Please understand that this information is subject to change and is only current for the date at the time this manual was written.

## 5.6.2 Audi Immobilizers

In the US, some early Audi models (1995–1996 A6) use the Infrared Remote key system and Pneumatic Central Locking that has no diagnostic capability. The 1997 A6, may have remote keys or a key fob with a transmitter to activate the central locking system. The remote key fob does not have diagnostic capability but the Central Locking does. Audi started using the Immobilizer III system in 1998.

## 5.6.3 Immobilizer Adaptation Procedures

The following sections provide Immobilizer adaptation procedures.

### Immobilizer II Engine Control Module Replacement Adaptation

The following procedure introduces a new control module to the instrument cluster. This must be performed each time the engine control module is replaced on a system with Immobilizer II.



#### To perform control module replacement adaptation with Immobilizer II:

1. Install the new control module in the car.
2. Connect the scan tool to the vehicle and select **Expert Mode** (see “Initiating Expert Mode” on page 17 for more information).  
The Expert Mode System Selection menu displays.
3. Select **17-Electronic Instrument Panel**.  
The Expert Mode Function Selection menu displays.
4. Select **10-Adaptation**.  
The Select Adaptation Channel screen displays.
5. Scroll in Channel **000** and press **Y**.  
The Clear Adaptation Values confirmation screen displays.
6. Press **Y** to clear adaptation values.  
The Adaptation Value Stored screen displays.
7. Press **N** exit.
8. Select **06-Stop Communication**.
9. Turn the ignition off for 10 seconds, then back on again. Leave the ignition on for two minutes without starting the engine. After two minutes, start the vehicle.

### Key Coding (Adaptation)

The following procedure outlines the key coding (adaptation) procedure for the Immobilizer II (early Immobilizer III) systems that use a 4-digit security code. Currently, the scan tool cannot perform key matching or adapting using the 7-digit security code obtained from the dealer. The 4-digit security code was available through 1999 (Immobilizer II) and may be found under a scratch-off tag on the key fob, or on a scratch-off tab on the instrument cluster (which has to be removed to inspect). All keys must be available at the start of the adaptation procedure.

**To perform a key adaptation:**

1. Connect the scan tool to the vehicle and select **Expert Mode** (see “Initiating Expert Mode” on page 17 for more information).
2. Select **17-Electronic Instrument Panel** (integrated immobilizer) or **25-Immobilizer** if separated.  
The Function Selection menu displays.
3. Select **11-Login Request**.
4. Scroll in the 4-digit security code preceded with a zero (for example, 0XXXX).
5. Press **N** to return to the Function Selection menu.
6. Select **10-Adaptation**.
7. Scroll in 021 (or 001 for separate Immobilizer 25).
8. Scroll in the number of keys to be programmed and press **Y** to store.  
After 2 seconds, the Immobilizer warning light in the dashboard should go off. The key in the ignition is now matched (adapted).
9. Press **N** to return to the Function Selection menu.
10. Turn the ignition off and remove the key from the ignition switch
11. Insert the next key into the ignition switch and turn the ignition switch on.  
The dashboard Immobilizer warning light should go on for about 2 seconds, then go out.
12. As soon as the warning light goes out, turn the ignition off and remove the key.  
This key is now matched (adapted).
13. Insert the next key into the ignition switch and turn the ignition switch on (within 30 seconds) and repeat procedure.

**NOTE:**

All keys must be inserted and the ignition switch turned on within 30 seconds after removing the last key.

14. After all keys are adapted, press **N** to return to the Function Selection menu.
15. Select **06-Stop Communication** before disconnecting the scan tool.

**NOTE:**

Any keys that are not present for the adaptation will not be recognized by the vehicle after the matching has completed. Any keys that are not adapted cause the Immobilizer light to flash. If a mismatched or unadapted key is used to start the car, the engine starts, runs for 2 seconds, and then dies.

**Immobilizer III Engine Control Module Replacement Adaptation**

The following procedure introduces a new control module to the instrument cluster. This must be performed when the engine control module is replaced on an Immobilizer III system.

**To perform control module replacement adaptation with Immobilizer III:**

1. Measure battery voltage.  
Voltage should be maintained at 12.5V or higher.
2. Install the new control module in the vehicle.

3. Connect the scan tool to the vehicle and select **Expert Mode** (see “Initiating Expert Mode” on page 17 for more information).  
The System Selection menu displays.
4. Select **01-Engine Management Master**.  
The ECU ID screen displays.
5. Verify that the VIN and the 14-digit Immobilizer serial number have been written to the new control module by checking the ECU ID.  
If they have not been written automatically to the new control module from the instrument cluster, a row of Xs displays, indicating that this action cannot be performed with the scan tool (requires 7-digit security code). If the VIN and the 14-digit serial number display, continue with the following steps to validate that the control module was coded correctly.
6. Press **Y** to proceed to the Function Selection menu.
7. Select **07-ECU Coding** to make sure the control module coding is correct.
8. Press **N** to return to the Function Selection menu.
9. Perform a Readiness Code Setting. See the “Volkswagen/Audi OBD-II Readiness Code Charts” supplement manual for details.

### Immobilizer II and III Adaptation: Remote Key Programming (Integrated Remote)

New or additional ignition keys must be matched to the Immobilizer and comfort system control electronics. The matching procedure must always be carried out for all the ignition keys, including the existing ones. The number of keys already matched will be displayed when the adaptation (matching) function is selected. You must have all ignition keys available to perform this procedure. If there is no existing ignition key, contact your VW/Audi dealer.



#### To match ignition keys to radio frequency remote control:

1. Insert correct profile (mechanically-programmed key marked “W”) key into the ignition lock (usually there is one mechanical key and 2 switchblade-type remote keys marked “W3”).
2. Connect the scan tool to the vehicle and select **Expert Mode** (see “Initiating Expert Mode” on page 17 for more information).
3. Select **46-Comfort System**.
4. Select **10-Adaptation**.
5. Enter Channel 000 (erase all keys with channel number 000).  
It is not possible to match new or additional keys without erasing existing keys.
6. Press **Y** to confirm the deletion of learned values.
7. Scroll in Channel 001.  
All keys are “learned” with channel number 001.
8. Scroll to select the number of keys, including the existing mechanical key in the ignition switch, (e.g. 00003) and press **Y** to confirm.  
There is a maximum of four possible keys that can be matched.
9. Press **N** to exit back to the Function Selection menu.
10. Press the lock or unlock button for one second, once on each of the radio frequency keys to be “learned” (in the example above, two keys). This must be completed within 15 seconds after pressing **N** to exit.
11. After all the remote keys are adapted, select **06-Stop Communication**.

12. Switch off the ignition and remove the ignition key.
13. Test the remote keys for proper operation.

### VW 1996–99 Remote Key Programming (Separate Remote)

Two keys and all remote controls that will be programmed are needed. A maximum of four keys can be programmed (old and new keys included).



#### To program 1996–99 mechanical keys:

1. Insert the first key into the ignition switch and turn it to “ignition on.”
2. Insert the second key into the outer door handle and turn it to the unlocked position for 10 seconds.  
The system alarm will beep three times.
3. Press button 1 on the first remote control to be programmed.  
The system alarm will beep two times.
4. Press button 1 on the second remote control to be programmed.  
The system alarm will beep two times.
5. Do the same for any further keys you wish to program.



#### NOTE:

All remote controls must be programmed within one minute, otherwise the new programming will be cancelled.

6. Turn the key in the outer door handle to the unlocked position for 10 seconds.  
The system alarm will beep once.
7. Switch the ignition off.

### Important Tips for Setting Immobilizer Adaptations

- All keys are “learned” in one matching sequence.
- 15 seconds must not be exceeded when matching all ignition keys (pressing either the lock or unlock button).
- A successful adaptation can be determined via Read Measured Value Block, function 08, display group number 013. The operation of the radio frequency unit measurement values must have the status OK. Simultaneously, the last measurement value will show the positional number of the key (i.e. first, second, third, fourth).
- If the remote control key is operated several times, the third display “no measured value” changes to “OK.”
- The matching of ignition keys is automatically terminated when:
  - Number of keys to be matched is reached.
  - A button of one of the keys to be “learned” is pressed frequently.
  - Permissible matching period of 15 seconds is exceeded (DTC is stored).
- Select function 02-Check DTC Memory. If there is no DTC stored, the matching of the keys has been successfully completed.

## 5.6.4 Radio Frequency Remote Control Functions

The functions in Table 5-14 on page 80 are examples of remote control variations that can be adapted by selecting 46-Comfort Systems > 10-Adaptation > channels 003–010.



### To change the battery in the remote key:

1. Insert a screwdriver in the slot between the transmitter unit -1- and the main key.
2. Move the screwdriver to unclip the transmitter unit from the main key.
3. Pry the transmitter unit apart on the two locating lugs.
4. Unclip the upper battery from the retainers with a screwdriver.

The contact plate has two straight edges. When these edges are turned toward the retainers, the contact plate can be removed. The contact plate can also be unclipped with a screwdriver.

5. Unclip the lower battery from the retainers with a screwdriver.

**Table 5-14** Sample remote key option settings

| Passat, New Beetle, New Jetta, New Golf |   |  |                   |
|---|---|--|-------------------|
| Channel                                 | 1998  | 1999–2000  | Condition         |
| 03                                      | Auto-lock: Vehicle is locked at 10 MPH (15 KPH) | Auto-lock: Vehicle is locked at 10 MPH (15 KPH)      | 1 = On<br>0 = Off |
| 04                                      | Interior monitoring switch off (if equipped)    | Auto-unlock: Vehicle is unlocked when key is removed |                   |
| 05                                      | Unlock: Horn sounds                             | Interior monitoring switch off (if equipped)         |                   |
| 06                                      | Lock: Horn sounds                               | Unlock: Horn sounds                                  |                   |
| 07                                      | Unlock: Turn signals flash twice                | Lock: Horn sounds                                    |                   |
| 08                                      | Lock: Turn signals flash once                   | Unlock: Turn signals flash twice                     |                   |
| 09                                      | —   | Lock: Turn signals flash once                        |                   |
| 10                                      | —   | Not for North American vehicles                      | —                 |

6. Place the battery with the positive terminal downward into the transmitter (positive terminal is marked on the housing).

Note the polarity and correct position when installing the batteries.

7. Place the contact plate on the battery.
8. Place the battery, with the positive terminal downward, onto the contact plate and secure.
9. Place the transmitter halves together and clip to fasten.
10. Engage the transmitter unit with the main key.



### NOTE:

When operating a radio wave remote control, the LED must flash briefly. If the LED does not flash, the battery is discharged and must be replaced.

## 5.6.5 Immobilizer Frequently Asked Questions

Refer to the following frequently asked questions for additional information.

### How do you tell if you have an Immobilizer?

With the key on and engine off, look for a yellow key dash light which should come on momentarily and then off.

### What does a flashing key dash light mean?

If it does not go out and starts flashing, then the Immobilizer has detected a problem and most likely the engine will not start.

### What are the possible causes for the Immobilizer light to flash?

- Wrong ignition key was inserted into the ignition switch
- Faulty key transponder
- Faulty control module
- Faulty Instrument Cluster

### What should always be done after working on the Immobilizer system?

- Check and clear any engine faults.
- Check and clear any Immobilizer (25) faults.
- Check and clear any CAN bus (19) faults.
- Check and clear any Instrument Cluster (17) faults.

### How do you tell if you have Immobilizer II or III?

Immobilizer III knows the VIN, which is imbedded in the CAN bus control unit.



#### To distinguish between Immobilizer II or III:

1. Connect the scan tool to the vehicle and select **Expert Mode** (see “Initiating Expert Mode” on page 17 for more information).
2. Select **17-Electronic Instrument Panel** or **25-Immobilizer (Separated)**.
3. Press **Y** until the ECU ID screen displays.

If you see something like “Immo-ID VWZ7Z0W0648696”, you have Immobilizer II.

If you see something like “WVZKB58001H231169 VWZ7Z0W0648696”, you have Immobilizer III. The first 17-digit string is the VIN. The second 14-digit string is the Immobilizer identification number.

### What does the scan tool do on Immobilizer II?

It can perform all Immobilizer functions if the 4-digit, vehicle-specific security code is known.



**Does the scan tool work on Immobilizer III?**

Yes. The scan tool can do key matching to the remote system and remote key adaptation. However, the scan tool cannot adapt new keys or adapt either a control module or Instrument Cluster to the Immobilizer III system.

**Is the key matching to the remote system the same procedure for Immobilizer II or III?**

Yes, although there may be different remote key option configurations depending on the vehicle.

## 5.7 Testing Electronic Instrument Panel Systems

The following sections provide information for testing electronic instrument panel systems.

### 5.7.1 Electronic Instrument Panel Types

There are several types of Electronic Instrument Panels and the possibilities of each type are described in the following sections.

**Electronic Instrument Panel, Type A**

The available functions are:

- Reset Service Interval Oil(Km)
- Reset Service Interval Insp1(Km)
- Reset Service Interval Insp1(Days)
- Reset Service Interval Insp2(Days)

After an Oil Service, the following must be used:

- Reset Service Interval Oil(Km)

After an Inspection 1, the following must be used:

- Reset Service Interval Oil(Km)
- Reset Service Interval Insp1(Km)
- Reset Service Interval Insp1(Days)

After an Inspection 2, the following must be used:

- Reset Service Interval Oil(Km)
- Reset Service Interval Insp1(Km)
- Reset Service Interval Insp1(Days)
- Reset Service Interval Insp2(Days)

## Electronic Instrument Panel, Type B

The available functions are:

- Reset Service Interval
- Pre-set Value Oil(Km)
- Pre-set Value Insp1(Km)
- Pre-set Value Insp1(Days)
- Read, Set Km Remaining To Oil Service
- Read, Set Km Remaining To Insp1
- Read, Set Days Remaining To Insp1

After any service, with the dashboard service indication on, the following must be used:

- Reset Service Interval

After an Oil Service, with the dashboard service indication off, such as a premature service, use the following function:

- Read, Set Km Remaining To Oil Service

After an Inspection 1, with the dashboard service indication off, such as a premature service, use the following functions:

- Read, Set Km Remaining To Insp1
- Read, Set Days Remaining To Insp1

## Electronic Instrument Panel, Type C

The available functions are:

- Pre-set Value Oil(KM)
- Pre-set Value Oil(Days)
- Pre-set Value Insp1(Days)
- Pre-set Value Insp2(KM)
- Read, Reset Km After Oil Service
- Read, Reset Days After Oil Serv.
- Read, Reset Days After Insp1
- Read, Reset Km After Insp2

After performing the Oil Service, the following functions must be used:

- Read, Reset Km After Oil Service
- Read, Reset Days After Oil Serv.

After performing the Inspection 1, the following function must be used:

- Read, Reset Days After Insp1

After performing the Inspection 2, the following function must be used:

- Read, Reset Km After Insp2

## Electronic Instrument Panel, Type D

The available functions are:

- Pre-set Value Oil(Km)
- Pre-set Value Insp1(Days)
- Read, Reset Km After Oil Service
- Read, Reset Days After Insp1

After an Oil Service, the following function must be used:

- Read, Reset Km After Oil Service

After an Inspection 1, the following function must be used:

- Read, Reset Days After Insp1

## Electronic Instrument Panel, Type E

The available functions are:

- Reset Service Interval
- Pre-set Value Oil(Km)
- Pre-set Value Insp1(Days)
- Read, Reset Km After Oil Service
- Read, Reset Days After Insp1

After any service, with the dashboard service indication on, the following must be used:

- Reset Service Interval

After an Oil Service, with the dashboard service indication off, i.e. a premature service, the following function must be used:

- Read, Reset Km After To Oil Service

After an Inspection 1, with the dashboard service indication off, i.e. a premature service, the following function must be used:

- Read, Reset Days After Insp1

## Electronic Instrument Panel, Type F

The Type F Instrument Panel can be programmed to use fixed or flexible Service Intervals (Table 5-15). For a fixed interval, the variables are set 15,000 KM. For flexible Service Intervals, minimum distance is set to 15,000 KM and Maximum is set to 30,000, 35,000 or 50,000 KM.

**Table 5-15** *Service intervals*

| Vehicle Type  | Interval Type Required                             |
|---|--|
| Vehicles with fixed intervals (Oil Quality 1)   | Fixed intervals (15000 kilometers, 9300 miles)     |
| Gasoline engines (Oil Quality 2)  | Flexible intervals (30000 kilometers, 18600 miles) |
| 6-cylinder diesel engines (Oil Quality 3)   | Flexible intervals (35000 kilometers, 21700 miles) |
| Diesel engines (Oil Quality 4)  | Flexible intervals (50000 kilometers, 31000 miles) |
| Insp1 has a factory setting of 365 days (1 year) for fixed intervals and 730 days (2 years) for flexible intervals. |  |

The available functions are:

- Reset Service Interval
- Pre-set Value Oil Quality(Km)
- Pre-set Value Min Oil(Km)
- Pre-set Value Max Oil(Km)
- Pre-set Value Insp1(Days)

After the Inspection the following functions must be used:

- Pre-set Value Oil Quality(Km)

Even when this number stays the same, this value must be changed. It is necessary for the internal housekeeping of the Instrument Panel. When the Oil Quality has been changed, check Minimum, Maximum and Insp1 for correct values, then use this function to reset the rest of the internal housekeeping of the Instrument Panel.

- Reset Service Interval

### **Electronic Instrument Panel, Type G**

The Type G Instrument Panel can be programmed to use fixed or flexible Service Intervals. Interval variables are the same as for a Type F Instrument Panel. See Table 5-15 on page 84 for service intervals.

The available functions are:

- Reset Service Interval
- Pre-set Value Oil Quality(Km)
- Pre-set Value Min Oil(Km)
- Pre-set Value Max Oil(Km)
- Pre-set Value Min Insp(Days)
- Pre-set Value Max Insp(Days)

After the Inspection the following functions must be used:

- Pre-set Value Oil Quality(Km)

Even when this number stays the same, this value must be changed. It is necessary for the internal housekeeping of the Instrument Panel. When the Oil Quality has been changed, check Minimum, Maximum Oil and Minimum, Maximum Insp for correct values.

Then use this function to reset the rest of the internal housekeeping of the Instrument Panel.

- Reset Service Interval

### **Electronic Instrument Panel, Type H**

The available functions are:

- Reset Service Interval
- Pre-set Value Oil(Miles)
- Pre-set Value Insp1(Days)
- Read, Reset Miles After Oil Service

- Read, Reset Days After Insp1

After any service, with the dashboard service indication ON, the following must be used:

- Reset Service Interval

After an Oil Service, with the dashboard service indication OFF (i.e. a premature service), the following function must be used:

- Read, Reset Miles After Oil Service

After an Inspection 1, with the dashboard service indication OFF, (i.e. a premature service), the following function must be used:

- Read, Reset Days After Insp1

### **Electronic Instrument Panel, Type I**

The available functions are:

- Reset Service Interval
- Pre-set Value Min Oil(Km)
- Pre-set Value Max Oil(Km)
- Pre-set Value Min Insp(Days)

After the service the following must be used:

- Reset Service Interval

### **Electronic Instrument Panel, Type J**

The Type J Instrument Panel can be programmed to use fixed or flexible Service Intervals. Interval variables are the same as for a Type F Instrument Panel (see Table 5-15 on page 84).

The available functions are:

- Reset Service Interval
- Pre-set Value Oil Quality(Miles)
- Pre-set Value Min Oil(Miles)
- Pre-set Value Max Oil(Miles)
- Pre-set Value Insp1(Days)

After the Inspection the following functions must be used:

- Pre-set Value Oil Quality(Miles)

Even when this number stays the same, this value must be changed. It is necessary for the internal housekeeping of the Instrument Panel. When the Oil Quality has been changed, check Minimum, Maximum Oil and Minimum, Maximum Insp for correct values.

Then use this function to reset the rest of the internal housekeeping of the Instrument Panel.

- Reset Service Interval

## Electronic Instrument Panel, Type K

The available functions are:

- Reset Service Interval

After the service the following function must be used:

- Reset Service Interval

Refer to the vehicle owner's manual for the actual values of the Service Interval settings.

## 5.8 Testing Airbag (SRS) Systems

There are currently three types of airbag (SRS) systems on VW/Audi vehicles.

*Airbag I* came out in 1989 and was used until about 1993 for both VW and Audi. This system had only one driver's side airbag and limited diagnostics—codes only (no data). California emission equipped vehicles may have red, white and black connectors. The red connector is for the Airbag I system. If the vehicle is Federal emission equipped, then it may only have a red and black connector. The airbag module on this system is pre-coded at the factory (no version coding).



---

**NOTE:**

The Snap-on® scan tool may read Airbag I codes without code definitions by hooking the white connector of the VW-1 adapter to the red vehicle connector and the black VW-1 connector to the black vehicle connector.

---

*Airbag II* was used from 1994 to 1995 for Audi models and from 1996 to 1998 for VW models. This SRS system displays codes and data and the module is version coded. This system uses pyrotechnics for seatbelt retraction and has dual airbags, one for the driver (steering wheel) and one for the passenger (front dash).

*Airbag III* is used from 1996 to 2003 for Audi models and from 1998 to 2003 for VW models. This system displays codes and data and the module is version coded. This system also uses pyrotechnics for seatbelt retraction and has dual airbags for the driver (steering wheel) and passenger (front dash).

**Note the following when working on SRS systems:**

- 1993–94 VW vehicles may have no airbag systems.
- For Airbag I, Audi has recalled KF for a static electricity deployment problem. The recall converts the system to an Airbag II module with codes and data but still has only the one driver's side airbag. To see if recall has been done, lift up the rear seat and look for two separate modules bolted to the body sheet metal. If both modules have been removed and the harnesses are taped, then the recall has been performed. If these two modules are present, then recall has not been performed and should be done.
- Airbag II and III systems are version coded. Be sure to use the latest version coding tables and that the battery is fully charged before coding the airbag modules. Coding is performed with the key on, engine off. Battery voltage should not drop below 11.6V. High quality battery chargers with noise and voltage spiking suppression are recommended.

---

**IMPORTANT:**

Coding and module corruption may occur if the battery goes dead during the coding process.

---

- SRS components made for European vehicles are not the same as for the US. Certain aftermarket sport steering wheels with SRS may be available for sale that do not meet U.S. SRS deployment specifications. Always identify the correct airbag system and verify the correct component configuration prior to version coding.

## 5.9 Testing CAN Data Bus Systems

Late 2001 and early 2002 models started using a CAN (Controller Area Network) data bus, which affects diagnostics and how and when the scan tool is used. The CAN data bus ensures that the electronics in the vehicle still remain manageable and do not take up too much space. CAN means that control units are networked and interchange data.

The CAN data bus is made up of a controller, a transceiver, two data bus terminals, and two data bus lines. Apart from the data bus lines, the components are located in the control units.

The CAN controller receives the transfer data from the microcomputer integrated in the control unit. The CAN controller processes this data and relays it to the CAN transceiver. Likewise, the CAN controller receives data from the CAN transceiver, processes it and relays it to the microcomputer integrated in the control unit.

The data bus does not have a designated receiver. Data is sent over the data bus and is generally received and evaluated by all subscribers (modules on the data bus).

### 5.9.1 Sources of Interference

Components which produce sparks or in which electric circuits are open or closed during operation can be sources of interference. Other sources of interference include mobile telephones and transmitter stations, or any other object which produces electromagnetic waves. Electromagnetic waves can affect or corrupt data transfer.

To prevent interference with the data transfer, the two data bus lines are twisted together so that the voltage on both lines is opposed. That means that if a voltage of approximately 0 Volts is applied to the one data bus line, then a voltage of approximately 5 Volts is applied to the other line and vice versa. As a result, the total voltage remains constant at all times and the electromagnetic field effects of the two data bus lines cancel each other out. The data bus line is protected against received interference and is virtually neutral in sending interference.

### 5.9.2 Powertrain CAN Bus

The CAN data bus links the following:

- The Motronic Engine management control unit
- The ABS/EDL control unit
- The automatic gearbox control unit

The data bus operates at a speed of 500 kbit/s (500,000 bits per second). This means that it lies in a speed range (high speed) from 125 to 1000 kbit/s. A data protocol transfer takes

approximately 0.25 milliseconds. Each control unit (depending on type) tries to send its data at intervals of 7–20 milliseconds.

If more than one control unit wants to send its data protocol simultaneously, the system must decide which control unit comes first. For safety reasons, the data protocol supplied by the ABS/EDL control unit is more important than the data protocol supplied by the engine control unit or automatic gearbox unit, so ABS/EDL data takes priority and is sent first. Table 5-16 demonstrates the order of priority of data on the CAN bus line.

**Table 5-16** Order of CAN bus information priorities in the drive train

| Priority | Control Unit         | Example   |
|----------|----------------------|---|
| 1        | ABS/EDL              | Request for Traction Control System (TCS)                     |
| 2        | ECU, data protocol 1 | Engine speed; throttle valve position; kickdown               |
| 3        | ECU, data protocol 2 | Coolant temperature; road speed                               |
| 4        | TCM                  | Gearshift; gearbox in emergency mode; selector lever position |



**NOTE:**

All control units which interchange information must be regarded as an integrated system during self-diagnosis and troubleshooting. This means data displayed at one control unit may actually be shared from another control unit on the CAN Bus. Codes set in one control unit will often set codes in other control units which share the data bus. Always clear codes in each control unit and monitor in which control unit the codes return.

### 5.9.3 CAN Data Bus in the Convenience System

The following functions of the convenience system transfer data:

- Central locking
- Electric windows
- Switch illumination
- Electrically adjustable and heated door mirrors
- Self-diagnosis

In the convenience system, the CAN data bus currently connects the control units of the convenience system. These are a central electronic unit (09) and two or four door Central door Lock (35) control units.

The lines of the control units converge at one point in a star pattern. The advantage: if one of the control units fails, the other control units are still able to send their data protocols. Each control unit tries to send its data at intervals of 20 milliseconds.

The following list describes how the information in the convenience system is prioritized:

1. Central control unit
2. Control unit on driver's side
3. Control unit on front passenger's side
4. Control unit on rear left
5. Control unit on rear right



Since the data in the comfort system can be transferred at a relatively low speed, it is possible to use a transceiver with a lower power output. The advantage is that it is possible to change over to single-wire mode if a data bus line fails. The data can still be transferred.

The following chapters provide definitions and operating ranges for the Volkswagen and Audi vehicle data stream parameters.

The ECM provides two basic kinds of parameters: digital (or discrete) and analog:

- **Digital (discrete) parameters** are those that can be in only one of two states, such as on or off, open or closed, high or low, rich or lean, and yes or no. Switches, relays, and solenoids are examples of devices that provide discrete parameters on the control module data list.
- **Analog parameters** are displayed as a measured value in the appropriate units. Voltage, pressure, temperature, time, and speed parameters are examples of analog values. The scan tool displays them as numbers that vary through a range of values in units, such as pounds per square inch (psi), kilopascal (kPa), degrees Celsius (°C), degrees Fahrenheit (°F), kilometers per hour (KPH), or miles per hour (MPH).

The scan tool displays some data parameters in numbers that range from 0 to 100, 0 to 255, or 0 to 1800. These ranges are used because it is the range that the control module transmits for a given parameter. However, many parameter readings never reach the highest possible number.

The maximum range of a parameter often varies by year, model, and engine. On these applications, the word “variable” appears in the range heading. However, typical sampled values observed under actual test conditions are in the parameter description when available.

Parameters may also be identified as input signals or output commands.

- **Input or feedback parameters** are signals from various sensors and switches to the control module. They may display as analog or discrete values, depending upon the input device.
- **Output parameters** are commands that the control module transmits to various actuators, such as solenoids and fuel injectors. They are displayed as discrete (ON/OFF) parameters, analog values or as a pulse-width modulated (PWM) signal.

In the following section, parameters are presented as they appear on the scan tool screen. Most parameter descriptions are in alphabetical order, but there are exceptions. Often, the same parameter goes by a similar, but different, name when used on more than one model, engine, or control system. In these instances, all of the applicable parameter names, as displayed on the scan tool, are listed in alphabetical order before the description.

To find the description of a parameter, locate it in the alphabetical index, then go to the indicated page. Parameters are listed in the index as they appear on the scan tool screen.

The data parameter descriptions in this manual were created from a combination of sources. For most parameters, some basic information was provided by the vehicle manufacturers, then expanded through research and field testing. Parameter definitions and ranges may expand as more test results become available. For some parameters, no information is currently available.

The scan tool may display names for some data parameters that differ from names displayed by a factory tool and other scan tools.

Always use a meter or lab scope, to further validate the displayed values. If data is corrupted on multiple parameters, do not assume that the control module may be faulty. This corrupt data may be caused by improper communication between the scan tool and the control module controller.

## 6.1 Alphabetical Parameter List

### A

|   |     |
|---|-----|
| A/C COMP SW OFF BY ENG-ECU .....                            | 104 |
| A/C COMPRESSOR .....  | 104 |
| A/C COMPRESSOR OFF .....                                    | 104 |
| A/C COMPRESSOR ON .....                                     | 104 |
| A/C KICKDOWN .....  | 139 |
| A/C MODE .....  | 104 |
| A/C READINESS .....   | 104 |
| A/C SWITCH .....  | 104 |
| A/T .....   | 139 |
| A/T INPUT(RPM) .....  | 139 |
| A/T INPUT(RPM) .....  | 140 |
| A/T INPUT(RPM) .....  | 140 |
| A/T OUTPUT(RPM) .....                                       | 140 |
| A/T SWITCH .....  | 140 |
| A/T(RPM) .....  | 139 |
| ACCEL.PEDAL POSITION SNS 1(%) .....                         | 104 |
| ACCEL.PEDAL POSITION SNS 2(%) .....                         | 104 |
| ACCELERATION ENRICHMENT .....                               | 104 |
| ACCELERATOR PEDAL POSITION(%) .....                         | 135 |
| Accelerator Pedal Value .....                               | 147 |
| ACTUAL ADAPTATION POSITION(V) .....                         | 104 |
| Actual Engine Torque .....                                  | 147 |
| ACTUAL SELECTED GEAR .....                                  | 139 |
| ACTUAL SOLENOID(A) .....                                    | 139 |
| ADAPTATION ABORTED(BATTERY <8V) .....                       | 104 |
| ADAPTATION ERROR .....                                      | 104 |
| Adaptation of start-from-stop behavior forward .....        | 147 |
| Adaptation of start-from-stop characteristics Reverse ..... | 147 |
| ADAPTATION REQUIRED .....                                   | 104 |
| ADAPTATION RUNNING .....                                    | 104 |
| ADAPTATION STATUS .....                                     | 105 |
| ADP ENG SPEED SENSOR(CROWN GEAR) .....                      | 105 |
| ADP IDLING STABILIZATION(kg/h) .....                        | 105 |
| ADP STOPPED(TIME EXCEEDED) .....                            | 105 |
| ADP THROTTLE VALVE ADJUSTER .....                           | 105 |
| ADP VALUE AIR MASS IDLE(%) .....                            | 105 |
| ADP VALUE CANP SYSTEM .....                                 | 105 |
| ADP VALUE CANP VALVE .....                                  | 105 |
| ADP VALUE CANP VALVE 1(%) .....                             | 105 |
| ADP VALUE ISC .....   | 105 |
| ADP VALUE MIXTURE(BANK1) .....                              | 106 |
| ADP VALUE MIXTURE(BANK1)(%) .....                           | 105 |
| ADP VALUE MIXTURE(BANK2) .....                              | 106 |
| ADP VALUE MIXTURE(BANK2)(%) .....                           | 105 |
| AIR DIVERT VALVE .....                                      | 106 |
| AIR MASS IDLE(g/s) .....                                    | 106 |
| ALTERNATOR DEFECT .....                                     | 106 |
| ALTERNATOR LOAD(%) .....                                    | 106 |
| ALTITUDE CORRECTION FACTOR .....                            | 106 |

|                                     |     |
|-------------------------------------|-----|
| ALTITUDE CORRECTION FACTOR(%) ..... | 106 |
| AMBIENT TEMPERATURE(°C/°F) .....    | 106 |
| ATF TEMPERATURE(°C) .....           | 140 |
| AUX HEATING REQUESTED .....         | 106 |

**B**

|                                     |     |
|-------------------------------------|-----|
| BAROMETRIC PRESSURE(mbar) .....     | 106 |
| BASE THR POS(IDLE SW CLSD)(°) ..... | 107 |
| BASE VALUE THROTTLE ADJUSTER .....  | 107 |
| BASE VALUE TPS .....                | 107 |
| BASE VALUE TPS(V) .....             | 107 |
| BATTERY VOLTAGE .....               | 140 |
| BATTERY VOLTAGE BELOW 9V .....      | 135 |
| BATTERY VOLTAGE TOO LOW .....       | 107 |
| BATTERY(V) .....                    | 107 |
| BOOST PRESSURE(ACTUAL)(mbar) .....  | 107 |
| BOOST PRESSURE(ACTUAL)(mbar) .....  | 135 |
| BOOST PRESSURE(DESIRED)(mbar) ..... | 107 |
| BOOST PRESSURE(DESIRED)(mbar) ..... | 135 |
| BOOST PRESSURE(mbar) .....          | 107 |
| BRAKE LIGHT SWITCH .....            | 140 |
| BRAKE PEDAL PRESSED .....           | 107 |
| BRAKE PEDAL SWITCH .....            | 107 |

**C**

|                                       |     |
|---------------------------------------|-----|
| CAM ADJUSTER MODE .....               | 107 |
| CAMSHAFT ADJUSTER .....               | 108 |
| CAMSHAFT ADJUSTER(ACTIVE)(°) .....    | 108 |
| CAMSHAFT ADVANCE(°) .....             | 108 |
| CAMSHAFT PHASING .....                | 108 |
| CAMSHAFT POSITION(BANK 1)(°) .....    | 108 |
| CAMSHAFT POSITION(BANK 2)(°) .....    | 108 |
| CANISTER PURGE MODE .....             | 108 |
| CANP CHARGE(%) .....                  | 108 |
| CANP FLUSH .....                      | 108 |
| CANP SYSTEM ACTIVE .....              | 108 |
| CANP VALVE CLOSED .....               | 108 |
| CANP VALVE ON CHARGE .....            | 108 |
| CANP VALVE ON MIN MODE .....          | 108 |
| CANP VALVE ON NORMAL MODE .....       | 108 |
| CAT TEMPERATURE>300°C .....           | 108 |
| CATALYST EFFICIENCY(%) .....          | 109 |
| CATALYST TEMPERATURE(°C/F) .....      | 108 |
| CHANGE OVER TO CHARGE MODE CANP ..... | 109 |
| CHANGE OVER TO CLOSE MODE CANP .....  | 109 |
| CHANGE OVER TO MIN MODE CANP .....    | 109 |
| CLUTCH PEDAL PRESSED .....            | 109 |
| CLUTCH PEDAL SWITCH .....             | 109 |
| CODING FOR SYNCRO(4WD) .....          | 109 |
| COMBINED HALL & ENG SPEED SIGN .....  | 109 |
| CONTROL VALUE MIXTURE(%) .....        | 109 |
| COOLANT TEMPERATURE >80°C .....       | 109 |

|                                    |     |
|------------------------------------|-----|
| COOLANT TEMPERATURE(°)             | 135 |
| COOLANT TMP >70°C/OR AIR TEMP >5°C | 135 |
| COOLANT/AIRTMP SNS DEFECT          | 135 |
| CRUISE CTRL ENABLED                | 109 |
| CRUISE CTRL STATUS                 | 109 |
| CTRL VALUE IDLE AIR MASS(g/s)      | 109 |
| CTRL VALUE MIXTURE(BANK 1)(%)      | 109 |
| CTRL VALUE MIXTURE(BANK 2)(%)      | 109 |
| CTRL VALUE MIXTURE/O2              | 110 |
| CTRL VALUE MIXTURE/O2(%)           | 110 |
| CURRENT CONSUMPTION IAC(A)         | 110 |
| CURRENT CTRL FACTOR IAC            | 110 |
| CURRENT CTRL IAC(%)                | 110 |
| CYLINDER 1 RECOGNIZED              | 110 |

**D**

|                                  |     |
|----------------------------------|-----|
| DC(DUTY CYCLE)START OF DELIVERY  | 138 |
| DECEL ENLEAN                     | 110 |
| DECELERATE POSITION              | 110 |
| DECELERATION ENLEANMENT          | 110 |
| DIAGNOSE LEARN VALUE O2(BK1)IDLE | 110 |
| DIAGNOSE LEARN VALUE O2(BK1)P/T2 | 110 |
| DIAGNOSE LEARN VALUE O2(BK1)P/T3 | 110 |
| DIAGNOSE LEARN VALUE O2(BK1)P/T4 | 110 |
| DIAGNOSE LEARN VALUE O2(BK2)IDLE | 110 |
| DIAGNOSE LEARN VALUE O2(BK2)P/T2 | 110 |
| DIAGNOSE LEARN VALUE O2(BK2)P/T3 | 110 |
| DIAGNOSE LEARN VALUE O2(BK2)P/T4 | 110 |
| DRIVING SLIP CTRL                | 147 |
| DUTY CYCLE CANP VALVE            | 111 |
| DUTY CYCLE CANP VALVE(%)         | 111 |
| DUTY CYCLE EGR-VALVE(%)          | 111 |
| DUTY CYCLE FAN CTRL VALVE(%)     | 111 |
| DUTY CYCLE IAC(%)                | 111 |
| DUTY CYCLE ISC(%)                | 111 |
| DUTY CYCLE THR ADJUSTER(%)       | 111 |
| DUTY CYCLE WASTE GATE VALVE(%)   | 111 |

**E**

|                              |     |
|------------------------------|-----|
| EDS CUT OFF                  | 149 |
| EGR-SYSTEM                   | 111 |
| EGR-TEMPERATURE(°C/°F)       | 111 |
| ENGINE CRANKED IN LAST 10S   | 135 |
| ENGINE LOAD AFTER REDUC(ms)  | 112 |
| ENGINE LOAD(%)               | 111 |
| ENGINE LOAD(ACTUAL)(%)       | 111 |
| ENGINE LOAD(ACTUAL)(ms)      | 112 |
| ENGINE LOAD(ACTUAL)(Nm)      | 112 |
| ENGINE LOAD(AFTER CORR)(ms)  | 112 |
| ENGINE LOAD(BEFORE CORR)(ms) | 112 |
| ENGINE LOAD(ms)              | 111 |
| ENGINE LOAD(V)               | 111 |

|                                      |     |
|--------------------------------------|-----|
| ENGINE SPEED <2000 RPM .....         | 112 |
| ENGINE SPEED <2300 RPM .....         | 112 |
| ENGINE SPEED <2500 RPM .....         | 112 |
| ENGINE SPEED <760 RPM .....          | 112 |
| ENGINE SPEED >1800 RPM .....         | 112 |
| ENGINE SPEED >2500 RPM .....         | 112 |
| ENGINE SPEED SIGNAL RECOGNIZED ..... | 112 |
| ENGINE SPEED(ACTUAL)(RPM) .....      | 112 |
| ENGINE SPEED(DESIRED)(RPM) .....     | 112 |
| ENGINE SPEED(IDLE)(RPM) .....        | 112 |
| ENGINE SPEED(RPM) .....              | 112 |
| ENGINE SPEED(RPM) .....              | 135 |
| ENGINE TORQUE MAX .....              | 141 |
| ENGINE TORQUE(Nm) .....              | 140 |
| EXHAUST GAS TEMPERATURE(°C/°F) ..... | 113 |

**F**

|                                  |     |
|----------------------------------|-----|
| FUEL CONS. AUX HEATER(l/h) ..... | 135 |
| FUEL CONSUMPTION ISC(g/s) .....  | 135 |
| FUEL CONSUMPTION SIGNAL .....    | 148 |
| FUEL CONSUMPTION(l/h) .....      | 135 |
| FUEL COOLING(%) .....            | 113 |
| FUEL CUT OFF .....               | 113 |
| FUEL CUT-OFF VALVE ACTIVE .....  | 113 |
| FUEL HEAT(l/h) .....             | 113 |
| FUEL LOW .....                   | 113 |
| FUEL TEMPERATURE(°) .....        | 136 |
| FULL LOAD .....                  | 113 |
| FULL LOAD DETECTED .....         | 113 |
| FULL LOAD SWITCH .....           | 113 |

**G**

|                     |     |
|---------------------|-----|
| GEAR POSITION ..... | 141 |
| GEAR SELECTED ..... | 148 |
| GLOW TIME(s) .....  | 136 |
| GLOW(s) .....       | 136 |

**H**

|                      |     |
|----------------------|-----|
| HALL-SENSOR(°) ..... | 113 |
| HANDBRAKE .....      | 149 |
| HILL FACTOR(%) ..... | 141 |

**I**

|                                |     |
|--------------------------------|-----|
| IAC INTEGRATOR .....           | 113 |
| IDLE AIR CORRECTION(g/s) ..... | 113 |
| IDLE AIR CTRL(%) .....         | 113 |
| IDLE AIR MASS(g/s) .....       | 113 |
| IDLE SPEED CTRL VALVE .....    | 114 |
| IDLE SPEED CTRL VALVE(%) ..... | 114 |
| IDLE SPEED SWITCH .....        | 114 |
| IDLE SPEED SWITCH CLOSED ..... | 114 |

|  |     |
|--|-----|
| IDLE SPEED SWITCH OPEN .....           | 114 |
| IDLE SPEED(ACTUAL)(RPM) .....          | 113 |
| IDLE SPEED(DESIRED)(RPM) .....         | 113 |
| IGN ADV W KNOCK & ISC(AV)(°) .....     | 114 |
| IGN RTD BY A/T-ECU(°) .....            | 114 |
| IGN RTD BY DIGITAL ISC(°) .....        | 114 |
| IGN RTD BY KNOCK CTRL(°) .....         | 114 |
| IGN RTD BY KNOCK CTRL(CYL 1)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 2)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 3)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 4)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 5)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 6)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 7)(°) .....  | 114 |
| IGN RTD BY KNOCK CTRL(CYL 8)(°) .....  | 114 |
| IGN RTD BY KNOCK(°) .....              | 114 |
| IGN RTD BY KNOCK(ALL CYL)(°) .....     | 114 |
| IGN RTD BY TCS-ECU(COLD)(°) .....      | 114 |
| IGN RTD W/O KNOCK & W/O ISC(°) .....   | 114 |
| IGN RTD WITH KNOCK & ISC(°) .....      | 114 |
| IGNITION ADV REDUCTION .....           | 115 |
| IGNITION ADV(CALCULATED)(°) .....      | 115 |
| IGNITION ADVANCE(°) .....              | 115 |
| IGNITION MAP .....                     | 115 |
| INCREASED IDLE SPEED WITH A/C ON ..... | 115 |
| INCREASING RPM .....                   | 115 |
| INJ DIFF CYL 1 TO 3(mg/S) .....        | 136 |
| INJ DIFF CYL 1 TO 4(mg/S) .....        | 136 |
| INJ DIFF CYL 1 TO 5(mg/S) .....        | 136 |
| INJ DIFF CYL 1 TO AVERAGE(mg/S) .....  | 136 |
| INJ DIFF CYL 2 TO 3(mg/S) .....        | 136 |
| INJ DIFF CYL 2 TO 4(mg/S) .....        | 136 |
| INJ DIFF CYL 2 TO 5(mg/S) .....        | 136 |
| INJ DIFF CYL 2 TO AVERAGE(mg/S) .....  | 136 |
| INJ DIFF CYL 3 TO 4(mg/S) .....        | 136 |
| INJ DIFF CYL 3 TO 5(mg/S) .....        | 136 |
| INJ DIFF CYL 3 TO AVERAGE(mg/S) .....  | 136 |
| INJ DIFF CYL 4 TO 3(mg/S) .....        | 136 |
| INJ DIFF CYL 4 TO 5(mg/S) .....        | 136 |
| INJ DIFF CYL 4 TO AVERAGE(mg/S) .....  | 136 |
| INJ DIFF CYL 5 TO 3(mg/S) .....        | 136 |
| INJ DIFF CYL 5 TO 4(mg/S) .....        | 136 |
| INJ DIFF CYL 6 TO 3(mg/S) .....        | 136 |
| INJ QUANTITY(CRUISE)(mg/S) .....       | 136 |
| INJ QUANTITY(DESIRED)(mg/S) .....      | 136 |
| INJ QUANTITY(DRIVER)(mg/S) .....       | 136 |
| INJ QUANTITY(mg/S) .....               | 136 |
| INJ QUANTITY(mm3) .....                | 115 |
| INJ QUANTITY(SMOKE)(mg/S) .....        | 136 |
| INJ QUANTITY(TCS)(mg/S) .....          | 137 |
| INJ QUANTITY(TORQUE A/T)(mg/S) .....   | 137 |
| INJ QUANTITY(TORQUE)(mg/S) .....       | 136 |
| INJECTION TIME(AVERAGE)(ms) .....      | 115 |

|                                      |     |
|--------------------------------------|-----|
| INJECTION TIME(ms) .....             | 115 |
| INTAKE AIR TEMPERATURE(°) .....      | 135 |
| INTAKE MANIFOLD PRESSURE(%) .....    | 115 |
| INTAKE MANIFOLD PRESSURE(mbar) ..... | 115 |
| ISC INTGRATOR .....                  | 115 |
| ISC UNDER LOAD .....                 | 116 |
| ISC(CTRL FACTOR) .....               | 115 |
| ISC(POSITION) .....                  | 115 |
| ISC(REACTION TO MALFUNCTION) .....   | 115 |

**K**

|                              |     |
|------------------------------|-----|
| KICKDOWN SWITCH .....        | 141 |
| KICKDOWN SWITCH .....        | 141 |
| KNOCK CTRL(°) .....          | 116 |
| KNOCK SENSOR(CYL 1)(V) ..... | 116 |
| KNOCK SENSOR(CYL 2)(V) ..... | 116 |
| KNOCK SENSOR(CYL 3)(V) ..... | 116 |
| KNOCK SENSOR(CYL 4)(V) ..... | 116 |
| KNOCK SENSOR(CYL 5)(V) ..... | 116 |
| KNOCK SENSOR(CYL 6)(V) ..... | 116 |
| KNOCK SENSOR(CYL 7)(V) ..... | 116 |
| KNOCK SENSOR(CYL 8)(V) ..... | 116 |

**L**

|                                     |     |
|-------------------------------------|-----|
| LACK OF FUEL .....                  | 116 |
| LEARN AIR MASS IDLE(D)(g/s) .....   | 116 |
| LEARN AIR MASS IDLE(g/s) .....      | 116 |
| LEARN AIR MASS IDLE(P/N)(g/s) ..... | 116 |
| LEARN INJECTION TIME(ms) .....      | 116 |
| LEARN MIXT(BANK 1)(IDLE)(%) .....   | 117 |
| LEARN MIXT(BANK 1)(IDLE)(%) .....   | 117 |
| LEARN MIXT(BANK 1)(P/T)(%) .....    | 117 |
| LEARN MIXT(BANK 1)(P/T)(%) .....    | 117 |
| LEARN MIXT(BANK 1)(P/T1)(%) .....   | 117 |
| LEARN MIXT(BANK 1)(P/T2)(%) .....   | 117 |
| LEARN MIXT(BANK 1)(P/T3)(%) .....   | 117 |
| LEARN MIXT(BANK 2)(IDLE)(%) .....   | 117 |
| LEARN MIXT(BANK 2)(IDLE)(%) .....   | 117 |
| LEARN MIXT(BANK 2)(P/T)(%) .....    | 117 |
| LEARN MIXT(BANK 2)(P/T)(%) .....    | 117 |
| LEARN MIXT(BANK 2)(P/T1)(%) .....   | 117 |
| LEARN MIXT(BANK 2)(P/T2)(%) .....   | 117 |
| LEARN MIXT(BANK 2)(P/T3)(%) .....   | 117 |
| LEARN RANGE O2 IDLE .....           | 117 |
| LEARN RANGE O2 P/T 2 .....          | 117 |
| LEARN RANGE O2 P/T 3 .....          | 117 |
| LEARN RANGE O2(BK1)IDLE .....       | 117 |
| LEARN RANGE O2(BK1)P/T2 .....       | 117 |
| LEARN RANGE O2(BK1)P/T3 .....       | 117 |
| LEARN RANGE O2(BK1)P/T4 .....       | 117 |
| LEARN RANGE O2(BK2)IDLE .....       | 117 |
| LEARN RANGE O2(BK2)P/T2 .....       | 117 |



|  |     |
|--|-----|
| LEARN RANGE O2(BK2)P/T3 .....          | 117 |
| LEARN RANGE O2(BK2)P/T4 .....          | 117 |
| LEARN VALUE AIR MASS IDLE(%) .....     | 117 |
| LEARN VALUE AIR MASS IDLE(g/s) .....   | 117 |
| LEARN VALUE CANP SYSTEM .....          | 118 |
| LEARN VALUE DC ISC .....               | 118 |
| LEARN VALUE DC ISC(%) .....            | 118 |
| LEARN VALUE DC ISC(A/T) .....          | 118 |
| LEARN VALUE DC ISC(MUL)(%) .....       | 118 |
| LEARN VALUE IAC .....                  | 118 |
| LEARN VALUE IDLE SPEED(NOT P/N) .....  | 118 |
| LEARN VALUE IDLE SPEED(P/N) .....      | 118 |
| LEARN VALUE ISC .....                  | 118 |
| LEARN VALUE ISC(AT IN D) .....         | 118 |
| LEARN VALUE ISC(MT/AT IN P/N) .....    | 118 |
| LEARN VALUE KICKDOWN(%) .....          | 118 |
| LEARN VALUE MAF-SENSOR .....           | 118 |
| LEARN VALUE MIXTURE .....              | 118 |
| LEARN VALUE MIXTURE CORR .....         | 120 |
| LEARN VALUE MIXTURE CORR(%) .....      | 120 |
| LEARN VALUE MIXTURE CORR(ms) .....     | 120 |
| LEARN VALUE MIXTURE(%) .....           | 119 |
| LEARN VALUE MIXTURE(ADAPTIVE) .....    | 119 |
| LEARN VALUE MIXTURE(ADP)(ms) .....     | 119 |
| LEARN VALUE MIXTURE(BANK 1) .....      | 119 |
| LEARN VALUE MIXTURE(BANK 1)(%) .....   | 119 |
| LEARN VALUE MIXTURE(BANK 2) .....      | 119 |
| LEARN VALUE MIXTURE(BANK 2)(%) .....   | 119 |
| LEARN VALUE MIXTURE(CANP ACT)(%) ..... | 119 |
| LEARN VALUE MIXTURE(IDLE)(%) .....     | 120 |
| LEARN VALUE MIXTURE(P/T1)(%) .....     | 120 |
| LEARN VALUE MIXTURE(P/T2)(%) .....     | 120 |
| LEARN VALUE MIXTURE(P/T3)(%) .....     | 120 |
| LEARN VALUE O2 .....                   | 120 |
| LEARN VALUE O2 IDLE OK .....           | 123 |
| LEARN VALUE O2 P/T 1 OK .....          | 123 |
| LEARN VALUE O2 P/T 2 OK .....          | 123 |
| LEARN VALUE O2 P/T 3 OK .....          | 123 |
| LEARN VALUE O2 SNS 1(IDLE)(%) .....    | 123 |
| LEARN VALUE O2 SNS 1(P/T)(%) .....     | 123 |
| LEARN VALUE O2(%) .....                | 121 |
| LEARN VALUE O2(ACTUAL)(BK1)(%) .....   | 121 |
| LEARN VALUE O2(ACTUAL)(BK2)(%) .....   | 121 |
| LEARN VALUE O2(BK1) .....              | 121 |
| LEARN VALUE O2(BK1)(%) .....           | 121 |
| LEARN VALUE O2(BK1)(ADD)(%) .....      | 121 |
| LEARN VALUE O2(BK1)(IDLE)(%) .....     | 121 |
| LEARN VALUE O2(BK1)(MUL)(%) .....      | 121 |
| LEARN VALUE O2(BK1)(P/T)(%) .....      | 121 |
| LEARN VALUE O2(BK1)IDLE OK .....       | 122 |
| LEARN VALUE O2(BK1)P/T1 OK .....       | 122 |
| LEARN VALUE O2(BK1)P/T2 OK .....       | 122 |
| LEARN VALUE O2(BK1)P/T3 OK .....       | 122 |

|                                      |     |
|--------------------------------------|-----|
| LEARN VALUE O2(BK2) .....            | 121 |
| LEARN VALUE O2(BK2)(%) .....         | 121 |
| LEARN VALUE O2(BK2)(ADD)(%) .....    | 121 |
| LEARN VALUE O2(BK2)(IDLE)(%) .....   | 121 |
| LEARN VALUE O2(BK2)(MUL)(%) .....    | 121 |
| LEARN VALUE O2(BK2)(P/T)(%) .....    | 121 |
| LEARN VALUE O2(BK2)IDLE OK .....     | 122 |
| LEARN VALUE O2(BK2)P/T1 OK .....     | 122 |
| LEARN VALUE O2(BK2)P/T2 OK .....     | 122 |
| LEARN VALUE O2(BK2)P/T3 OK .....     | 122 |
| LEARN VALUE O2(FULL) .....           | 122 |
| LEARN VALUE O2(IDLE) .....           | 122 |
| LEARN VALUE O2(IDLE)(%) .....        | 122 |
| LEARN VALUE O2(IDLE)(ms) .....       | 122 |
| LEARN VALUE O2(P/T) .....            | 122 |
| LEARN VALUE O2(P/T)(%) .....         | 122 |
| LEARN VALUE O2(P/T)(MUL)(%) .....    | 122 |
| LEARN VALUE O2(P/T-WOT) .....        | 122 |
| LEARN VALUE THR VALVE ADJUSTER ..... | 123 |
| LEARN VALUE TPS .....                | 123 |
| LEARN VALUE TPS(V) .....             | 123 |
| LIMITED DYNAMIC ACTIVE .....         | 123 |
| LIMITED OPERATION(LIMP) .....        | 123 |
| LOCK-UP SLIP .....                   | 141 |
| LOCK-UP SLIP .....                   | 141 |
| LOCK-UP SLIP .....                   | 141 |
| LOS MODE .....                       | 123 |
| LRN IDLING STABILIZATION(kg/h) ..... | 123 |
| LRN VALUE ISC(g/s) .....             | 118 |

## M

|                                    |     |
|------------------------------------|-----|
| MAF 1(mg/S) .....                  | 137 |
| MAF 2(mg/S) .....                  | 137 |
| MAF DES(mg/S) .....                | 137 |
| MAF IDLE(g/s) .....                | 123 |
| MAF ISC TRIM(%) .....              | 123 |
| MAF TRIM(g/s) .....                | 124 |
| MAF-SENSOR(V) .....                | 124 |
| MAP(%) .....                       | 124 |
| MAP(mbar) .....                    | 124 |
| MAP(V) .....                       | 124 |
| MAP-CONTROLLED IDLE SPEED .....    | 124 |
| MASS AIR FLOW(ACTUAL)(g/s) .....   | 124 |
| MASS AIR FLOW(ACTUAL)(mg/S) .....  | 137 |
| MASS AIR FLOW(DESIRED)(g/s) .....  | 124 |
| MASS AIR FLOW(DESIRED)(ms/S) ..... | 137 |
| MASS AIR FLOW(g/s) .....           | 124 |
| MASS AIR FLOW(mg/S) .....          | 137 |
| MASS AIR FLOW(V) .....             | 124 |
| MAX VALUE THR ADJUSTER(%) .....    | 124 |
| MAX VALUE THR ADJUSTER(V) .....    | 124 |
| MIN VALUE THR ADJUSTER(%) .....    | 124 |
| MIN VALUE THR ADJUSTER(V) .....    | 125 |

MISFIRES PER 200 REVS(ALL CYL) .....125  
 MISFIRES PER 200 REVS(CYL.1) .....125  
 MISFIRES PER 200 REVS(CYL.2) .....125  
 MISFIRES PER 200 REVS(CYL.3) .....125  
 MISFIRES PER 200 REVS(CYL.4) .....125  
 MISFIRES PER 200 REVS(CYL.5) .....125  
 MISFIRES PER 200 REVS(CYL.6) .....125  
 MISFIRES PER 200 REVS(CYL.7) .....125  
 MISFIRES PER 200 REVS(CYL.8) .....125  
 MIXTURE .....125  
 MIXTURE CORR(CANP ACTIVE) .....125  
 MIXTURE CORRECTION .....125  
 MIXTURE CORRECTION(%) .....125  
 MODE HALL-REFERENCE SIGNAL .....125

O

O2 ACTIVE .....125  
 O2 ADP & ACTUAL VALUE(%) .....126  
 O2 CONTROL MODE .....126  
 O2 CORR(CANP ACTIVATED) .....126  
 O2 CORR(CANP ACTIVATED)(%) .....126  
 O2 CTRL & ACT(BANK 1)(%) .....126  
 O2 CTRL & ACT(BANK 2)(%) .....126  
 O2 CTRL FACTOR(BANK 1) .....126  
 O2 CTRL FACTOR(BANK 2) .....126  
 O2 CTRL FACTOR(CYL 1-3)(%) .....127  
 O2 CTRL FACTOR(CYL 4-6)(%) .....127  
 O2 CTRL READY .....127  
 O2 CTRL(BANK 1)(%) .....126  
 O2 CTRL(BANK 2)(%) .....126  
 O2 INTEGRATOR .....127  
 O2 LOOP CLOSED .....127  
 O2 REGULATION .....127  
 O2 REGULATION ACTIVE .....128  
 O2 REGULATION ON STOP .....128  
 O2 REGULATION(%) .....128  
 O2 REGULATION(BANK 1)(%) .....128  
 O2 REGULATION(BANK 2)(%) .....128  
 O2 SENSOR 1(V) .....128  
 O2 SENSOR 2(V) .....128  
 O2 SENSOR HEATER .....129  
 O2 SENSOR HEATER AFTER CAT .....129  
 O2 SENSOR HEATER BEFORE CAT .....129  
 O2 SENSOR HEATER(BK1-SNS1) .....129  
 O2 SENSOR HEATER(BK1-SNS2) .....129  
 O2 SENSOR HEATER(BK2-SNS1) .....129  
 O2 SENSOR HEATER(BK2-SNS2) .....129  
 O2 SENSOR READY .....129  
 O2 SENSOR(BANK 1)(V) .....128  
 O2 SENSOR(BANK 1)(V) .....128  
 O2 SENSOR(BANK 2)(V) .....128  
 O2 SENSOR(BANK 2)(V) .....128  
 O2 SENSOR(V) .....128

|                                     |     |
|-------------------------------------|-----|
| O2 VALUE .....                      | 129 |
| O2 VALUE(ACTUAL)(%) .....           | 129 |
| O2 VALUE(BANK 1)(%) .....           | 129 |
| O2 VALUE(BANK 2)(%) .....           | 129 |
| OIL TEMPERATURE(°C/°F) .....        | 130 |
| On-Board Diagnostic .....           | 148 |
| OPERATING MODE .....                | 130 |
| OVERRUN .....                       | 130 |
| Overrun/engine pulling signal ..... | 148 |

**P**

|                                  |     |
|----------------------------------|-----|
| PARK/NEUTRAL POSITION .....      | 130 |
| PARK/NEUTRAL POSITION .....      | 130 |
| PART LOAD DETECTED .....         | 130 |
| PHASE POSITION BK1(°CA) .....    | 130 |
| PHASE POSITION BK2(°CA) .....    | 130 |
| PHASE POSITION HALL SNS(°) ..... | 130 |
| POWER SUPPLY ECU(V) .....        | 149 |
| PRESS CNTRL(%) .....             | 130 |
| PRESSURE CTRL(A) .....           | 142 |

**R**

|                                    |     |
|------------------------------------|-----|
| REAR HEATER MODE .....             | 130 |
| REAR HEATER SWITCH .....           | 130 |
| REDUCTION TORQUE(ACTUAL)(Nm) ..... | 130 |
| REL.HEAT HIGH .....                | 137 |
| REL.HEAT LOW .....                 | 137 |
| RELATIVE AIR MASS(%) .....         | 130 |
| RELAY HEATER HIGH .....            | 137 |
| RELAY HEATER LOW .....             | 137 |
| REQUIRED SOLENOID #4 .....         | 142 |
| REQUIRED SOLENOID #5 .....         | 142 |
| REQUIRED SOLENOID #6 .....         | 142 |
| REQUIRED SOLENOID #7 .....         | 142 |
| REQUIRED SOLENOID(A) .....         | 142 |
| RETARDED IGNITION POINT .....      | 130 |
| RETARDED IGNITION POINT(°) .....   | 130 |
| RETARDING STEPS .....              | 130 |
| ROTATIONAL SPEED(°/s) .....        | 149 |
| RTD SIGNAL A/T ACTIVE .....        | 131 |

**S**

|                                  |     |
|----------------------------------|-----|
| SECONDARY AIR MASS(g/s) .....    | 131 |
| SELECTOR OUTPUTS .....           | 148 |
| SHIFT LEVER LOCK .....           | 142 |
| SIGNAL FROM A/T .....            | 131 |
| SLIDE VALVE SENSOR(MAX)(V) ..... | 131 |
| SLIDE VALVE SENSOR(MIN)(V) ..... | 131 |
| SLIDE VALVE SENSOR(V) .....      | 137 |
| SOLENOID #1 .....                | 142 |
| SOLENOID #2 .....                | 142 |
| SOLENOID #3 .....                | 142 |

|                                     |     |
|-------------------------------------|-----|
| SOLENOID #4 .....                   | 142 |
| SOLENOID #5 .....                   | 142 |
| SOLENOID #7 .....                   | 142 |
| SPORT FACTOR(%) .....               | 144 |
| START OF DELIVERY(°) .....          | 131 |
| START OF DELIVERY(ACTUAL) .....     | 138 |
| START OF DELIVERY(ACTUAL)(°) .....  | 131 |
| START OF DELIVERY(DESIRED) .....    | 138 |
| START OF DELIVERY(DESIRED)(°) ..... | 131 |
| START QUANTITY(mg/S) .....          | 138 |
| START SYNCHRONIZATION(°) .....      | 131 |
| STATUS FUEL COOLING(%) .....        | 131 |
| STEERING ANGLE(°) .....             | 149 |
| SUM MISFIRES .....                  | 131 |

## T

|   |     |
|---|-----|
| TCS STATUS .....                            | 144 |
| TCS SWITCH .....                            | 149 |
| TEETH COUNT TILL HALL-SIG SHIFT +TO - ..... | 131 |
| THR ADJ SENSOR, MAX LRN OK/EXEC .....       | 131 |
| THR ADJ SENSOR, MIN LRN OK/EXEC .....       | 131 |
| THR ADJ/TPS BALANCE OK/EXEC .....           | 132 |
| THR ADJUSTER(LIMP)(%) .....                 | 132 |
| THR POS SENSOR(AV)(LIMP)(V) .....           | 132 |
| THR POS SENSOR(THR STOP)(V) .....           | 132 |
| THR VALVE ADJUSTER ANGLE(V) .....           | 132 |
| THR VALVE ANGLE(ABSOLUTE)(°) .....          | 132 |
| THR VALVE ANGLE(LEARN)(°) .....             | 132 |
| THROTTLE ADJUSTER MODE .....                | 132 |
| THROTTLE POSITION SENSOR(V) .....           | 132 |
| THROTTLE POSITION(IDLE)(V) .....            | 132 |
| THROTTLE VALVE ADJUSTER ANGLE(°) .....      | 132 |
| THROTTLE VALVE ADJUSTER MAX(%) .....        | 132 |
| THROTTLE VALVE ADJUSTER MAX(V) .....        | 132 |
| THROTTLE VALVE ADJUSTER MIN(%) .....        | 132 |
| THROTTLE VALVE ADJUSTER MIN(V) .....        | 132 |
| THROTTLE VALVE ADJUSTER(V) .....            | 132 |
| THROTTLE VALVE ANGLE(°) .....               | 132 |
| THROTTLE VALVE CLOSED .....                 | 132 |
| THROTTLE VALVE POSITION 1(%) .....          | 133 |
| THROTTLE VALVE POSITION 1(°) .....          | 133 |
| THROTTLE VALVE POSITION 2(%) .....          | 133 |
| THROTTLE VALVE POSITION 2(°) .....          | 133 |
| THROTTLE VALVE POSITION(%) .....            | 132 |
| THROTTLE VALVE POSITION(V) .....            | 144 |
| TIME COUNTER 1 .....                        | 133 |
| TIME COUNTER 2 .....                        | 133 |
| TIME COUNTER(O2) .....                      | 133 |
| TIPTRONIC .....                             | 145 |
| TORQUE (ACTUAL)(Nm) .....                   | 133 |
| Torque converter slip speed .....           | 148 |
| TORQUE FROM A/T(Nm) .....                   | 133 |
| TORQUE FROM ENGINE(Nm) .....                | 133 |

|                                       |     |
|---------------------------------------|-----|
| TORQUE LOSS(Nm) .....                 | 149 |
| TORQUE MAX(Nm) .....                  | 145 |
| TORQUE RAISE .....                    | 145 |
| TORQUE REDUC .....                    | 145 |
| TORQUE REDUCTION .....                | 133 |
| TORQUE REDUCTION(Nm) .....            | 133 |
| TORQUE(%) .....                       | 149 |
| TORQUE(DESIRED)(Nm) .....             | 133 |
| TORQUE(DESIRED, BY A/T-ECU)(Nm) ..... | 133 |
| TORQUE(Nm) .....                      | 145 |
| TPS FULL RANGE(V) .....               | 133 |
| TPS LOW RANGE(V) .....                | 133 |
| TPS, MAX LRN OK/EXEC .....            | 133 |
| TPS, MIN LRN OK/EXEC .....            | 133 |
| TRANSVERSE ACCELERATION(m/s2) .....   | 149 |
| TROUBLE CODE STORED IN MEMORY .....   | 134 |

**U**

|                                  |     |
|----------------------------------|-----|
| UNPLAUSIBLE SIGNAL THR ADJ ..... | 134 |
|----------------------------------|-----|

**V**

|                                    |     |
|------------------------------------|-----|
| VEHICLE SPEED .....                | 134 |
| VEHICLE SPEED .....                | 145 |
| VEHICLE SPEED CTRL .....           | 134 |
| VEHICLE SPEED SENSOR(V) .....      | 145 |
| VOLTAGE THR ADJ OUT OF RANGE ..... | 134 |

**W**

|   |     |
|---|-----|
| WARM UP CAT .....                       | 134 |
| WARM UP CAT(%) .....                    | 134 |
| WARN. SIGNAL INSTR. PANEL: REFUEL ..... | 134 |
| WHEEL LEFT FRONT .....                  | 149 |
| WHEEL LEFT FRONT(RPM) .....             | 146 |
| WHEEL LEFT REAR .....                   | 149 |
| WHEEL LEFT REAR(RPM) .....              | 146 |
| WHEEL RIGHT FRONT .....                 | 149 |
| WHEEL RIGHT FRONT(RPM) .....            | 146 |
| WHEEL RIGHT REAR .....                  | 149 |
| WHEEL RIGHT REAR(RPM) .....             | 146 |

## 6.2 Gas Engine Parameters

**A/C COMP SW OFF BY ENG-ECU** \_\_\_\_\_ (range: YES/NO)

Indicates an ECM-controlled switch which disables the operation of the A/C if a fault is detected by the ECM. If the ECM has switched the A/C off, the reading will be YES.

**A/C COMPRESSOR** \_\_\_\_\_ (range: ON/OFF)

Indicates a feedback signal from the A/C compressor clutch or relay. When the display reads ON, the clutch is engaged, when it reads OFF, the clutch is disengaged.

**A/C COMPRESSOR OFF)**  
**A/C COMPRESSOR ON** \_\_\_\_\_ (range: YES/NO)

Indicates whether the A/C compressor is running.

**A/C MODE** \_\_\_\_\_ (range: HIGH/LOW)

Indicates whether the A/C system is set in the HIGH or LOW mode.

**A/C READINESS** \_\_\_\_\_ (range: YES/NO)

Indicates if the A/C is ready to be used. If A/C is fitted and no defects are found in the system, the reading will be YES. If the vehicle does not have A/C fitted or a fault in the system or wiring is found, the reading will be NO.

**A/C SWITCH** \_\_\_\_\_ (range: ON/OFF)

Informs the ECM whether the A/C switch is set at ON/OFF or HIGH/LOW.

**ACCELERATION ENRICHMENT** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM provides a richer mixture during acceleration by momentarily increasing injector pulse width. It should read YES when the ECM is enriching the mixture during acceleration. Injector pulse width should also increase at the same time. It should read NO under all other conditions.

**ACCEL.PEDAL POSITION SNS 1(%)**  
**ACCEL.PEDAL POSITION SNS 2(%)** \_\_\_\_\_ (range: not available)

Indicates the position of the acceleration pedal in percentage. A V-type Engine uses 2 sensors, which are designated by the 1 and 2 in the parameter name.

**ACTUAL ADAPTATION POSITION(V)** \_\_\_\_\_ (range: not available)

Indicates the adaptive position of the EGR valve calculated by the ECM in voltage.

**ADAPTATION ABORTED(BATTERY <8V)** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has recognized a battery voltage less than 8V. If the reading is NO, then Adaptation (adaptive learn) can take place. If the reading is YES, then the ECM will not relearn any values.

**ADAPTATION ERROR** \_\_\_\_\_ (range: YES/NO)

Indicates whether an error in the throttle adjustment is detected. It reads YES if a fault is detected, check for trouble codes. It reads NO at all other times.

**ADAPTATION REQUIRED** \_\_\_\_\_ (range: YES/NO)

Indicates whether the Idle Stabilizing Control (ISC) system is being operated outside of the learned values. It reads YES only when an Adaptation is required to inform the ECM of the new ISC position.

**ADAPTATION RUNNING** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is updating the throttle position sensors idle and full open positions. It reads YES during adaptation, NO at all other times.

**ADAPTATION STATUS** \_\_\_\_\_ (range: RUNNING/OK/ERROR)

Indicates whether the ECM is learning a position for the throttle valve, for example: under normal conditions the reading should be OK.

RUNNING will be displayed for a short time as the ECM learns the new values while in Basic Setting mode. If ERROR is displayed, then a fault in the learning processes has occurred.

**ADP ENG SPEED SENSOR(CROWN GEAR)** \_\_\_\_\_ (range: I/O or RUNNING)

Indicates the operation of the crankshaft sensor and the segmented gear fitted to the crankshaft and adapts the ECM for ignition misfires. The crown gear is the segmented disk fitted on the crankshaft and the engine speed sensor (Hall-effect sensor) takes its signal from the teeth on this gear. If the display reads RUNNING, then the sender/gear check has not yet been completed and the misfire detection is restricted until the adaptation is completed. The sender/gear check can only be performed during overrun conditions.

**ADP IDLING STABILIZATION(kg/h)** \_\_\_\_\_ (range: not available)

Indicates the learning value of the idle control system. The reading is the volume of air the ECM is commanding in kilograms per hour.

**ADP STOPPED(TIME EXCEEDED)** \_\_\_\_\_ (range: YES/NO)

Indicates whether the adaptation process was stopped because the maximum time allowed was exceeded. The normal reading is NO, Yes indicates an adaptation problem.

**ADP THROTTLE VALVE ADJUSTER** \_\_\_\_\_ (range: not available)

Indicates the current throttle adjuster adaptation mode and can display ADP, (running) ADP OK, or ADP ERROR.

**ADP VALUE AIR MASS IDLE(%)** \_\_\_\_\_ (range: not available)

Indicates the amount of extra air mass required to keep the engine idle speed correct when a change in load occurs, such as when the A/C or the rear heater is switched on.

**ADP VALUE CANP SYSTEM** \_\_\_\_\_ (range: not available)

Indicates the learning value of the canister purge system. It displays the duty cycle the ECM is commanding.

**ADP VALUE CANP VALVE****ADP VALUE CANP VALVE 1(%)** \_\_\_\_\_ (range: not available)

Indicates the learning value of the canister purge system. It displays the duty cycle the ECM has learned.

**ADP VALUE ISC** \_\_\_\_\_ (range: not available)

Indicates the learning value of the idle control system. It displays the duty cycle the ECM is commanding.

**ADP VALUE MIXTURE(BANK1)(%)****ADP VALUE MIXTURE(BANK2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery for cylinders 1 to 3 (Bank 1) and cylinders 4 to 6 (Bank 2). It shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction.

A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.



**ADP VALUE MIXTURE(BANK1)  
ADP VALUE MIXTURE(BANK2)** \_\_\_\_\_ (range: 0.0 to 1.9)

Indicates the operation and Short-term correction of the fuel delivery for cylinders 1 to 4 (Bank 1) and for cylinders 5 to 8 (Bank 2). It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.0 to 1.9 with 1.0 as the midpoint. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.

**AIR DIVERT VALVE** \_\_\_\_\_ (range: ON/OFF)

Indicates the state of the dual path intake manifold used on the 2.8 5V V6. There are two sets of intake runners of different lengths. At lower engine speeds the length of the intake manifold is lengthened with smaller diameter runners to produce a ram effect (increased air velocity). At higher RPM, the intake manifold is shortened with larger diameter runners to reduce restriction to faster moving air. Should read ON (ECM command) at 4500 RPM.

An actuator or rotary servo changes intake manifold position from low to high or high to low. At 4500 RPM after the Intake Manifold change over valve receives a signal from the ECM, it supplies vacuum to the servo which in turn moves the rotary valve to engage the high speed intake runners. When engine RPM drops, the change over valve shuts off vacuum to the servo (low speed intake runners) and vents trapped vacuum.

**AIR MASS IDLE(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of alteration required to maintain idle speed when there is a change in load conditions at idle, such as when the heated rear window is switched on. Once the ECM has learned the new value, the figure should return to the mean setting (0).

**ALTERNATOR DEFECT** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has recognized a charging voltage. The reading is YES when the ECM is allowing adaptation (adaptive learn). If the reading is NO, the ECM will not relearn any adaptation values.

**ALTERNATOR LOAD(%)** \_\_\_\_\_ (range: not available)

Indicates the current alternator load.

**ALTITUDE CORRECTION FACTOR  
ALTITUDE CORRECTION FACTOR(%)** \_\_\_\_\_ (range: not available)

Indicates the correction factor for altitude, which is applied to air intake and lambda values when driving in mountainous terrain. This is an ECM-calculated value that compares air mass and throttle angle, and is greatly influenced by intake air temperature.

**AMBIENT TEMPERATURE(°C/°F)** \_\_\_\_\_ (range: not available)

Indicates the temperature of the ambient air outside the vehicle.

**AUX HEATING REQUESTED** \_\_\_\_\_ (range: not available)

Indicates if Auxiliary Heat is requested or not.

**BAROMETRIC PRESSURE(mbar)** \_\_\_\_\_ (range: not available)

Indicates barometric pressure, which is provided by the barometric pressure (BARO) sensor, in millibars. The reading should be high when barometric pressure is near atmospheric pressure at sea level, and drop as barometric pressure drops.

The ECM uses the BARO sensor to calculate manifold vacuum and true absolute pressure. Some systems do not have a BARO sensor, but the ECM provides a BARO reading by sampling the MAP sensor reading with the key on and engine off just before cranking.

**BASE THR POS(IDLE SW CLSD)(°)** \_\_\_\_\_ (range: not available)

Indicates throttle opening in degrees based on the Throttle Position Sensor low range potentiometer. This is one of two potentiometers incorporated into one (throttle position) TP sensor. The signal is for the whole range (from idle to full throttle).

**BASE VALUE THROTTLE ADJUSTER** \_\_\_\_\_ (range: not available)

Indicates the stored base value for the throttle value potentiometer position when throttle valve is fully closed. The value is determined when base settings are activated with the throttle closed.

**BASE VALUE TPS**

**BASE VALUE TPS(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from throttle position (TP) sensor low range potentiometer. This is one from a set of two potentiometers incorporated into one TP sensor. The signal is for the whole range (from idle to full throttle).

**BATTERY(V)** \_\_\_\_\_ (range: not available)

Indicates vehicle battery voltage. The engine control system has no specific sensor to measure battery voltage, but some ECMs calculate this parameter from a sensing circuit across the supply voltage circuit. The reading should be close to normal charging system regulated voltage with the engine running. This is typically 13.5 to 14.5V at idle. Check the reading against actual voltage measured at the battery or alternator. Check vehicle specifications for exact values.

The battery voltage value is used principally for ECM self-diagnostics. Some ECM functions will be modified if voltage falls too low or rises too high. For example, if voltage drops below minimum value, the ECM will try to recharge the battery by running the engine at a higher idle speed. This may affect the idle speed control, fuel metering and ignition timing parameters.

**BATTERY VOLTAGE TOO LOW** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has recognized a battery voltage that is too low for reliable operation. If the reading is NO, then Adaptation (adaptive learn) can take place. If the reading is YES, then the ECM will not relearn any values.

**BOOST PRESSURE(ACTUAL)(mbar)** \_\_\_\_\_ (range: not available)

Indicates the current pressure in the intake manifold. The value is in millibar and will be an absolute pressure.

**BOOST PRESSURE(DESIRED)(mbar)** \_\_\_\_\_ (range: not available)

Indicates the desired intake manifold pressure under present operating conditions. The value is in millibar and will be an absolute pressure.

**BOOST PRESSURE(mbar)** \_\_\_\_\_ (range: not available)

Indicates the pressure in the intake manifold under current operating conditions. The value is in millibar and will be an absolute pressure.

**BRAKE PEDAL PRESSED** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has detected that the brake pedal has been pressed.

**BRAKE PEDAL SWITCH** \_\_\_\_\_ (range: OPEN/CLOSED)

Indicates whether the ECM has detected that the brake pedal switch is closed or open.

**CAM ADJUSTER MODE** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates whether the ECM has activated camshaft timing adjustments.

**CAMSHAFT ADJUSTER** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates whether the ECM has activated camshaft timing adjustments.

**CAMSHAFT ADJUSTER(ACTIVE)(°)**  
**CAMSHAFT ADVANCE(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of camshaft adjustment commanded by the ECM in degrees.

**CAMSHAFT PHASING** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has activated the camshaft timing adjustments.

**CAMSHAFT POSITION(BANK 1)(°)**  
**CAMSHAFT POSITION(BANK 2)(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of camshaft adjustment commanded by the ECM for the intake camshaft on cylinders 1 to 3 (Bank 1) or cylinders 4 to 6 (Bank 2) from its base position.

**CANISTER PURGE MODE** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates the operating mode of the canister purge valve.

**CANP CHARGE(%)** \_\_\_\_\_ (range: 0 to 100%)

Indicates the percentage of canister purge flow. The duty cycle solenoids in these systems are turned on to activate purging and turned off to block purging. A reading of 0 indicates that the solenoid is fully de-energized to cut off purging. A reading of 100 indicates that the solenoid is fully energized to allow maximum purging.

**CANP FLUSH** \_\_\_\_\_ (range: 0 to 100%)

Indicates the percentage of canister purge flushed from the charcoal canister back into the engine for re-burn. A reading of 0 indicates the solenoid is fully de-energized to cut off purging. A reading of 100 indicates the solenoid is fully energized to allow maximum purging.

**CANP SYSTEM ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is active (purging).

**CANP VALVE CLOSED** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is closed (not purging).

**CANP VALVE ON CHARGE** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is in check mode. In check mode, the ECM calculates the fuel content of the fumes coming from the canister by measuring the effect the fumes have on the lambda signal.

**CANP VALVE ON MIN MODE** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is at a minimum pulse width in order to stop sudden mixture changes and improve driveability.

**CANP VALVE ON NORMAL MODE** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is operating normally.

**CAT TEMPERATURE>300°C** \_\_\_\_\_ (range: not available)

Indicates whether catalytic converter (CAT) temperature is above 300°C (572°F).

**CATALYST TEMPERATURE(°C/F)** \_\_\_\_\_ (range: not available)

Indicates catalytic converter (CAT) temperature.

**CATALYST EFFICIENCY(%)** \_\_\_\_\_ (range: not available)

Indicates the efficiency of the catalytic converter (CAT) based on O2S signals.

**CHANGE OVER TO CHARGE MODE CANP** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is in charge mode.

**CHANGE OVER TO CLOSE MODE CANP** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is closed.

**CHANGE OVER TO MIN MODE CANP** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the canister purge valve, it reads YES when the canister purge valve (CANP) is at a minimum pulse width in order to stop sudden mixture changes and improve driveability.

**CLUTCH PEDAL PRESSED** \_\_\_\_\_ (range: YES/NO)

Indicates clutch pedal status, it reads YES when the ECM detects the clutch pedal is pressed.

**CLUTCH PEDAL SWITCH** \_\_\_\_\_ (range: OPEN/CLOSED)

Indicates the current state of the clutch pedal switch.

**CODING FOR SYNCRO(4WD)** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is coded for 4WD.

**COMBINED HALL & ENG SPEED SIGN** \_\_\_\_\_ (range: not available)

Indicates the number of teeth on the crankshaft sender wheel until the hall sensor on the camshaft switches. The ECM uses this to determine the relative positions of crank and cam.

**CONTROL VALUE MIXTURE(%)**

**CTRL VALUE MIXTURE(BANK 1)(%)**

**CTRL VALUE MIXTURE(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery for the stated cylinders. The reading shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.

**COOLANT TEMPERATURE >80°C** \_\_\_\_\_ (range: YES/NO)

Indicates whether the engine coolant temperature is above 80°C (176°F). It is used during some adaptive learning processes.

**CRUISE CTRL ENABLED** \_\_\_\_\_ (range: ON/OFF)

Indicates the current state of the main cruise control switch.

**CRUISE CTRL STATUS** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates the current state of the main cruise control switch.

**CTRL VALUE IDLE AIR MASS(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of air that bypasses the throttle at idle and thus controls the idle speed. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value in grams per second.

**CTRL VALUE MIXTURE/O2 \_\_\_\_\_ (range: not available)**

Indicates the operation and Short-term correction of the fuel delivery. The reading shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint, but in practice the number only ranges from 0.9 to 1.1. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.

**CTRL VALUE MIXTURE/O2(%) \_\_\_\_\_ (range: not available)**

Indicates the operation and Short-term correction of the fuel delivery. The reading shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.

**CURRENT CONSUMPTION IAC(A) \_\_\_\_\_ (range: not available)**

Indicates the amount of current used by the IAC (Idle Air Control) valve as amperes.

**CURRENT CTRL FACTOR IAC \_\_\_\_\_ (range: not available)**

Indicates the amount of current used by the IAC (Idle Air Control) valve as a percentage.

**CURRENT CTRL IAC(%) \_\_\_\_\_ (range: not available)**

Indicates the control factor regulating the current to the IAC valve as a percentage.

**CYLINDER 1 RECOGNIZED \_\_\_\_\_ (range: YES/NO)**

Indicates whether the ECM has detected cylinder number 1 TDC.

**DECEL ENLEAN \_\_\_\_\_ (range: not available)**

Indicates whether the ECM is providing a lean air/fuel mixture during deceleration.

**DECELERATE POSITION \_\_\_\_\_ (range: YES/NO)**

Indicates whether the ECM determines the current engine operating condition as deceleration.

**DECELERATION ENLEANMENT \_\_\_\_\_ (range: not available)**

Indicates whether the ECM is providing a lean air/fuel mixture due to deceleration.

**DIAGNOSE LEARN VALUE O2(BK1)IDLE****DIAGNOSE LEARN VALUE O2(BK1)P/T2****DIAGNOSE LEARN VALUE O2(BK1)P/T3****DIAGNOSE LEARN VALUE O2(BK1)P/T4****DIAGNOSE LEARN VALUE O2(BK2)IDLE****DIAGNOSE LEARN VALUE O2(BK2)P/T2****DIAGNOSE LEARN VALUE O2(BK2)P/T3****DIAGNOSE LEARN VALUE O2(BK2)P/T4 \_\_\_\_\_ (range: YES/NO)**

Indicates whether the relearn operation for the stated cylinders and engine/throttle load conditions was successful.

**DUTY CYCLE CANP VALVE**  
**DUTY CYCLE CANP VALVE(%)** \_\_\_\_\_ (range: not available)

Indicates the percentage of canister purge flow. The duty cycle solenoids in these systems are turned on to activate purging and turned off to block purging. A reading of 0% indicates that the solenoid is fully de-energized to cut off purging. A reading of 100% indicates that the solenoid is fully energized to allow maximum purging.

**DUTY CYCLE EGR-VALVE(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the Exhaust Gas Recirculating (EGR) valve. Exhaust gasses can be added to the intake air (to cool combustion temperatures thus reducing the formation of NOx). EGR valve open/close rate depends on operating conditions of the engine.

**DUTY CYCLE FAN CTRL VALVE(%)** \_\_\_\_\_ (range: not available)

Indicates the duty-cycle of the electric ventilator. A lower percentage means the ventilator is blowing lightly.

**DUTY CYCLE IAC(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the IAC valve.

**DUTY CYCLE ISC(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the throttle valve positioner, which regulates the throttle stop position, thus controlling idle speed.

**DUTY CYCLE THR ADJUSTER(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the throttle adjuster valve.

**DUTY CYCLE WASTE GATE VALVE(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the turbo waste gate actuator valve. This action governs the turbo output (manifold) pressure.

**EGR-SYSTEM** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates whether the EGR system is active or not.

**EGR-TEMPERATURE(°C/°F)** \_\_\_\_\_ (range: not available)

Indicates EGR system temperature based on a feedback signal from a thermistor installed in the EGR passage.

**ENGINE LOAD(%)** \_\_\_\_\_ (range: not available)

Indicates the ECM calculated relative engine load based on engine speed (RPM), number of cylinders, and manifold airflow. High readings indicate a heavy load; low readings, a light load.

**ENGINE LOAD(ms)** \_\_\_\_\_ (range: not available)

Indicates the relative engine load based on a processed signal that comes from the Throttle Position Sensor and/or the Manifold Air Flow sensor and/or the Manifold Air Pressure sensor and/or the Intake Air Temperature sensor. The Engine Load has still to be corrected with all lambda factors. View this in conjunction with the injection period where Engine Load is the theoretical Injection time and the injection period is the corrected actual value.

**ENGINE LOAD(V)** \_\_\_\_\_ (range: not available)

Indicates the ECM calculated relative engine load as voltage based on engine speed (RPM), number of cylinders, and manifold airflow.

**ENGINE LOAD(ACTUAL)(%)** \_\_\_\_\_ (range: not available)

Indicates the ECM calculated actual engine load based on engine speed (RPM), number of cylinders, and manifold airflow. High readings indicate a heavy load; low readings, a light load.

**ENGINE LOAD(ACTUAL)(ms)** \_\_\_\_\_ **(range: not available)**

Indicates the actual engine load based on a processed signal that comes from the Throttle Position Sensor and/or the Manifold Air Flow sensor and/or the Manifold Air Pressure sensor and/or the Intake Air Temperature sensor. The load has been corrected with all factors.

**ENGINE LOAD(ACTUAL)(Nm)** \_\_\_\_\_ **(range: not available)**

Indicates the ECM calculated actual engine load based on engine speed (RPM), number of cylinders, and manifold airflow as newton meters (Nm).

**ENGINE LOAD(AFTER CORR)(ms)** \_\_\_\_\_ **(range: not available)**

Indicates the corrected engine load based on a processed signal that comes from the Throttle Position Sensor and/or the Manifold Air Flow sensor and/or the Manifold Air Pressure sensor and/or the Intake Air Temperature sensor. The load has been corrected with all factors.

**ENGINE LOAD(BEFORE CORR)(ms)** \_\_\_\_\_ **(range: not available)**

Indicates the uncorrected engine load based on a processed signal that comes from the Throttle Position Sensor and/or the Manifold Air Flow sensor and/or the Manifold Air Pressure sensor and/or the Intake Air Temperature sensor. The load has still to be corrected with all lambda factors.

**ENGINE LOAD AFTER REDUC(ms)** \_\_\_\_\_ **(range: not available)**

Indicates the engine load based on a processed signal that comes from the Throttle Position Sensor and/or the Manifold Air Flow sensor and/or the Manifold Air Pressure sensor and/or the Intake Air Temperature sensor. The load has been corrected with knock control factors.

**ENGINE SPEED(RPM)** \_\_\_\_\_ **(range: not available)**

Indicates whether the ECM is receiving engine speed information from the engine speed sensor, then passing this information on to the TCM.

Signal utilization: The engine speed signal is one of the most important input signals and is required for calculation of the shift points.

**ENGINE SPEED <760 RPM****ENGINE SPEED <2000 RPM****ENGINE SPEED <2300 RPM****ENGINE SPEED <2500 RPM****ENGINE SPEED >2500 RPM****ENGINE SPEED >1800 RPM** \_\_\_\_\_ **(range: YES/NO)**

Indicates whether the engine is running at more than (<) or less than (>) the indicated RPM. They are used during some adaptive learning processes.

**ENGINE SPEED(ACTUAL)(RPM)**

Indicates the ECM calculated engine speed based on reference pulses from the ignition system or a crankshaft sensor. This is the recorded actual RPM as opposed to desired RPM.

**ENGINE SPEED(DESIRED)(RPM)** \_\_\_\_\_ **(range: not available)**

Indicates the idle speed that the ECM is trying to maintain. If there is a large difference between actual idle and desired RPM readings, the ECM may have reached its control limit without being able to control the idle speed. This may be due to a basic mechanical or electrical problem with the engine.

**ENGINE SPEED(IDLE)(RPM)** \_\_\_\_\_ **(range: not available)**

Indicates the actual recorded idle RPM as opposed to desired RPM.

**ENGINE SPEED SIGNAL RECOGNIZED** \_\_\_\_\_ **(range: YES/NO)**

Indicates whether the ECM has determined that the engine is running. The reading should be YES with the engine running, this value is used during some adaptive learning processes.

**EXHAUST GAS TEMPERATURE(°C/°F)** \_\_\_\_\_ (range: not available)

Indicates the exhaust-gas temperature.

**FUEL COOLING(%)** \_\_\_\_\_ (range: not available)

Indicates the percentage that the fuel is cooled.

**FUEL CUT OFF  
FUEL CUT-OFF VALVE ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates the status of the ECM command to cut off to the injectors during engine overrun.

**FUEL HEAT(l/h)** \_\_\_\_\_ (range: not available)

Indicates the amount of fuel that is used by the external heater.

**FUEL LOW** \_\_\_\_\_ (range: not available)

Indicates whether the fuel level is low.

**FULL LOAD DETECTED  
FULL LOAD** \_\_\_\_\_ (range: YES/NO)

Indicates whether the engine is currently operating at full load. The reading is YES at full load, this value is used during some adaptive learning processes.

**FULL LOAD SWITCH** \_\_\_\_\_ (range: OPEN/CLOSED)

Indicates the ECM output to the TP sensor full load switch.

**HALL-SENSOR(°)**

Indicates the position of the Hall Sensor offset against the zero adjustment in crankshaft angle degrees.

**IAC INTEGRATOR** \_\_\_\_\_ (range: not available)

Indicates the working zero range of the idle air control (IAC). It represents the point that the ECM regards as IAC set to 0 (no adjustment required). The number can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has learned to reduce the idle. A number below 128 indicates that the ECM has learned to increase the idle.

**IDLE AIR CORRECTION(g/s)** \_\_\_\_\_ (range: not available)

Indicates the correction factor of the idle control system. The value is the amount of airflow correction the ECM is commanding.

**IDLE AIR CTRL(%)** \_\_\_\_\_ (range: not available)

Indicates the duty cycle of the idle air control valve, which regulates the throttle stop position, thus controlling idle speed.

**IDLE AIR MASS(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of air being drawn into the engine at idle. Most port fuel injection engines have an airflow sensor to measure the mass or weight of air entering the engine. The airflow sensor delivers a signal that indicates the mass airflow in grams per second at any given instant. The ECM uses the signal from the airflow sensor and other sensors to determine the air/fuel ratio needed by the engine and the amount of fuel to be injected.

**IDLE SPEED(ACTUAL)(RPM)** \_\_\_\_\_ (range: not available)

Indicates the actual engine idle speed recorded by the ECM, as opposed to desired RPM.

**IDLE SPEED(DESIRED)(RPM)** \_\_\_\_\_ (range: not available)

Indicates the engine idle speed the ECM is trying to maintain, as opposed to the actual RPM.



**IDLE SPEED CTRL VALVE****IDLE SPEED CTRL VALVE(%)** \_\_\_\_\_ (range: not available)

Indicates the amount of air that bypasses the throttle at idle. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value as a percentage of the total airflow.

**IDLE SPEED SWITCH** \_\_\_\_\_ (range: OPEN/CLOSED)

Indicates the ECM has detected idle switch state. It is used in conjunction with other parameters when the ECM is applying learned idle values.

**IDLE SPEED SWITCH CLOSED** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has detected that the idle switch is closed. It is used in conjunction with other parameters when the ECM is applying learned idle values.

**IDLE SPEED SWITCH OPEN** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has detected that the idle switch is open. It is used in conjunction with other parameters when the ECM is applying learned idle values.

**IGN ADV W KNOCK & ISC(AV)(°)** \_\_\_\_\_ (range: not available)

Indicates the average amount of ignition advance actually applied to the engine after any retardation by the knock sensor or idle speed control has been removed.

**IGN RTD BY A/T-ECU(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance removed by the ECM when the automatic transmission commands it. Timing is retarded from the optimum advance for the existing speed and load.

**IGN RTD BY DIGITAL ISC(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance removed by the ECM when the digital idle speed control (ISC) commands it. Timing is retarded from the optimum advance for the existing speed and load.

**IGN RTD BY KNOCK(°)****IGN RTD BY KNOCK CTRL(°)****IGN RTD BY KNOCK(ALL CYL)(°)****IGN RTD BY KNOCK CTRL(CYL 1)(°)****IGN RTD BY KNOCK CTRL(CYL 2)(°)****IGN RTD BY KNOCK CTRL(CYL 3)(°)****IGN RTD BY KNOCK CTRL(CYL 4)(°)****IGN RTD BY KNOCK CTRL(CYL 5)(°)****IGN RTD BY KNOCK CTRL(CYL 6)(°)****IGN RTD BY KNOCK CTRL(CYL 7)(°)****IGN RTD BY KNOCK CTRL(CYL 8)(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance removed by the ECM when detonation is sensed by the knock sensor. Timing is retarded from the optimum advance for existing speed and load.

**IGN RTD BY TCS-ECU(COLD)(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance to be removed by the ECM using the traction control system (only with engine cold conditions) restrictions. Timing is retarded from the optimum advance for the existing speed and load.

**IGN RTD WITH KNOCK & ISC(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance actually applied to the engine after any retardation by the knock sensor or idle speed control has been removed.

**IGN RTD W/O KNOCK & W/O ISC(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance commanded by the ECM before any retardation by the knock sensor or idle speed control has been removed.

**IGNITION ADV(CALCULATED)(°)** \_\_\_\_\_ (range: not available)

Indicates the amount of ignition advance before other factors are removed by the ECM.

**IGNITION ADV REDUCTION** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates whether the ignition timing reduction system is active or not.

**IGNITION ADVANCE(°)** \_\_\_\_\_ (range: not available)

Indicates the total spark advance or retard commanded by the ECM, including base timing.

**IGNITION MAP** \_\_\_\_\_ (range: not available)

Indicates which ignition timing map is currently being used by the ECM. The map changeover is initiated by the knock sensor. The 1ST TIMING MAP is the default choice (98 octane) and the 2ND TIMING MAP retards the overall ignition timing (95 octane).

**INCREASED IDLE SPEED WITH A/C ON** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has detected the A/C is active. If so, the ECM increases the idle speed to compensate.

**INCREASING RPM** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is increasing the idle speed because the A/C is active.

**INJ QUANTITY(mm3)** \_\_\_\_\_ (range: not available)

Indicates the maximum quantity of fuel that has been injected under the present operating conditions. The value is in cubic milliliters per cylinder stroke.

**INJECTION TIME(ms)** \_\_\_\_\_ (range: not available)

Indicates the length of time that the ECM commands the fuel injectors to turn on in milliseconds (ms). A high reading indicates more "on time" and a richer mixture. A low reading indicates less "on time" and a leaner mixture. There are no definite specifications for injector pulse, but the reading should change as engine speed and load change.

**INJECTION TIME(AVERAGE)(ms)** \_\_\_\_\_ (range: not available)

Indicates the average length of time that the ECM commands the fuel injectors to turn on in milliseconds (ms). A high reading indicates more "on time" and a richer mixture. A low reading indicates less "on time" and a leaner mixture. There are no definite specifications for injector pulse, but the reading should change as engine speed and load change.

**INTAKE MANIFOLD PRESSURE(%)** \_\_\_\_\_ (range: not available)

Indicates intake manifold vacuum as a percentage. The ECM uses the figure in calculations to determine engine load.

**INTAKE MANIFOLD PRESSURE(mbar)** \_\_\_\_\_ (range: not available)

Indicates intake manifold vacuum as millibar. The ECM uses the figure in calculations to determine engine load.

**ISC(CTRL FACTOR)** \_\_\_\_\_ (range: not available)

Indicates the idle stabilizing control factor.

**ISC(POSITION)** \_\_\_\_\_ (range: not available)

Indicates the idle speed control valve position.

**ISC(REACTION TO MALFUNCTION)** \_\_\_\_\_ (range: not available)

Indicates the influence value of a system fault on the idle speed control system.

**ISC INTGRATOR** \_\_\_\_\_ (range: not available)

Indicates the integrator value for the idle speed control.

**ISC UNDER LOAD \_\_\_\_\_ (range: not available)**

Indicates the working range of the idle speed control (ISC) when a load is applied (example, with A/C operating). It indicates whether the ECM is commanding a faster or slower idle. The number can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has commanded less air to slow the idle. A number below 128 indicates that the ECM has commanded more air to speed up the idle.

**KNOCK CTRL(°) \_\_\_\_\_ (range: not available)**

Indicates the amount of spark advance removed by the ECM when detonation is sensed by the knock sensor. Timing is retarded from the optimum advance for existing speed and load. The value is the amount of advance that has been taken away.

**KNOCK SENSOR(CYL 1)(V)****KNOCK SENSOR(CYL 2)(V)****KNOCK SENSOR(CYL 3)(V)****KNOCK SENSOR(CYL 4)(V)****KNOCK SENSOR(CYL 5)(V)****KNOCK SENSOR(CYL 6)(V)****KNOCK SENSOR(CYL 7)(V)****KNOCK SENSOR(CYL 8)(V) \_\_\_\_\_ (range: not available)**

Indicates the voltage read by the ECM when detonation is sensed by the knock sensor on the indicated cylinder.

**LACK OF FUEL \_\_\_\_\_ (range: not available)**

Indicates whether or not there is a lack of fuel.

**LEARN AIR MASS IDLE(g/s) \_\_\_\_\_ (range: not available)**

Indicates the learned value of air that bypasses the throttle at idle and thus controls the idle speed. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value in grams per second.

**LEARN AIR MASS IDLE(D)(g/s) \_\_\_\_\_ (range: not available)**

Indicates the learned value of air that bypasses the throttle at idle only if the transmission is in drive. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value in grams per second.

**LEARN AIR MASS IDLE(P/N)(g/s) \_\_\_\_\_ (range: not available)**

Indicates the learned value of air that bypasses the throttle at idle only if the transmission is in park or neutral. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value in grams per second.

**LEARN INJECTION TIME(ms) \_\_\_\_\_ (range: not available)**

Indicates the value in milliseconds that the ECM is using as an adaptive value for injection time correction.

**LEARN MIXT(BANK 1)(IDLE)(%)**  
**LEARN MIXT(BANK 1)(P/T)(%)**  
**LEARN MIXT(BANK 1)(P/T1)(%)**  
**LEARN MIXT(BANK 1)(P/T2)(%)**  
**LEARN MIXT(BANK 1)(P/T3)(%)**  
**LEARN MIXT(BANK 1)(IDLE)(%)**  
**LEARN MIXT(BANK 1)(P/T)(%)**  
**LEARN MIXT(BANK 2)(IDLE)(%)**  
**LEARN MIXT(BANK 2)(P/T)(%)**  
**LEARN MIXT(BANK 2)(P/T1)(%)**  
**LEARN MIXT(BANK 2)(P/T2)(%)**  
**LEARN MIXT(BANK 2)(P/T3)(%)**  
**LEARN MIXT(BANK 2)(IDLE)(%)**  
**LEARN MIXT(BANK 2)(P/T)(%)** \_\_\_\_\_ **(range: not available)**

Indicates the operation and Long-term correction of the fuel delivery for the stated loads and cylinders. The readings show whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded an overall rich mixture correction. A number below 0% indicates that the ECM has commanded an overall lean mixture correction. Fuel correction parameters operate only in closed loop. In open loop, the number changes to a fixed value.

**LEARN RANGE O2 IDLE**  
**LEARN RANGE O2 P/T 2**  
**LEARN RANGE O2 P/T 3**  
**LEARN RANGE O2(BK1)IDLE**  
**LEARN RANGE O2(BK1)P/T2**  
**LEARN RANGE O2(BK1)P/T3**  
**LEARN RANGE O2(BK1)P/T4**  
**LEARN RANGE O2(BK2)IDLE**  
**LEARN RANGE O2(BK2)P/T2**  
**LEARN RANGE O2(BK2)P/T3**  
**LEARN RANGE O2(BK2)P/T4** \_\_\_\_\_ **(range: REACHED/NOT REACHED)**

Indicates the state of the lambda learned range when at idle or part load section 2, 3, for cylinders 1 to 3 (Bank 1) when at idle or part load section 2, 3 or 4, and for cylinders 4 to 6 (Bank 2) when at idle or part load section 2, 3 or 4.



**NOTE:**

On some OBD-I (1991–1995) vehicles, the displayed values for Short-term fuel trim, LEARN O2 (IDLE), LEARN O2 (P/T), or LEARN O2 (FULL), may be mislabeled as reading in percentage. In actuality, they are reading a numeric factor of 1.0 midpoint  $\pm 0.5$  (0.5 to 1.5). For 2.8L AAA engine, the range is 0.80–1.20.

**LEARN VALUE AIR MASS IDLE(%)** \_\_\_\_\_ **(range: see description)**

Indicates the learned value correction for idle speed based on mass airflow. The number can range from -100% to 100% with 0% as the midpoint. A number above 0% indicates that the ECM has commanded a overall high idle correction. A number below 0% indicates that the ECM has commanded a overall low idle correction.

**LEARN VALUE AIR MASS IDLE(g/s)** \_\_\_\_\_ **(range: see description)**

Indicates learned value of air that bypasses the throttle at idle and thus controls the idle speed. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value in grams per second.

**LEARN VALUE CANP SYSTEM \_\_\_\_\_ (range: see description)**

Indicates the learned canister purge value, an internal calculating factor and can be ignored.

**LEARN VALUE DC ISC  
LEARN VALUE DC ISC(%) \_\_\_\_\_ (range: see description)**

Indicates the learned duty cycle of the idle air control motor and thus controls the idle speed.

**LEARN VALUE DC ISC(AT) \_\_\_\_\_ (range: see description)**

Indicates the learned value of the idle air control motor on models with an automatic transmission. The value is the duty cycle of the ISC valve.

**LEARN VALUE DC ISC(MUL)(%) \_\_\_\_\_ (range: not available)**

Indicates the learned duty cycle of the idle air control motor and thus controls the idle speed.

**LEARN VALUE IAC \_\_\_\_\_ (range: not available)**

Indicates the current learned idle air control value.

**LEARN VALUE IDLE SPEED(NOT P/N) \_\_\_\_\_ (range: not available)**

Indicates the learning value for the idle stabilizing control system when an automatic transmission is in drive or reverse range.

**LEARN VALUE IDLE SPEED(P/N) \_\_\_\_\_ (range: not available)**

Indicates the learning value for the idle stabilizing control system when an automatic transmission is in neutral or park range, or when a manual transmission is in neutral.

**LEARN VALUE ISC \_\_\_\_\_ (range: not available)**

Indicates the current learned idle speed control value.

**LRN VALUE ISC(g/s) \_\_\_\_\_ (range: not available)**

Indicates the learned value of the idle speed control airflow when the transmission is in park or neutral range. The motor that drives the ISC valve returns the duty cycle to the ECM which calculates the airflow value in grams per second.

**LEARN VALUE ISC(AT IN D) \_\_\_\_\_ (range: not available)**

Indicates the learned value of the idle air control motor when an automatic transmission is in a forward or reverse range. The value is the ISC valve duty cycle.

**LEARN VALUE ISC(MT/AT IN P/N) \_\_\_\_\_ (range: not available)**

Indicates the learned value of the idle air control motor when the transmission is in park or neutral range. The value is the ISC valve duty cycle.

**LEARN VALUE KICKDOWN(%) \_\_\_\_\_ (range: not available)**

Indicates the learning value for the kickdown of the automatic transmission.

**LEARN VALUE MAF-SENSOR \_\_\_\_\_ (range: not available)**

Indicates the learning voltage being read by the Mass Air Flow (MAF) sensor. This voltage is used by the ECM to calculate the maximum amount of air being drawn into the engine.

**LEARN VALUE MIXTURE \_\_\_\_\_ (range: not available)**

Indicates the operation and Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded an overall rich mixture correction. A number below 1.0 indicates that the ECM has commanded an overall lean mixture correction.

Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE MIXTURE(%)****LEARN VALUE MIXTURE(BANK 1)(%)****LEARN VALUE MIXTURE(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture. The number theoretically can range from -100% to 100% with 0% as the midpoint. A number above 0% indicates that the ECM has commanded an overall rich mixture correction. A number below 0% indicates that the ECM has commanded an overall lean mixture correction.

These Long-term correction numbers are calculated by the ECM from the Short-term fuel correction patterns or trends. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE MIXTURE(ADAPTIVE)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0 to 255 with 0 as the midpoint. A number of 13 to 128 indicates that the ECM has commanded an overall lean mixture correction. A number of 128 to 243 indicates that the ECM has commanded an overall rich mixture correction.

These Long-term correction numbers are calculated by the ECM from the Short-term fuel correction patterns or trends. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE MIXTURE(ADP)(ms)** \_\_\_\_\_ (range: not available)

Indicates what the ECM uses as a learned value for injection time correction in milliseconds.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE MIXTURE(BANK 1)****LEARN VALUE MIXTURE(BANK 2)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery for cylinders 1 to 4 (Bank 1) or 5 to 8 (Bank 2). The readings show if the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded an overall rich mixture correction. A number below 1.0 indicates that the ECM has commanded an overall lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE MIXTURE(CANP ACT)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery when the canister purge system is active. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from -100% to 100% with 0% as the midpoint. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE MIXTURE(IDLE)(%)**  
**LEARN VALUE MIXTURE(P/T1)(%)**  
**LEARN VALUE MIXTURE(P/T2)(%)**  
**LEARN VALUE MIXTURE(P/T3)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery when at idle or part throttle 1, 2 or 3 only. (Sections of a petitioned part load range). It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from -100% to 100% with 0% as the midpoint. A number above 0% indicates that the ECM has commanded an overall rich mixture correction. A number below 0% indicates that the ECM has commanded an overall lean mixture correction.

These Long-term correction numbers are calculated by the ECM from the Short-term fuel correction patterns or trends. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE MIXTURE CORR** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has commanded an overall rich mixture correction. A number below 128 indicates that the ECM has commanded an overall lean mixture correction.

These Long-term correction numbers are calculated by the ECM from the Short-term fuel correction patterns or trends. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE MIXTURE CORR(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from -100% to 100% with 0% as the midpoint. A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE MIXTURE CORR(ms)** \_\_\_\_\_ (range: not available)

Indicates the learning value the ECM is using for injection time correction at idle in milliseconds.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE O2** \_\_\_\_\_ (range: not available)

Indicates the Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has commanded a overall rich mixture correction. A number below 128 indicates that the ECM has commanded a overall lean mixture correction.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE O2(%) \_\_\_\_\_ (range: not available)**

Indicates the operation and Long-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from -100% to 100% with 0% as the midpoint. A number above 0% indicates that the ECM has commanded an overall rich mixture correction. A number below 0% indicates that the ECM has commanded an overall lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE O2(ACTUAL)(BK1)(%)  
LEARN VALUE O2(ACTUAL)(BK2)(%) \_\_\_\_\_ (range: not available)**

Indicates the actual value (before correction) of the fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). A number above 0% indicates a rich mixture. A number below 0% indicates a lean mixture. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE O2(BK1)  
LEARN VALUE O2(BK2) \_\_\_\_\_ (range: not available)**

Indicates the operation and Short-term correction of the fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). They show whether the ECM is commanding a rich or lean mixture.

The number theoretically ranges from 0.00 to 2.00 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page 117 for details.

**LEARN VALUE O2(BK1)(%)  
LEARN VALUE O2(BK2)(%)  
LEARN VALUE O2(BK1)(ADD)(%)  
LEARN VALUE O2(BK2)(ADD)(%)  
LEARN VALUE O2(BK1)(MUL)(%)  
LEARN VALUE O2(BK2)(MUL)(%)  
LEARN VALUE O2(BK1)(IDLE)(%)  
LEARN VALUE O2(BK2)(IDLE)(%)  
LEARN VALUE O2(BK1)(P/T)(%)  
LEARN VALUE O2(BK2)(P/T)(%) \_\_\_\_\_ (range: not available)**

Indicates the operation and Short-term correction of the fuel delivery for Bank 1 or Bank 2 under the stated engine load conditions. They show if the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.



**LEARN VALUE O2(BK1)IDLE OK**  
**LEARN VALUE O2(BK1)P/T1 OK**  
**LEARN VALUE O2(BK1)P/T2 OK**  
**LEARN VALUE O2(BK1)P/T3 OK** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has determined that the learned lambda value for cylinders 1 to 3 (Bank 1) at idle or part load sections is within tolerances. They read YES if adaptation is learned, and NO if the ECM has to relearn the lambda settings in this engine load range.

**LEARN VALUE O2(BK2)IDLE OK**  
**LEARN VALUE O2(BK2)P/T1 OK**  
**LEARN VALUE O2(BK2)P/T2 OK**  
**LEARN VALUE O2(BK2)P/T3 OK** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has determined that the learned lambda value for cylinders 4 to 6 (Bank 2) at idle or part load sections is within tolerances. They read YES if adaptation is learned, and NO if the ECM has to relearn the lambda settings in this engine load range.

**LEARN VALUE O2(FULL)**  
**LEARN VALUE O2(IDLE)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery, when at full throttle or at idle only. They show whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded an overall rich mixture correction. A number below 1.0 indicates that the ECM has commanded an overall lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE O2(IDLE)(%)**  
**LEARN VALUE O2(P/T)(%)**  
**LEARN VALUE O2(P/T)(MUL)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery under the stated engine load conditions. They show whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**LEARN VALUE O2(IDLE)(ms)** \_\_\_\_\_ (range: not available)

Indicates the learning value that the ECM is using for injection time correction at idle in milliseconds.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page page 117 for details.

**LEARN VALUE O2(P/T)**  
**LEARN VALUE O2(P/T-WOT)** \_\_\_\_\_ (range: not available)

Indicates the operation and Long-term correction of the fuel delivery when at part load or full throttle (WOT). They show whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded an overall rich mixture correction.

A number below 1.0 indicates that the ECM has commanded an overall lean mixture correction. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

On some OBD-I (1991–1995) vehicles, values for short-term fuel trim may be mislabeled. See the note on page 117 for details.

**LEARN VALUE O2 IDLE OK**  
**LEARN VALUE O2 P/T 1 OK**  
**LEARN VALUE O2 P/T 2 OK**  
**LEARN VALUE O2 P/T 3 OK** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has determined that the learned lambda value for idle or part load sections is within tolerances. They read YES when within tolerance, and NO if the ECM has to relearn the lambda adaptation settings in the idle engine load range.

**LEARN VALUE O2 SNS 1(IDLE)(%)** \_\_\_\_\_ (range: not available)

Indicates the learning value for the O2S when the engine is idling.

**LEARN VALUE O2 SNS 1(P/T)(%)** \_\_\_\_\_ (range: not available)

Indicates the learning value for the O2S when the engine is in part load according to the throttle position.

**LEARN VALUE THR VALVE ADJUSTER** \_\_\_\_\_ (range: not available)

Indicates the internal ECM figure for the learning value for the idling stabilization by throttle valve positioner.

**LEARN VALUE TPS** \_\_\_\_\_ (range: not available)

Indicates the learning value for the throttle position sensor.

**LEARN VALUE TPS(V)** \_\_\_\_\_ (range: not available)

Indicates the learning voltage for throttle closed. This value is learned by the ECM and is used as the throttle closed learned position.

**LIMITED DYNAMIC ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates whether the self diagnostic system has detected a fault in the lambda or lambda heater systems, even if no trouble codes are stored in the fault code memory.

**LIMITED OPERATION(LIMP)** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is operating in limited operation strategy (LOS or limp home mode), which can automatically supply substitute values when sensor failure occurs, so a sensor can fail and not necessarily affect driveability. Reading should normally be NO.

**LOS MODE** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is operating in limited operation strategy (LOS or limp home mode), which can automatically supply substitute values when sensor failure occurs, so a sensor can fail and not necessarily affect driveability. Reading should normally be NO.

**LRN IDLING STABILIZATION(kg/h)** \_\_\_\_\_ (range: not available)

Indicates the learned value of the idle control system. It shows the volume of air the ECM is commanding in kilograms per hour.

**MAF IDLE(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of extra air mass required to keep the engine idle speed correct when a change in load occurs, such as when the air conditioning or the rear heater is switched on.

**MAF ISC TRIM(%)** \_\_\_\_\_ (range: not available)

Indicates the amount of air that bypasses the throttle at idle. The motor that drives the IAC valve returns a value of 0 to 255 to the ECM. The ECM then converts this value into an airflow value as a percentage of the total airflow.

**MAF-SENSOR(V)** \_\_\_\_\_ (range: not available)

Indicates the actual voltage signal from the Mass Air Flow (MAF) sensor. This voltage is used by the ECM to calculate the maximum amount of air being drawn into the engine.

**MAF TRIM(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of extra air mass required to keep the engine idle speed correct when a change in load occurs, such as when the air conditioning or the rear heater is switched on.

**MAP(%)** \_\_\_\_\_ (range: not available)

Indicates intake manifold vacuum as a percentage. The ECM uses the figure in calculations to determine engine load.

**MAP(V)****MAP(mbar)** \_\_\_\_\_ (range: not available)

Indicates either actual voltage from the Manifold Absolute Pressure (MAP) sensor, or a pressure in mbar as calculated by the ECM based on the MAP sensor signal. The voltage is low when the absolute pressure is low and high when the absolute pressure is high.

On turbocharged engines, this value is used to control the amount of boost that the turbocharger delivers.

**MAP-CONTROLLED IDLE SPEED** \_\_\_\_\_ (range: not available)

Indicates the pre-mapped working range of the idle speed control (ISC). It shows the idle stabilization characteristics the ECM should use for a given set of operating conditions.

**MASS AIR FLOW(g/s)** \_\_\_\_\_ (range: not available)

Indicates mass air flow (MAF) in grams per second. Most port fuel injection engines have an airflow sensor to measure the mass or weight of air entering the engine. The airflow sensor delivers a signal that indicates the mass airflow in grams per second at any given instant. The ECM uses the signal from the airflow sensor and other sensors to determine the air/fuel ratio needed by the engine and the amount of fuel to be injected.

**MASS AIR FLOW(V)** \_\_\_\_\_ (range: not available)

Indicates the actual voltage being read by the Mass Air Flow (MAF) sensor. This voltage is used by the ECM to calculate the maximum amount of air being drawn into the engine.

**MASS AIR FLOW(ACTUAL)(g/s)** \_\_\_\_\_ (range: not available)

Indicates the actual amount of air flowing into the engine as grams per second.

Used on 2.0L 5.9.2 systems for measurement of reverse airflow at MAF sensor using two temperature sensors. Normal valve overlap and intake manifold design may cause reversion of airflow which results in incorrect rich mixture. Two similarly heated temperature sensors are ECM monitored in the MAF to detect differential temperatures.

**MASS AIR FLOW(DESIRED)(g/s)** \_\_\_\_\_ (range: not available)

Indicates the maximum quantity of air that should be drawn into the engine under the present operating conditions in grams per second.

**MAX VALUE THR ADJUSTER(%)** \_\_\_\_\_ (range: not available)

Indicates the throttle valve adjuster maximum stop position for start up and base idle.

**MAX VALUE THR ADJUSTER(V)** \_\_\_\_\_ (range: not available)

Indicates the throttle valve adjuster maximum position as voltage.

**MIN VALUE THR ADJUSTER(%)** \_\_\_\_\_ (range: not available)

Indicates the throttle valve adjuster minimum stop position for start up and basic idle.

**MIN VALUE THR ADJUSTER(V)** \_\_\_\_\_ (range: not available)

Indicates the throttle valve adjuster minimum stop position for start up and basic idle.

**MISFIRES PER 200 REVS(CYL.1)**

**MISFIRES PER 200 REVS(CYL.2)**

**MISFIRES PER 200 REVS(CYL.3)**

**MISFIRES PER 200 REVS(CYL.4)**

**MISFIRES PER 200 REVS(CYL.5)**

**MISFIRES PER 200 REVS(CYL.6)**

**MISFIRES PER 200 REVS(CYL.7)**

**MISFIRES PER 200 REVS(CYL.8)**

**MISFIRES PER 200 REVS(ALL CYL)** \_\_\_\_\_ (range: not available)

Indicates the number of misfires detected for the selected cylinder per 200 crankshaft revolutions (vehicle must be driven).

**MIXTURE** \_\_\_\_\_ (range: RICH/LEAN)

Indicates the general rich or lean condition of the exhaust as measured by the lambda O2S.

Exhaust oxygen content is related to oxygen content in the intake air/fuel mixture and thus indicates intake air/fuel ratio. The O2S is the primary sensor that indicates whether the engine is running rich or lean. The O2S must be hot and the ECM must be in closed loop before the ECM will respond to the sensor signal.

**MIXTURE CORR(CANP ACTIVE)** \_\_\_\_\_ (range: YES/NO)

Indicates the current mixture correction with canister purge valve active.

**MIXTURE CORRECTION** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has commanded a temporary rich mixture correction. A number below 128 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**MIXTURE CORRECTION(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**MODE HALL-REFERENCE SIGNAL** \_\_\_\_\_ (range: not available)

Indicates the position of the reference signal (missing teeth) in the Hall-effect sensor window.

**O2 ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda regulation part of the ECM is active or not (open/closed loop), this depends on the lambda sensor temperature and operating conditions of the engine. Under full load conditions, the ECM goes into open loop.

**O2 ADP & ACTUAL VALUE(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the actual fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction. These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**O2 CONTROL MODE** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates the current operating mode of the lambda system.

**O2 CORR(CANP ACTIVATED)** \_\_\_\_\_ (range: not available)

Indicates the required correction of the lambda figure when the canister purge system (CANP) is in operation. It shows whether the charge coming from the CANP is very rich or lean and therefore the ECM needs to reduce or increase the amount of fuel delivery.

The number theoretically can range from 0.0 to 1.9 with 1.0 as the midpoint. A number above 1.0 indicates an ECM command for a temporary rich mixture correction. A number below 1.0 indicates an ECM command for a temporary lean mixture correction.

**O2 CORR(CANP ACTIVATED)(%)** \_\_\_\_\_ (range: not available)

Indicates the required correction of the lambda figure when the canister purge system (CANP) is in operation. It shows the percentage the ECM needs to reduce or increase the amount of fuel delivery.

A number above 0% indicates an ECM command for a temporary rich mixture correction. A number below 0% indicates an ECM command for a temporary lean mixture correction.

**O2 CTRL(BANK 1)(%)**  
**O2 CTRL(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). It shows whether the ECM is commanding a rich or lean mixture.

**O2 CTRL & ACT(BANK 1)(%)**  
**O2 CTRL & ACT(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the overall operation and Long-term correction of fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). They show whether the ECM is commanding an overall rich or lean mixture. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction. These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values.

**O2 CTRL FACTOR(BANK 1)**  
**O2 CTRL FACTOR(BANK 2)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). It shows whether the ECM is commanding a rich or lean mixture. The number theoretically can range from 0.0 to 1.9 with 1.0 as the midpoint. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**Table 6-1** Normal ranges and factory names for O2 control factor parameters

| Factory Data Name  | Normal Value Working Range   |
|--|--|
| O2 SENSOR LAMBDA FACTOR  | Range: 0.5–1.5; Normal Value: 1.0 ±0.3 is base mid-point; For 2.8 (AAA) spec: 0.80–1.20  |
| O2 SENSOR LAMBDA FACTOR  | Range: 0.5–1.5; Normal Value: 1.0 ±0.3 is base mid-point   |
| LAMBDA FACT IDLE ADAPT; LAMBDA FACT PART ADAPT; LAMBDA FACT ADAPTMED/FULL LOAD | Range: 0.5–1.5; Normal Value: 1.0 ±0.3 (0.7–1.3) is base mid-point; For 2.0L (ABA) IDLE ADAPT: 0.87–1.2; For 2.8L (AAA) IDLE ADAPT: 0.53–1.47; Part Load: 0.80–1.20; Low Load: 0.53–1.47 |

**O2 CTRL FACTOR(CYL 1-3)(%)**

**O2 CTRL FACTOR(CYL 4-6)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of fuel delivery for cylinders 1 to 3 (Bank 1) or 4 to 6 (Bank 2). They show whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values.

**O2 CTRL READY** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda circuit is ready to reliably measure the exhaust oxygen content.

**O2 INTEGRATOR** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number can range from 0 to 255 with 128 as the midpoint. A number above 128 indicates that the ECM has commanded a temporary rich mixture correction. A number below 128 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**O2 LOOP CLOSED** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda regulation part of the ECM is in closed loop. This depends on the lambda sensor temperature and operating conditions of the engine. Under full load conditions, the ECM goes into open loop.

**O2 REGULATION** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint, but in practice the number only ranges from 0.9 to 1.1. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction.

These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**O2 REGULATION(%)****O2 REGULATION(BANK 1)(%)****O2 REGULATION(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction. A number below 0% indicates that the ECM has commanded a temporary lean mixture correction. These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**O2 REGULATION ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda regulation part of the ECM is active or not (open/closed loop). This depends on the lambda sensor temperature and operating conditions of the engine. Under full load conditions, the ECM goes into open loop.

**O2 REGULATION ON STOP** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda regulation part of the ECM is active or not (open/closed loop). This depends on the lambda sensor temperature and operating conditions of the engine. Under full load conditions, the ECM goes into open loop.

**O2 SENSOR(V)****O2 SENSOR 1(V)****O2 SENSOR 2(V)****O2 SENSOR(BANK 1)(V)****O2 SENSOR(BANK 1)(V)****O2 SENSOR(BANK 2)(V)****O2 SENSOR(BANK 2)(V)** \_\_\_\_\_ (range: not available)

Indicates oxygen sensor (O2S) voltage. The O2S is the primary sensor that indicates whether the engine is running rich or lean. An O2S can have a range of 0.0 to 1.0V or 0.0 to 5.0V.

O2 SENSOR 1 and O2 SENSOR 2 refer to cylinder Bank 1 or cylinder Bank 2 respectively.

The most common O2Ss generate a voltage signal that ranges from 0.0 to 1.0V. A high signal (0.48 to 1.00V) indicates a rich mixture; a low signal (0.0 to 0.48) indicates a lean mixture. In normal operation, the O2S voltage ranges from 0.1 to 1.0V. The O2S must be hot, and the ECM must be in closed loop before the ECM will respond to the sensor signal.

Some models, such as the VW 2001 2.0L with the AEG engine and the new 2002 Passat W8 (BDP), use a 0–5V O2S. Rich is high voltage; lean is low voltage. Other models may use a Linear Air/Fuel Ratio Sensor (A/F sensor) which measures the exact air/fuel mixture, the signal does not constantly switch between low and high. The voltage displayed (display group 33 in Table 6-2 below) for these is an ECM computed value where 1.5V = 1 lambda or the ideal fuel mixture ratio of 14.7:1. Higher voltage indicates correction for rich mixture and lower voltage indicates a correction for a lean mixture. Under normal load, the voltage should vary around 1.5V, which means the mixture is right at stoichiometric or Lambda = 1. During deceleration from 3000 RPM,

the mixture is lean and the voltage should go higher than 1.5V. Under full load acceleration, the mixture is rich and the signal should go low, 1V or lower.

**Table 6-2** Display group 33

| Display Group | Sensor                             | Bank 1, Sensor 1  | Bank 1, Sensor 2                                    | Bank 2, Sensor 1  | Bank 2, Sensor 2                                    |
|---------------|------------------------------------|-------------------|---|-------------------|---|
| 33            | Linear oxygen sensor control value | Control value (%) | Sensor voltage before CAT of a broadband sensor (V) | Control value (%) | Sensor voltage before CAT of a broadband sensor (V) |

**O2 SENSOR HEATER** \_\_\_\_\_ (range: ON/OFF)

Indicates whether the preheating of the O2 sensor is ON or OFF.

**O2 SENSOR HEATER(BK1-SNS1)** \_\_\_\_\_ (range: ON/OFF)

Indicates if the before CAT O2S on Bank 1 heater is turned on.

**O2 SENSOR HEATER(BK1-SNS2)** \_\_\_\_\_ (range: ON/OFF)

Indicates if the before CAT O2S on Bank 2 heater is turned on.

**O2 SENSOR HEATER(BK2-SNS1)** \_\_\_\_\_ (range: ON/OFF)

Indicates if the preheating of the after CAT O2S is ON or OFF (Bank 1).

**O2 SENSOR HEATER(BK2-SNS2)** \_\_\_\_\_ (range: ON/OFF)

Indicates if the preheating of the after CAT O2S is ON or OFF (Bank 2).

**O2 SENSOR HEATER AFTER CAT** \_\_\_\_\_ (range: ON/OFF)

Indicates if the preheating of the after CAT O2S is ON or OFF.

**O2 SENSOR HEATER BEFORE CAT** \_\_\_\_\_ (range: ON/OFF)

Indicates if the preheating of the before CAT O2S is ON or OFF.

**O2 SENSOR READY** \_\_\_\_\_ (range: YES/NO)

Indicates whether the lambda regulation part of the ECM is ready or not (open/closed loop). This depends on the lambda sensor temperature and operating conditions of the engine. Under full load conditions, the ECM goes into open loop.

**O2 VALUE** \_\_\_\_\_ (range: not available)

Indicates the operation and short term correction of the fuel delivery. It shows whether the ECM is commanding a rich or lean mixture.

The number theoretically can range from 0.00 to 1.99 with 1.00 as the midpoint. A number above 1.0 indicates that the ECM has commanded a temporary rich mixture correction. A number below 1.0 indicates that the ECM has commanded a temporary lean mixture correction.

These short term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**O2 VALUE(ACTUAL)(%)**

**O2 VALUE(BANK 1)(%)**

**O2 VALUE(BANK 2)(%)** \_\_\_\_\_ (range: not available)

Indicates the operation and Short-term correction of the fuel delivery for the stated cylinders. They show whether the ECM is commanding a rich or lean mixture.

A number above 0% indicates that the ECM has commanded a temporary rich mixture correction.

A number below 0% indicates that the ECM has commanded a temporary lean mixture correction.



These Short-term correction numbers are also used by the ECM to learn a fuel correction pattern or trend and are stored in the learned mixture or lambda values. Fuel correction operates only in closed loop. In open loop, a fixed value displays.

**OIL TEMPERATURE(°C/°F)** \_\_\_\_\_ (range: not available)  
Indicates engine oil temperature in degrees.

**OPERATING MODE** \_\_\_\_\_ (range: not available)  
Indicates the current operating mode of the engine system.

**OVERRUN** \_\_\_\_\_ (range: YES/NO)  
Indicates whether the current engine operating condition is overrun.

**PARK/NEUTRAL POSITION** \_\_\_\_\_ (range: P-N/-R-DL)  
Indicates whether an automatic transmission is in park or neutral, or in one of the drive ranges. It should read: P-N if the transmission is in either park or neutral R-DL if the transmission is in any forward gear or in reverse.

**PARK/NEUTRAL POSITION** \_\_\_\_\_ (range: P/N /NOT P/N)  
Indicates whether an automatic transmission is in park or neutral (reads P/N), or in one of the drive ranges (reads NOT P/N).

**PART LOAD DETECTED** \_\_\_\_\_ (range: YES/NO)  
Indicates whether the ECM has determined that the engine is currently at part load. It is used during some adaptive learning processes.

**PHASE POSITION BK1(°CA)**  
**PHASE POSITION BK2(°CA)** \_\_\_\_\_ (range: not available)  
Indicates the position of the camshaft of Bank 1 or 2 in degrees.

**PHASE POSITION HALL SNS(°)** \_\_\_\_\_ (range: not available)  
Indicates the position of the Hall-effect sensor in degrees.

**PRESS CNTRL(%)** \_\_\_\_\_ (range: not available)  
Indicates the duty cycle of the pressure control valve of the fuel pump.

**REAR HEATER MODE**  
**REAR HEATER SWITCH** \_\_\_\_\_ (range: ON/OFF)  
Indicates the feedback signal from the Heated Rear Screen switch.

**REDUCTION TORQUE(ACTUAL)(Nm)**  
Indicates the actual torque output after reductions (flywheel torque). Torque reductions are made by retarding the ignition point or by briefly switching off the fuel injectors.

**RELATIVE AIR MASS(%)** \_\_\_\_\_ (range: not available)  
Indicates the relative air mass in percentage.

**RETARDED IGNITION POINT** \_\_\_\_\_ (range: YES/NO)  
Indicates whether the ignition retard is active by, for example, the knock control system.

**RETARDED IGNITION POINT(°)** \_\_\_\_\_ (range: not available)  
Indicates the amount of ignition timing retard in degrees that is required to enable smooth gear changes on an automatic transmission system.

**RETARDING STEPS** \_\_\_\_\_ (range: not available)  
Indicates the torque reduction steps being currently applied by the traction control system.

**RTD SIGNAL A/T ACTIVE** \_\_\_\_\_ (range: YES/NO)

Indicates whether the automatic transmission (A/T) retard is active. With the vehicle stationary and signal inactive (NO), A/T has R selected and with the signal active (YES), A/T has 2, 3, D, P or N selected.

With the vehicle moving (above 10 MPH or 14 KM/H) and the signal inactive (NO), ignition timing retardation for A/T downshift is selected and with the signal active (YES), ignition timing retardation for A/T upshift is selected.

**SECONDARY AIR MASS(g/s)** \_\_\_\_\_ (range: not available)

Indicates the amount of output air from the secondary air pump in grams per second.

**SIGNAL FROM A/T** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is receiving a signal from the automatic transmission.

**SLIDE VALVE SENSOR(MAX)(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage feedback signal used by the ECM to determine the injection pump governor maximum voltage (start position) and is used during start up.

**SLIDE VALVE SENSOR(MIN)(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage feedback signal used by the ECM to determine the injection pump governor minimum voltage (stop position) and is used before start up.

**START OF DELIVERY(°)** \_\_\_\_\_ (range: not available)

Indicates the commencement of injection point that the ECM commands. The figure is degrees of crankshaft angle and can be + for BTDC or - for ATDC.

**START OF DELIVERY(ACTUAL)(°)** \_\_\_\_\_ (range: not available)

Indicates the actual commencement of injection. The figure is degrees of crankshaft angle and can be + for BTDC or - for ATDC. The signal is from the injector pump cam ring position sensor.

**START OF DELIVERY(DESIRED)(°)** \_\_\_\_\_ (range: not available)

Indicates the desired commencement of injection point. The figure is degrees of crankshaft angle and can be + for BTDC or - for ATDC.

**START SYNCHRONIZATION(°)** \_\_\_\_\_ (range: not available)

Indicates the start synchronization in degrees.

**STATUS FUEL COOLING(%)** \_\_\_\_\_ (range: not available)

Indicates the percentage that the fuel is cooled.

**SUM MISFIRES** \_\_\_\_\_ (range: not available)

Indicates the total amount of misfires detected.

**TEETH COUNT TILL HALL-SIG SHIFT +TO -** \_\_\_\_\_ (range: not available)

Indicates the number of teeth on the crankshaft sender wheel until the Hall-effect sensor on the camshaft switches the polarity of the sensor from positive (+) to negative (-). This is so the ECM knows the difference between compression stroke and exhaust stroke.

**THR ADJ SENSOR, MAX LRN OK/EXEC** \_\_\_\_\_ (range: YES/NO)

Indicates the current state of the learning process for the TP sensor maximum position stop.

**THR ADJ SENSOR, MIN LRN OK/EXEC** \_\_\_\_\_ (range: YES/NO)

Indicates the current state of the learning process for the TP sensor minimum position stop.

**THR ADJ/TPS BALANCE OK/EXEC** \_\_\_\_\_ (range: YES/NO)

Indicates if the signal from the throttle position (TP) sensor is equalized to the signal from the throttle stop position sensor. (The ECM recognizes both signals as being the same.)

**THR ADJUSTER(LIMP)(%)**

**THR POS SENSOR(AV)(LIMP)(V)** \_\_\_\_\_ (range: not available)

Indicates the signal used by the ECM to set the throttle valve adjuster average voltage when in limp home mode. Reading may be as a percentage of opening or voltage.

**THR POS SENSOR(THR STOP)(V)** \_\_\_\_\_ (range: not available)

Indicates the signal voltage of the throttle position sensor at idle.

**THR VALVE ADJUSTER ANGLE(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage signal from the throttle adjuster potentiometer (throttle position).

**THR VALVE ANGLE(ABSOLUTE)(°)** \_\_\_\_\_ (range: not available)

Indicates the actual throttle valve angle.

**THR VALVE ANGLE(LEARN)(°)** \_\_\_\_\_ (range: not available)

Indicates the learned throttle valve angle when the idle switch is closed or when the throttle is slightly open.

**THROTTLE ADJUSTER MODE** \_\_\_\_\_ (range: IDLING/PART TRHROTTL)

Indicates the current throttle adjuster mode.

**THROTTLE POSITION(IDLE)(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from the throttle position sensor at idle.

**THROTTLE POSITION SENSOR(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from the throttle position sensor. The throttle position (TP) sensor produces a voltage signal proportional to the throttle position. The signal tells the ECM how wide the throttle is open: low voltage at closed throttle, high voltage at WOT.

The full range of the TP sensor voltage readings available to the ECM is 0 to approximately 5.1 V.

A typical TP sensor voltage range might be approximately 0.5 V at idle to 4.5 V at WOT.

**THROTTLE VALVE ADJUSTER(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from the throttle position sensor. The throttle position (TP) sensor produces a voltage signal proportional to the throttle position.

**THROTTLE VALVE ADJUSTER ANGLE(°)** \_\_\_\_\_ (range: not available)

Indicates the position in degrees that the throttle returns to when the accelerator is released.

**THROTTLE VALVE ADJUSTER MAX(V)**

**THROTTLE VALVE ADJUSTER MAX(%)**

**THROTTLE VALVE ADJUSTER MIN(V)**

**THROTTLE VALVE ADJUSTER MIN(%)** \_\_\_\_\_ (range: not available)

Indicates the throttle valve adjuster maximum position.

**THROTTLE VALVE ANGLE(°)** \_\_\_\_\_ (range: not available)

Indicates the ECM calculated amount of throttle opening in degrees.

**THROTTLE VALVE CLOSED** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has detected the throttle valve is closed or open. This value is used in conjunction with other parameters when the ECM is applying learned idle values.

**THROTTLE VALVE POSITION(%)** \_\_\_\_\_ (range: not available)

Indicates the amount of throttle opening as a percentage.

**THROTTLE VALVE POSITION 1(%)**  
**THROTTLE VALVE POSITION 1(°)**  
**THROTTLE VALVE POSITION 2(%)**  
**THROTTLE VALVE POSITION 2(°)** \_\_\_\_\_ (range: not available)

Indicates the position of the throttle valve on Banks 1 and 2.

**TIME COUNTER(O2)** \_\_\_\_\_ (range: not available)

Indicates a time counter that starts counting upwards when the diagnosis conditions for EGR are met and counts backwards when the diagnosis conditions for EGR are not met.

**TIME COUNTER 1** \_\_\_\_\_ (range: not available)

Indicates a time counter that starts counting upwards when the diagnosis conditions for the EGR are met and counts backwards when the diagnosis conditions for the EGR are not met. Time counter 1 is increased by 1 when counter 2 reaches the value of 255. This value is only valid if the vehicle has an EGR system. If no EGR, then 0 will be displayed.

**TIME COUNTER 2** \_\_\_\_\_ (range: not available)

Indicates a time counter that starts counting upwards when the diagnosis conditions for the EGR are met and counts backwards when the diagnosis conditions for the EGR are not met. Time counter 2 is increased by 1 when counter 1 reaches the value of 255. This value is only valid if the vehicle has an EGR system. If no EGR, then 0 will be displayed.

**TORQUE (ACTUAL)(Nm)** \_\_\_\_\_ (range: not available)

Indicates the actual torque output after reductions (flywheel torque).

**TORQUE(DESIREDD)(Nm)** \_\_\_\_\_ (range: not available)

Indicates the actual torque output before reductions (flywheel torque).

**TORQUE(DESIREDD, BY A/T-ECU)(Nm)**

**TORQUE FROM A/T(Nm)** \_\_\_\_\_ (range: not available)

Indicates the maximum torque output before reductions (flywheel torque) that the automatic transmission can use for smooth gear change.

**TORQUE FROM ENGINE(Nm)** \_\_\_\_\_ (range: not available)

Indicates the amount of torque the engine produces, it is used when gear changes are made.

**TORQUE REDUCTION(Nm)**

**TORQUE REDUCTION** \_\_\_\_\_ (range: ACTIVE/NOT ACTIVE)

Indicates the amount of torque the engine produces, it is used when gear changes are made.

**TPS FULL RANGE(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from throttle position (TP) sensor full range potentiometer. This is one of two potentiometers incorporated into one TP sensor unit. The signal is for the whole range (from idle to full throttle).

**TPS LOW RANGE(V)** \_\_\_\_\_ (range: not available)

Indicates the voltage from throttle position (TP) sensor low range potentiometer. This is one of two potentiometers incorporated into one TP sensor unit. The signal is for the whole range (from idle to full throttle).

**TPS, MAX LRN OK/EXEC** \_\_\_\_\_ (range: YES/NO)

Indicates the current state of the learning process for the TP sensor maximum position stop.

**TPS, MIN LRN OK/EXEC** \_\_\_\_\_ (range: YES/NO)

Indicates the current state of the learning process for the TP sensor minimum position stop.

**TROUBLE CODE STORED IN MEMORY** \_\_\_\_\_ (range: YES/NO)

Indicates whether the self diagnostic system has detected a fault. It reads YES if a fault is detected and reads NO at all other times.

**UNPLAUSIBLE SIGNAL THR ADJ** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM can reconcile the relationship between the throttle position sensor and the throttle stop position sensor.

**VEHICLE SPEED** \_\_\_\_\_ (range: not available)

Indicates vehicle speed, which is calculated by the ECM based on the vehicle speed sensor (VSS) pulses. The ECM uses vehicle speed primarily for torque converter clutch engagement, although it also is an important value for electronic cruise control systems.

This induction sensor detects the information regarding vehicle speed by means of the pulse rotor at the input gear. This information is used for the decision as to which gear should be engaged, cruise control system and torque converter slip control.

**NOTE:**

If signal fails, the control unit uses the engine speed as a substitute signal and the lockup clutch is no longer closed.

**VEHICLE SPEED CTRL** \_\_\_\_\_ (range: TACHO/SPEEDO)

Indicates whether a speedometer or a speed recorder (tachograph) is fitted to the vehicle.

**VOLTAGE THR ADJ OUT OF RANGE** \_\_\_\_\_ (range: YES/NO)

Indicates that ECM can not reconcile the relationship between the throttle position sensor and the throttle stop position sensor.

**WARM UP CAT** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM is operating in warm up CAT mode. Warm-up is achieved by retarding the ignition point to after TDC and enriching the mixture.

**WARM UP CAT(%)** \_\_\_\_\_ (range: not available)

Indicates whether the ECM is allowing extra fuel into the CAT to speed warm-up. Warm-up is achieved by retarding the ignition point to AFTER TDC and enriching the mixture.

**WARN. SIGNAL INSTR. PANEL: REFUEL** \_\_\_\_\_ (range: not available)

Indicates whether the fuel level is low or not.

## 6.3 Diesel Engine Parameters

Volkswagen Turbo Direct Injection (TDI) diesel came out in 1996. Previous ECO and Umwelt diesel engines were not electronically-controlled. The control system has more than 25 performance maps and characteristic curves for all possible performance variations based on torque, fuel consumption, and emissions.

**ACCELERATOR PEDAL POSITION(%)** \_\_\_\_\_ (range: not available)

Indicates accelerator pedal position (APP). The APP sensor is one of the main inputs for determining fuel quantity. The APP sensor is a potentiometer that contains an idle switch and a kickdown switch. With failure, the engine runs at fast idle.

**BATTERY VOLTAGE BELOW 9V** \_\_\_\_\_ (range: YES/NO)

Indicates whether the ECM has recognized a battery voltage below 9V and is used by the glow plug start system.

**BOOST PRESSURE(DESIRED)(mbar)**

**BOOST PRESSURE(ACTUAL)(mbar)**

**INTAKE AIR TEMPERATURE(°)** \_\_\_\_\_ (range: not available)

Indicates intake air pressure and temperature based on the MAP sensor and IAT sensor signals. Both sensors are combined in the intake air duct between the charge cooler and intake manifold and are used to calculate intake air density and turbocharger boost pressure. Atmospheric pressure at sea level = 1000 millibar; boost pressure increases to a positive pressure above atmospheric. Desired and actual should read fairly close to each other.

**COOLANT TEMPERATURE(°)** \_\_\_\_\_ (range: not available)

Indicates temperature based on the signal of the engine coolant temperature (ECT) sensor, which is the main input for determining fuel quantity and injector timing based on engine temperature. If ECT fails, the ECM substitutes the value from the Fuel Temperature Sensor.

**COOLANT/AIRTMP SNS DEFECT** \_\_\_\_\_ (range: YES/NO)

Indicates whether a fault has been recognized in the coolant or air temperature systems and is used by the glow plug start system.

**COOLANT TMP >70°C/OR AIR TEMP >5°C** \_\_\_\_\_ (range: YES/NO)

Indicates whether the coolant or air temperature are above the set temperatures and is used by the glow plug start system. (range: not available)

**ENGINE CRANKED IN LAST 10S** \_\_\_\_\_ (range: YES/NO)

Indicates whether the engine has been cranked in the last 10 seconds and is used by the glow plug start system.

**ENGINE SPEED(RPM)** \_\_\_\_\_ (range: not available)

Indicates engine speed based on the signal from the RPM sensor, which supplies a Top Dead Center signal for each cylinder. If this sensor fails, the engine will not run.

**FUEL CONS. AUX HEATER(l/h)** \_\_\_\_\_ (range: not available)

Indicates the amount of fuel that is used by the external heater.

**FUEL CONSUMPTION(l/h)** \_\_\_\_\_ (range: not available)

Indicates fuel consumption (as calculated by the ECM) in liters per hour.

**FUEL CONSUMPTION ISC(g/s)** \_\_\_\_\_ (range: not available)

Indicates the calculated fuel usage adaptation by the idle stabilization control unit. Value is in grams per second.

**FUEL TEMPERATURE(°)** \_\_\_\_\_ (range: not available)

Indicates the reading from the fuel temperature sensor. Fuel quantity calculation requires coolant temperature and fuel density. Uses substituted values in the event of sensor failure.

**GLOW(s)** \_\_\_\_\_ (range: not available)

Indicates the time in seconds the glow plug start system is active.

**GLOW TIME(s)** \_\_\_\_\_ (range: not available)

Indicates the time in seconds the glow plug start system is active.

**INJ DIFF CYL 1 TO AVERAGE(mg/S)**

**INJ DIFF CYL 2 TO AVERAGE(mg/S)**

**INJ DIFF CYL 3 TO AVERAGE(mg/S)**

**INJ DIFF CYL 4 TO AVERAGE(mg/S)** \_\_\_\_\_ (range: not available)

TDI Diesels are equipped with an Idle speed smooth running control system. To smooth out power differences between individual cylinders, the identified cylinder is given more (+x.xx mg/S) or less fuel (-x.xx mg/S), until the engine runs evenly again. Individual cylinder power output is compared to being more or less powerful than the number 3 cylinder.

**INJ DIFF CYL 1 TO 3(mg/S)**

**INJ DIFF CYL 1 TO 4(mg/S)**

**INJ DIFF CYL 1 TO 5(mg/S)**

**INJ DIFF CYL 2 TO 3(mg/S)**

**INJ DIFF CYL 2 TO 4(mg/S)**

**INJ DIFF CYL 2 TO 5(mg/S)**

**INJ DIFF CYL 3 TO 4(mg/S)**

**INJ DIFF CYL 3 TO 5(mg/S)**

**INJ DIFF CYL 4 TO 3(mg/S)**

**INJ DIFF CYL 4 TO 5(mg/S)**

**INJ DIFF CYL 5 TO 3(mg/S)**

**INJ DIFF CYL 5 TO 4(mg/S)**

**INJ DIFF CYL 6 TO 3(mg/S)** \_\_\_\_\_ (range: not available)

Indicates the difference of fuel injected in milligrams per stroke between the two identified cylinders.

**INJ QUANTITY(mg/S)** \_\_\_\_\_ (range: not available)

Indicates the quantity of fuel that has been injected under the present operating conditions. The value is in milligrams per cylinder stroke.

**INJ QUANTITY(DESIRED)(mg/S)**

Indicates the maximum quantity of fuel that can be injected under the present operating conditions after all corrections are applied. The value is in milligrams per cylinder stroke.

**INJ QUANTITY(DRIVER)(mg/S)**

**INJ QUANTITY(TORQUE)(mg/S)**

**INJ QUANTITY(SMOKE)(mg/S)**

**INJ QUANTITY(CRUISE)(mg/S)** \_\_\_\_\_ (range: not available)

Indicates injection quantity based on the driver's requirement, injection quantity limited according to specific RPM/torque limitation, injection quantity limited for smoke prevention, and injection quantity with cruise control system activated, respectively. DRIVER is the APP sensor input from the driver commanding more or less fuel. TORQUE is the RPM/load restrictions (torque) placed on the engine influencing fuel demand. SMOKE is a calculation from the Smoke Map to ensure fuel quantity does not exceed a preset amount to prevent black smoke. CRUISE calculation is from various inputs indicating engine fuel delivery for cruise conditions.

**INJ QUANTITY(TCS)(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the maximum quantity of fuel that can be injected under the present operating conditions with regards to the Traction Control System (TCS) map. The value is in milligrams per cylinder stroke.

**INJ QUANTITY(TORQUE A/T)(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the maximum quantity of fuel that can be injected under the present operating conditions, limited by the automatic transmission during gear change. The value is in milligrams per cylinder stroke.

**MAF 1(mg/S)****MAF 2(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the amount of air measured by the manifold airflow sensor in cylinder banks 1 and 2.

**MAF DES(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the desired amount of airflow calculated by the ECM.

**MASS AIR FLOW(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the amount of air drawn into the engine under the present operating conditions. The value is in milligrams per cylinder stroke. The figure is only valid while the EGR is active.

**MASS AIR FLOW(DESIRED)(ms/S)****MASS AIR FLOW(ACTUAL)(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the desired and actual reading of the MAF sensor. The MAF sensor uses Reverse Flow detection using two temperature sensors to measure intake air flow upstream and downstream of a heating element. The downstream sensor will measure higher temperature because the air is warmed as it passes the heating element. Change in temperature signals the ECM to factor out the reverse flow. Uses substitute values if sensor fails. The fixed value may result in part throttle performance problems. Normal value range for Mass Air Flow at idle is 230 to 370 (mg/S). Mass Air Flow desired and actual should read fairly close to each other.

**REL.HEAT HIGH****REL.HEAT LOW \_\_\_\_\_ (range: YES/NO)**

Indicates whether the coolant or air temperature is above or below the set temperatures and is used by the glow plug start system.

**RELAY HEATER HIGH****RELAY HEATER LOW \_\_\_\_\_ (range: ON/OFF)**

Indicates the current output state of the glow plug start system relay circuits.

**SLIDE VALVE SENSOR(V)**

Indicates the voltage of the modulating piston replacement sensor. Part of the Injection Pump, the Quantity adjuster regulates the quantity of fuel injected; an electromagnetic swivelling positioner, ECM duty cycle controlled. The rotational angle of an eccentric shaft attached to the quantity adjuster is measured by the modulating piston displacement sensor (slide valve sensor) The sensor variable voltage directly correlates to how much fuel is delivered. Normal range is 1.45 to 2.0 V. Below 1.450 V, mixture is too rich; Above 2.0 V, mixture is too lean.

Slide Valve Sensor Min. V range is 0.500 to 0.970 V. Slide Valve Sensor Max V range is 4.150 to 4.740 V.



**START OF DELIVERY(DESIRED)****START OF DELIVERY(ACTUAL)****DC(DUTY CYCLE)START OF DELIVERY \_\_\_\_\_ (range: not available)**

Injector #3 is equipped with a Needle Lift Sensor to detect the start of injection. The sensor signals the actual opening time of the injector which acts as ECM feedback to confirm that the proper map for start of injection. The ECM calculates the start of injection from the time difference between the needle lift sensor and the TDC signal input from the RPM sensor. This is compared to a programmed map (DESIRED vs. ACTUAL) and corrected to the specified value if they differ.

Normal values for START OF DELIVERY (DESIRED) are 2° ATDC to 3 ° BTDC at idle. Normal values for START OF DELIVERY (ACTUAL) are 2° ATDC to 3° BTDC at idle and 8–14° at WOT (2900–3100 RPM).

DC (DUTY CYCLE) START OF DELIVERY (Cold Start Injector) controls the start of injection timing by regulating the pressure for the injection timing piston. The injection pump contains a mechanical injection timing device which requires engine speed dependent fuel pressure to advance or retard injection timing. The cold start injector is duty cycle controlled, precisely regulating the pressure to the timing piston. Normal range is 3 to 80% at idle and 70 to 95% at full throttle.

**START QUANTITY(mg/S) \_\_\_\_\_ (range: not available)**

Indicates the quantity of fuel that has to be injected under the present starting conditions because ECM input reading may not be correct under start conditions. The value is in milligrams per cylinder stroke.

## 6.4 Transmission Parameters

These parameters are ECM signals to and from various actuators and sensors in the transmission.

### **A/C KICKDOWN** \_\_\_\_\_ (range: ACTIVATED/NOT ACTIVATED)

Indicates the state of A/C (A/C). Only activated after the kickdown downshift. The TCM is linked to the switch unit for solenoid coupling in the event of a manual A/C, whereas it is connected to the A/C control module and indicating unit on vehicles with digital A/C.



#### **NOTE:**

Shifting down a gear with the kickdown switch actuated results in a brief disconnection of the A/C compressor for up to 8 seconds to provide more power on acceleration.

### **ACTUAL SELECTED GEAR** \_\_\_\_\_ (range: variable)

Indicates the TCM commanded gear. Vehicles with an electronic program switch in the TCM, the "ECO", or "Sport" program will be automatically selected by the TCM according to the speed at which the accelerator pedal is depressed. The displayed parameters are 1H, 2H, 3H, 4M. Vehicles with an electronic program in the transmission range program switch display parameters 1H, 2H, 3H, 3LT1, 3M, 3LT2, 4M. There are some transaxles that have the capability to display 1H, 1M, 2H, 2M, 3H, 3M, 4H, 4M, 5H, 5M. Different phases of this transaxle have a different shift solenoid firing order and may display parameters UNKNOWN.

- H = hydraulic (torque converter not locked up)
- M = mechanical (torque converter locked up)
- LT1 = load splitting (used momentarily for shift smoothness between 3H and 3M shift)
- LT2 = load splitting (used momentarily for shift smoothness between 3M and 4M shift)

LT1 and LT2 are used only with 095, 096, 097, and 098 phase 0 transmissions and may not be detected by the scan tool.

### **ACTUAL SOLENOID(A)** \_\_\_\_\_ (range: 0.0 to 1.1A)

Indicates the actual amperage of solenoid # 6 (EPC) timing valve and pressure regulation on 095, 096, 097, 098, 01M, 01N and 01P transmissions. Readings should be 0.0 (A) at WOT and 1.1 (A) at closed throttle. Actual solenoid (A) should read close to required solenoid (A).

### **A/T** \_\_\_\_\_ (range: YES/NO)

Indicates whether an automatic transmission is fitted.

### **A/T(RPM)**

### **A/T INPUT(RPM)** \_\_\_\_\_ (range: 0 to maximum RPM)

Indicates the transmission input shaft RPM.

**A/T INPUT(RPM)** \_\_\_\_\_ (range: 0 to maximum RPM)  
**01V**

Indicates transmission input speed.

**Table 6-3** *Transmission input speed*

| Gear                 | Rpm            |
|----------------------|----------------|
| R*                   | Approx. 0–10   |
| R                    | Approx. 0–2000 |
| 1M*                  | Approx. 0–10   |
| 1M, 1H               | Approx. 0–1200 |
| 2H                   | Approx. 0–4000 |
| 3H                   | Approx. 0–5800 |
| 4H                   | Approx. 0–8200 |
| 5H                   | Approx. 0–8200 |
| * Vehicle stationary |                |

**A/T INPUT(RPM)** \_\_\_\_\_ (range: 0 to 8200 RPM)  
**01N**

Indicates transmission input speed based on an input speed sensor that is positioned in the transmission housing. It detects the speed of the large sun wheel in the planetary gear so the control unit can accurately calculate reduction in engine torque during the gearshift by retarding the ignition angle to control the clutch and brake application during a shift.

**A/T OUTPUT(RPM)** \_\_\_\_\_ (range: 0 to maximum RPM)

Indicates transmission output shaft speed (OSS) based on the OSS sensor. The OSS sensor is on inductive pickup.

**A/T SWITCH** \_\_\_\_\_ (range: P/N /NOT P/N)

Indicates the Park/Neutral Position (PNP) switch status, which indicates whether an automatic transmission is in park or neutral, or in one of the drive ranges.

**ATF TEMPERATURE(°C)** \_\_\_\_\_ (range: variable)

Indicates the temperature of the transmission fluid based on the transmission fluid temperature (TFT) sensor. It is monitored to prevent the transmission from overheating. It is located on the valve body within the solenoid wiring harness.

**BATTERY VOLTAGE** \_\_\_\_\_ (range: 9.0 to 16.0 volts)

Indicates battery voltage on terminal 15 of the TCM on a 01V transmission. The TCM monitors battery voltage to make sure it can operate safely. The safe parameter is 10.8 to 16.0 volts.

**BRAKE LIGHT SWITCH** \_\_\_\_\_ (range: OPERATED/NOT OPERATED)

Indicates the state of brake switch. It reads OPERATED when the switch is on; and NOT OPERATED when the switch is off.

**ENGINE TORQUE(Nm)** \_\_\_\_\_ (range: variable)

Indicates the ECM calculated engine torque, which is based on the injection time and passed on to the TCM.

In the event of a faulty signal gear, selection is always implemented at maximum modulation pressure, emergency operation 1. Gear shifting is affected with a throttle-valve opening angle of 30%. There is no kickdown.

**ENGINE TORQUE MAX \_\_\_\_\_ (range: variable)**

Indicates the maximum engine torque that the TCM will allow on a 01V transmission. The TCM reduces engine torque required during shifts.

**GEAR POSITION \_\_\_\_\_ (range: variable)**

Indicates which gear the transmission is in.

**HILL FACTOR(%) \_\_\_\_\_ (range: 0 to 100%)**

Indicates the TCM calculation of driving conditions on 01M and 01N transmissions. When driving on level road (less than  $\pm 3\frac{1}{2}$  degrees), the TCM will function in economy mode. When there is road resistance, such as wind load, towing, increased vehicle load or uphill driving (more than  $3\frac{1}{2}$  degrees), shift points change to provide more engine RPM and power. When road resistance decreases, such as going downhill, the TCM automatically selects a suitable lower gear. Engine braking is provided with the selector lever in "D" and reduces the need for braking when driving downhill. When road resistance returns to normal, shifting characteristic also return to normal.

**KICKDOWN SWITCH \_\_\_\_\_ (range: ON/OFF)**

Indicates the state of the kickdown switch. The kickdown switch is integrated into the Bowden accelerator cable. It is used to detect situations where the accelerator pedal is depressed beyond the full-throttle point. With the kickdown switch actuated, the A/C compressor is disengaged to provide more power on acceleration.

**NOTE:**

On vehicles with a TDI engine, the TCM receives the kickdown signal from the acceleration pedal position (APP) sensor.

---

**KICKDOWN SWITCH \_\_\_\_\_ (range: ON/OFF)**

Indicates the state of the kickdown switch on 01M, 01F, and 01K transmissions. The kickdown switch is integrated into the Bowden accelerator cable. It is used to detect situations where the accelerator pedal is depressed beyond the full-throttle point.

**NOTE:**

On vehicles with a TDI engine, the TCM receives the kickdown signal from the APP sensor that is located in the bracket for the bell crank. It is an EDC sensor that supplies the kickdown signal on vehicles with TDI engines.

---

**LOCK-UP SLIP \_\_\_\_\_ (range: 0 to 99%)**

Indicates the amount of torque converter clutch regulated slip. It normally reads 0–30% slip when lockup occurs.

**LOCK-UP SLIP \_\_\_\_\_ (range: 0 to stall)**

Indicates condition of the torque converter lockup clutch on a 01V transmission. With the TCC solenoid in the open state, lockup slip, or torque converter slip speed should be between 0 RPM and stall speed. With the TCC solenoid in the control state, lockup slip speed should be 20 to 120 RPM (last gear shift at least 20 seconds ago). With the TCC solenoid in the closed state, lockup speed should be 0 to 10 RPM. Engine torque is mechanically transmitted to the transmission during torque converter lockup.

**LOCK-UP SLIP \_\_\_\_\_ (range: 0 to stall)**

Indicates torque converter lockup slip on a 01P transmission. When in the hydraulic gears, the torque converter lockup must be open with 0 to stall RPM slip. With engine speed 2000–3000

RPM in the mechanical gears, gear completed, the torque converter lockup clutch must be closed and the accelerator pedal value held constant with 0 to 130 RPM slip.

**PRESSURE CTRL(A)** \_\_\_\_\_ (range: variable)

Indicates the pressure control amperage of the #4 solenoid. It controls the pressure for actuation of shift elements (modulation pressure) as a function of engine speed, engine torque, and transmission oil temperature.

**REQUIRED SOLENOID(A)** \_\_\_\_\_ (range: 0.0 to 1.0A)

Indicates the specified current the TCM would like to see through solenoid A, which is the electronic pressure control (EPC) solenoid, on 095, 096, 097, 098, 01M, 01N, and 01P transmissions. It should read 0.0 at WOT and 1.0 at closed throttle. This value should closely match Actual solenoid (A). Code set if actual and required vary by 0.050 A or more.

**REQUIRED SOLENOID #4**

**REQUIRED SOLENOID #5**

**REQUIRED SOLENOID #6**

**REQUIRED SOLENOID #7** \_\_\_\_\_ (range: 0.0 to 1.0A)

Indicates the specified current the TCM would like to see through solenoids #4, 5, 6, and 7 on a 01V transmission. It should read 0.0 at WOT and 1.0 at closed throttle. This value should closely match Actual solenoid (A). Code set if actual and required vary by 0.050 A or more.

**Table 6-4** Shift element positions—01V transmission

| Gear          | 1-N88 | 2-N89 | 3-N90 | 4-N91 | 5-N92 | 6-N93 | 7-N94 |
|---------------|-------|-------|-------|-------|-------|-------|-------|
| Reverse       | *     |       |       | *     |       | *     |       |
| Neutral       | *     | *     |       | *     |       | *     |       |
| D, 1st        | *     | *     |       | *     |       | *     |       |
| D, 2nd        | *     | *     |       | *     | *     | *     |       |
| D, 3rd        |       | *     | *_*   | *     | *     |       |       |
| D, 4th        |       |       | *_*   | *     |       |       |       |
| D, 5th        | *     |       | *_*   | *     | *     |       |       |
| 2, 1st        | *     |       |       | *     |       | *     |       |
| D, 5th to 4th | *     |       | *     | *     | *     |       | *     |

\* = Component is actuated, - = Component is not actuated

**SHIFT LEVER LOCK** \_\_\_\_\_ (range: not available)

Indicates the status of the shift lever lock. It prevents involuntary movement of the selector lever positions P and N if the brake pedal is not depressed.

**SOLENOID #1**

**SOLENOID #2**

**SOLENOID #3**

**SOLENOID #4**

**SOLENOID #5**

**SOLENOID #7** \_\_\_\_\_ (range: ACT/N.ACT)

Indicates the state of the shift solenoids, and should read ACT (active) when the solenoid is on, and N.ACT (not active) when the solenoid is off.

For 01F and 01K transmissions, the solenoid valves #1 and #2 govern the selection of various gears in line with actuation by TCM. Solenoid valve #3 creates the necessary prerequisites (pressure) for proper switching of the solenoid valves #1, #2 while driving.

**Table 6-5** Solenoid valve activation—01F and 01K transmissions

| Gear   | Sv 1 (n88) | Sv 2 (n89) | Sv 3 (N90) |
|--|------------|------------|------------|
| Park   | N.ACT      | ACT        | ACT        |
| Reverse  | N.ACT      | N.ACT      | N.ACT      |
| Neutral  | N.ACT      | ACT        | ACT        |
| First  | N.ACT      | ACT        | N.ACT      |
| Second   | ACT        | ACT        | N.ACT      |
| Third  | ACT        | N.ACT      | N.ACT      |
| Fourth   | N.ACT      | N.ACT      | N.ACT      |
| 3-4*   |            |            | ACT        |
| * Brief actuation on shifting from 3rd/4th gear. |            |            |            |



**NOTE:**

Solenoid #4 is timing valve and is responsible for pressure regulation (See “PRESSURE CTRL(A)” on page 142).

For 095, 096, 097, and 098 transmissions, the solenoid valves #1, #2, #3, and #4 govern the selection of various gears in line with actuation by the TCM. Solenoid valves #5 and #7 create the necessary prerequisites (pressure) for proper clutch apply and release.

**Table 6-6** Solenoid valve activation—095, 096, 097, and 098 transmissions

| Gear   | Solenoid #1 | Solenoid #2 | Solenoid #3 | Solenoid #4 |
|--|-------------|-------------|-------------|-------------|
| Drive 1st  |             |             |             | ACT         |
| Drive 2nd  |             | ACT         |             | ACT         |
| D 3rd H  |             |             |             |             |
| D 3rd LT1*   |             |             | ACT         | ACT         |
| D 3rd M*   |             |             | ACT         |             |
| D 3rd LT2*   | ACT         |             | ACT         |             |
| D 4th M  | ACT         | ACT         | ACT         | ACT         |
| Reverse  |             |             |             |             |
| H = hydraulic, M = mechanical, LT1 & LT2 = load splitting  |             |             |             |             |
| * LT1, D3M, and LT2 are only used with phase 0 transmissions. Also, LT1 and LT2 are momentary TCM commands and may not be detected by the scan tool. |             |             |             |             |



**NOTE:**

Solenoid #6 is timing valve and is responsible for pressure regulation (See “ACTUAL SOLENOID(A)” on page 139).

Solenoid #4 becomes TCC activation with phase 2.

For 01M, 01N, and 01P transmissions, the solenoid valves #1, #2, and #3 govern the selection of various gears in line with actuation by the TCM. Solenoid valves #5 and #7 create the necessary prerequisites (pressure) for proper clutch apply and release.

**Table 6-7** Solenoid valve activation—01M, 01N, and 01P transmissions

| Gear           | Solenoid #1 | Solenoid #2 | Solenoid #3 | Solenoid #4 | Solenoid #5 | Solenoid #7 |
|----------------|-------------|-------------|-------------|-------------|-------------|-------------|
| P              | ACT         |             | ACT         |             |             |             |
| R              | ACT         |             | ACT         |             |             |             |
| R <sup>1</sup> |             |             | ACT         |             |             |             |
| N              | ACT         |             | ACT         |             |             |             |
| D 1            |             |             | ACT         |             | X           |             |
| D 2 H          |             | ACT         | ACT         |             |             |             |
| D 2 M          |             | ACT         | ACT         | ACT         |             |             |
| D 3 H          |             |             |             |             |             | ACT         |
| D 3 M          |             |             |             |             |             | ACT         |
| D 4 H          | ACT         | ACT         |             |             |             | ACT         |
| D 4 M          | ACT         | ACT         |             |             |             | ACT         |

X = variable switching condition, H = hydraulic, M = mechanical, <sup>1</sup> = Vehicle stationary,

**NOTE:**



Solenoid #4 is a modulation type for torque converter lockup that does not read amps. This solenoid shows ACT or N.ACT. To look at how much modulation is taken place, see “LOCK-UP SLIP” on page 141.

Solenoid #6 is timing valve and is responsible for pressure regulation. See “ACTUAL SOLENOID(A)” on page 139.

**SPORT FACTOR(%)** \_\_\_\_\_ (range: 0 to 100%)

Indicates the percentage of sport driving on a 01N transmission. High values move the shift points to higher speeds.

**TCS STATUS** \_\_\_\_\_ (range: TCS ACTIVE)

Indicates the traction control system (TCS) status on a 01V transmission. When TCS ACTIVE displays, traction control is activated from TCS control module. When the display is blank, the traction control system is not activated.

**THROTTLE VALVE POSITION** \_\_\_\_\_ (range: 0 to 100%)

Indicates the accelerator pedal position (APP). The readout constantly increases from closed throttle position to WOT.

**THROTTLE VALVE POSITION(V)** \_\_\_\_\_ (range: 0.156V to 4.680V)

Indicates the throttle valve position sensor voltage on a 01P transmission. When accelerating from idling to WOT, the voltage figure increases constantly. With the vehicle stationary, idling should be min. 0.165, max 0.8V, and WOT should read minimum 3.5 to maximum 4.680V.

**NOTE:**



Diesel engine voltage may differ slightly.

**TIPTRONIC**

Indicates the selected gear range of a Tiptronic transmission. Tiptronic transmissions have an additional selector gate on the right of the transmission shifter selector gate or steering wheel paddles. Tiptronic makes it possible to manually shift up a gear by moving the selector lever or steering wheel paddles to plus (+) or manually shift down a gear by moving the selector lever or steering wheel paddles to negative (-). This mode is for drivers who prefer manual gear shifting. The transmission will upshift automatically to prevent inadvertent over-revving of the engine. Also, the driver cannot downshift to a lower gear if the engine RPM would exceed red-line by downshifting. In addition, the transmission will downshift to first automatically when the vehicle comes to a stop, even if the driver does not remember to downshift. This transmission is designed to handle high torque output.

The left-hand gate is for electronically controlled automatic shifting with adaptive control. This is a function of various sensors and is transparent to the driver. Shift points are automatically regulated to provide three distinct operating characteristics:

- Comfort driving for maximum fuel economy (shift points are kept low).
- Average driving (shift points are raised slightly).
- High-performance driving (shift points are increased to allow the engine to rev higher between gearshifts).

**TIPTRONIC SWITCH** \_\_\_\_\_ (range: N/A (+) upshift (-) downshift)

Indicates the upshift (+) or downshift (-) position of the tiptronic shifter.

**TORQUE(Nm)** \_\_\_\_\_ (range: variable)

Indicates the torque of the TCM calculated by the ECM.

**TORQUE MAX(Nm)** \_\_\_\_\_ (range: 0 to maximum torque)

Indicates the maximum torque of the TCM calculated by the ECM.

**TORQUE RAISE** \_\_\_\_\_ (range: 1-2,17)

Indicates torque increase in the converter while driving on a 01V transmission. It is calculated by the TCM from torque converter slip speed.

**TORQUE REDUC** \_\_\_\_\_ (range: not available)

Indicates if there is a torque reduction or not.

**VEHICLE SPEED** \_\_\_\_\_ (range: 0 to maximum speed)

Indicates vehicle speed on 01F and 01K transmissions based on the vehicle speed sensor mounted in the transmission housing. This information is used for the decision as to which gear should be engaged, cruise control system and torque converter slip control.

**NOTE:**

If the signal fails, the control unit uses the engine speed as a substitute signal and lockup clutch is no longer closed.

**VEHICLE SPEED SENSOR(V)** \_\_\_\_\_ (range: 2.20 to 2.52V)

Indicates vehicle speed sensor voltage on 097, 01N and 098 transmissions. With the vehicle stationary, voltage should read 2.20 min. and 2.52 max.



---

**WHEEL LEFT FRONT(RPM)** \_\_\_\_\_ (range: 0 to vehicle speed)  
**WHEEL RIGHT FRONT(RPM)**  
**WHEEL RIGHT REAR(RPM)**  
**WHEEL LEFT REAR(RPM)**

Indicates vehicle speed from wheel speed sensor through the ABS controller on 018 and 01K transmissions. The ABS unit recognizes the wheel speeds from the signals provided by the speed sensors. These signals are passed from ABS control unit to the control unit for the automatic transmission. The TCM averages the 4 signals and detects output speed.



**NOTE:**

Should one wheel-speed signal fail, the transmission output speed is determined from the three remaining signals. The TCM switches to emergency operation 2 if more than one speed sensor signal fails.

---

## 6.5 Transmission Expert Mode Parameters

Expert Mode displays all data groups and on some models data may not be available, but still may show data in some form. Data is filtered in regulator data groups and should be verified before suspecting a scan tool or vehicle problem.

**Accelerator Pedal Value** \_\_\_\_\_ (range: 0 to 100%)

Indicates the accelerator pedal position (APP). When accelerating from idle to WOT, the accelerator pedal percentage should increase.

**Actual Engine Torque** \_\_\_\_\_ (range: variable)

Indicates actual engine torque. This 01V transmission parameter is viewed from Expert Mode in display group 009, display field 1. With the vehicle driven, the actual engine torque signal is passed from the engine control module (ECM) to the transmission control module (TCM) via CAN bus wiring.

**Adaptation of start-from-stop behavior forward** \_\_\_\_\_ (range: ADP OK/RUNNING)

This 01J transmission data parameter is viewed from Expert Mode in display group 010, display field 2. The parameter should read either ADP OK or RUNNING. ADP (“adaptation”) means adapting to an internal specified value. If the ADP value does not read OK with transmission fluid temperature higher than 140°F (60° C) and no codes in memory, drive forward briefly and then brake to a stop again. Repeat until the display reads ADP OK.

- Display field 3 is transaxle temperature.
- Display field 1 is adaptation of clutch curve forward and can be ignored.
- Display field 4 is specified clutch torque and can be ignored.

**Adaptation of start-from-stop characteristics Reverse** \_\_\_\_\_ (range: ADP OK/RUNNING)

This 01J transmission parameter is viewed from Expert Mode in display group 011, display field 2. The parameter should read either ADP OK or RUNNING. ADP (“adaptation”) means adapting to an internal specified value. If ADP value does not read OK, with transmission fluid temperature higher than 140°F (60°C) and no codes in memory, drive in reverse briefly and then brake to a stop again. Repeat until the display reads ADP OK.

- Display field 3 is transaxle temperature.
- Display field 1 is adaptation of clutch curve forward and can be ignored.
- Display field 4 is specified clutch torque and can be ignored.

**DRIVING SLIP CTRL** \_\_\_\_\_ (range: ACT/N.ACT)

Indicates whether the traction control system is activated (ACT) or not activated (N.ACT) on a 01M transmission.

**Dynamic Code Number** \_\_\_\_\_ (range: variable)

Indicates a code for the 01V transmission that can only be viewed from Expert Mode in display group 002, display field 1. This data group has five number sets to indicate vehicle characteristics and customer driving conditions. The first set of three numbers is determined by driving style and operating conditions (acceleration, accelerator pedal movement, speed, and load).

With normal driving conditions, a reading of 0 equals minimum value (very economic), 240 equals maximum value (very sporty). High values move shift points to higher engine speeds. The second set of three numbers indicated whether the warm-up program is active (min./max numbers are not available) and may read 241. The third set of three numbers determines whether the anti-slip regulation (ASR) is active and may read 242 (min./max numbers are not available). Shifting should be avoided whenever possible. The fourth set of three numbers determines whether the

tiptronic recognition is activated and may read 243 (min./max numbers are not available). The fifth set of three numbers indicates the cruise control system characteristic map and may read 244 (min./max numbers are not available). This parameter is only available for vehicles in the USA and may not be applicable on some models.

**FUEL CONSUMPTION SIGNAL** \_\_\_\_\_ (range: not available)

Indicates fuel consumption on a 01V transmission when viewed in Expert Mode display group 009, display field 4. Fuel consumption signal displays the injection period on vehicles equipped with a data bus. Injection period is read in milliseconds and varies by engine, speed, and load.

**GEAR SELECTED** \_\_\_\_\_ (range: 1H+/- to 4M +/-)

Indicates the current gear on 01M, 01N, and 01P transmissions when viewed in Expert Mode data group 007, display field 1. The + or – sign relates to the lockup slip of the torque converter clutch. A plus sign (“+”) indicates that the engine speed (pump speed) is greater than the turbine speed, and so the vehicle is under traction. A minus sign (“-”) indicates that the engine speed is less than the turbine speed, and so the vehicle in overrun.

**On-Board Diagnostic** \_\_\_\_\_ (range: 0 to 1)

Indicates the on-board diagnostic display information from left to right. This display group can be viewed in Expert Mode display group 004, display field 4. The display indicates malfunction (1 = switched on 0 = switched off), trip (1 = complete 0 = not complete), transmission warm-up (1 = complete 0 = not complete), engine start (1 = recognized 0 = not recognized).

**Overrun/engine pulling signal** \_\_\_\_\_ (range: overrun/engine pulling)

Indicates whether an 01V transmission is in overrun or normal mode when viewed from Expert Mode in display group 008, display field 4. If in overrun, the transaxle has engine braking. With no display normal driving, the engine is delivering power.

**SELECTOR OUTPUTS** \_\_\_\_\_ (range: 0 and 1)

Indicates engine management status (0 = turned off, 1 = turned on) on a 098 transmission when viewed from Expert Mode in display group 005, display field 2 (first set of binary numbers). The second set of numbers are unknown at this time. The third set of numbers are the shift lock solenoid (0 = turned off, 1 = turned on). The fourth set of numbers are unknown at this time. The fifth set of numbers are the cruise control (0 = turned off, 1 = turn on). The sixth set of numbers are the air conditioner (0 = turned off, 1 = on). The seventh set of numbers are the Park/Neutral signal selector lever (0 = 1, 2, 3, D; 1 = P, N).

**Torque converter lockup clutch** \_\_\_\_\_ (range: tcc open/tcc control/tcc closed)

Indicates the percentage of TCC solenoid activation on a 01V transmission when viewed from Expert Mode in display group 007, display field 3. When the parameter reads TCC OPEN, there is no torque converter clutch operation, with TCC CONTROL, the torque converter clutch is partially applied, with TCC CLOSED, the torque converter clutch is fully applied.

**Torque converter slip speed** \_\_\_\_\_ (range: 0 to stall speed)

Indicates the torque converter slip speed on a 01V transmission when viewed in Expert Mode in display group 007, display field 3, display fields 4.

## 6.6 ABS Parameters

**EDS CUT OFF** \_\_\_\_\_ (range: not available)

Indicates if the EDS fuel cut off is switched on or off.

**HANDBRAKE** \_\_\_\_\_ (range: not available)

Indicates if the handbrake is activated or not.

**POWER SUPPLY ECU(V)** \_\_\_\_\_ (range: not available)

Indicates the power supply of the ECM.

**ROTATIONAL SPEED(°/s)** \_\_\_\_\_ (range: not available)

Indicates the rotation speed of the steering wheel in degrees per second.

**STEERING ANGLE(°)** \_\_\_\_\_ (range: not available)

Indicates the position of the steering wheel in degrees.

**TCS SWITCH** \_\_\_\_\_ (range: ON/OFF)

Indicates a feedback signal from the Traction Control System (TCS) switch.

**TORQUE(%)** \_\_\_\_\_ (range: not available)

Indicates the total torque in percentage.

**TORQUE LOSS(Nm)** \_\_\_\_\_ (range: not available)

Indicates the total torque loss in the ABS system in Newton meters.

**TRANSVERSE ACCELERATION(m/s<sup>2</sup>)**

Indicates the transverse acceleration.

**WHEEL LEFT FRONT**

**WHEEL RIGHT FRONT**

**WHEEL LEFT REAR**

**WHEEL RIGHT REAR** \_\_\_\_\_ (range: not available)

Indicates wheel speed.

## A.1 Terms

The following terms are used throughout this manual to explain certain operations and displays:

|                   |   |
|-------------------|---|
| <b>blink code</b> | A type of vehicle control system that has no serial data. Any trouble codes the control system set are extracted either by flashing the malfunction indicator lamp (MIL) or using a special breakout box. |
| <b>bonnet</b>     | European for "hood."  |
| <b>code</b>       | A numerical code, generated by the vehicle control system to indicate a fault has occurred in a particular subsystem, circuit, or part.   |
| <b>cursor</b>     | The arrow that appears on menus and some other displays. In most displays, the cursor moves as you scroll.  |
| <b>fix</b>        | To lock a single line of the display in a fixed position on the screen to prevent it from scrolling. Data readings remain live while the parameter categories are fixed.                                  |
| <b>frame</b>      | One complete data package, or transmission cycle, from an electronic control module (ECM) that provides serial data of control system operating parameters.   |
| <b>hold</b>       | To capture and hold a single data frame for review or printing.   |
| <b>movie</b>      | A vehicle data record whose length depends on the number of selected data parameters.   |
| <b>menu</b>       | A list of vehicle tests or programs from which a selection can be made.   |
| <b>parameter</b>  | A measured value of control system input or output operation. Parameters include voltage signals, as well as temperature, pressure, speed, and other data.  |
| <b>release</b>    | To unlock a fixed line and allow it to scroll.  |
| <b>screen</b>     | Any given 4-line display.   |

## A.2 Acronyms

The following acronyms are used in diagnostic trouble code definitions displayed by the scan tool or used in this manual.

|            |                                  |
|------------|----------------------------------|
| <b>4WD</b> | 4 wheel drive                    |
| <b>ABS</b> | antilock brake system            |
| <b>A/C</b> | air conditioning                 |
| <b>AIR</b> | secondary Air Injection (OBD-II) |
| <b>APP</b> | accelerator pedal position       |

|             |  |
|-------------|--|
| <b>ASC</b>  | anti-spin control  |
| <b>ASR</b>  | anti-slip regulation   |
| <b>A/T</b>  | automatic transmission   |
| <b>B1S1</b> | bank 1, sensor 1 (passenger side pre-catalytic, upstream oxygen sensor)    |
| <b>B1S2</b> | bank 1, sensor 2 (passenger side post-catalytic, downstream oxygen sensor) |
| <b>B2S1</b> | bank 2, sensor 1 (driver side pre-catalytic, upstream oxygen sensor)       |
| <b>B2S2</b> | bank 2, sensor 2 (driver side post-catalytic, downstream oxygen sensor)    |
| <b>BDC</b>  | bottom dead center   |
| <b>CA</b>   | California   |
| <b>CAN</b>  | controller area network  |
| <b>CAT</b>  | catalytic converter  |
| <b>CCS</b>  | cruise control system  |
| <b>CMP</b>  | camshaft position  |
| <b>CPI</b>  | central point injection  |
| <b>CPP</b>  | clutch pedal position  |
| <b>CTP</b>  | closed throttle position   |
| <b>CVT</b>  | continuously variable transmission   |
| <b>DA</b>   | drivers airbag   |
| <b>DIS</b>  | digital idle speed control   |
| <b>DLC</b>  | data link connector  |
| <b>DP</b>   | driver pretensioner  |
| <b>DLC</b>  | data link connector  |
| <b>DSA</b>  | driver side airbag   |
| <b>DSL</b>  | diesel engine  |
| <b>DTC</b>  | diagnostic trouble code  |
| <b>DTM</b>  | output diagnostic test mode  |
| <b>ECM</b>  | engine control module  |
| <b>ECT</b>  | electronic coolant temperature   |
| <b>ECU</b>  | electronic control unit  |
| <b>EDL</b>  | electronic differential lock   |
| <b>EDS</b>  | pressure regulator   |
| <b>EFI</b>  | electronic fuel injection  |
| <b>EGR</b>  | exhaust gas recirculation  |
| <b>EMS</b>  | engine management system   |
| <b>EPC</b>  | electronic power control   |
| <b>ESP</b>  | electronic stability control   |
| <b>EVAP</b> | evaporative emissions system   |

|              |  |
|--------------|--|
| <b>FL</b>    | front left (wheel)                     |
| <b>FR</b>    | front right (wheel)                    |
| <b>FT</b>    | fuel trim                              |
| <b>IAT</b>   | intake air temperature                 |
| <b>ISC</b>   | idle speed control                     |
| <b>L4</b>    | 4 cylinder longitudinal mounted engine |
| <b>LDP</b>   | leak detection pump                    |
| <b>LEV</b>   | low emission vehicle                   |
| <b>MAF</b>   | mass airflow sensor                    |
| <b>MAP</b>   | manifold absolute pressure             |
| <b>MBAR</b>  | millibar; 1000 millibar = 14.5 psi     |
| <b>MIL</b>   | malfunction indicator lamp             |
| <b>MPI</b>   | multipoint injection                   |
| <b>MSR</b>   | engine drag torque control             |
| <b>M/T</b>   | manual transmission                    |
| <b>MV</b>    | magnetic valve(s)                      |
| <b>O2S</b>   | oxygen sensor                          |
| <b>PA</b>    | passenger airbag                       |
| <b>PNP</b>   | park/neutral position                  |
| <b>PP</b>    | passenger pretensioner                 |
| <b>PSA</b>   | passenger side airbag                  |
| <b>RL</b>    | rear left (wheel)                      |
| <b>RR</b>    | rear right (wheel)                     |
| <b>SAI</b>   | secondary air injection                |
| <b>SFI</b>   | sequential fuel injection              |
| <b>SULEV</b> | super ultra low emission vehicle       |
| <b>TCC</b>   | torque converter clutch                |
| <b>TCM</b>   | transmission control module            |
| <b>TCS</b>   | traction control system                |
| <b>TDC</b>   | top dead center                        |
| <b>TDI</b>   | turbo direct injection                 |
| <b>TLEV</b>  | transitional low emission vehicle      |
| <b>TP</b>    | throttle position                      |
| <b>TWC</b>   | three way catalytic converter          |
| <b>ULEV</b>  | ultra low emission vehicle             |
| <b>V6</b>    | 6-cylinder V-type engine               |
| <b>WOT</b>   | wide open throttle                     |
| <b>ZEV</b>   | zero emission vehicle                  |

This chapter contains information for troubleshooting specific problems that may arise when using the scan tool.

## B.1 Communication Problems

When the scan tool is unable to establish communication with the control module in the vehicle under test, or when the communication is interrupted, a message will display. If this happens, wait to see whether the communication is established again or interrupted. If communication is interrupted again, press **N** to abort.



---

**NOTE:**

Switching the ignition off-and-on and reentering the ID may reset communication.

---

**Note the following regarding communication problems with VW/Audi vehicles:**

- When testing a VW/Audi with certain ECMs, communication problems may occur when the engine speed is above 2000 RPM. In this case, communication cannot be established. Once communication has been established, the engine may be revved above 2000 RPM.
- If testing ABS/EDS/ESP/TCS systems, problems may occur if the vehicle speed exceeds 12 MPH (19 KPH). Communication will be stopped or cannot be established.

## B.2 The Aftermarket Radio Problem

Between 1997 and 1998, VW and Audi started using radios with self-diagnostic capabilities in most models. The scan tool can communicate with the radio, which allows you to set various options, like whether a CD player is connected, an amplified or conventional antenna, or other installed options.

### B.2.1 The Problem

VW brought the “K-Line”, the wire on which all of the vehicle control modules communicate with the scan tool, to a pin in the connector on which older radios used to return B+ back into the harness. So if you were to take the non-diagnostics capable radio out of a 1997 GTI and put it in a 1998 where there should be a diagnostics-capable one, it fits perfectly, but the K-Line ends up shorted to power.

Many aftermarket radios have adapter harnesses that plug into the vehicle radio connector. Unfortunately, some of the aftermarket harnesses faithfully reproduce the older, non-diagnostics radios with a loop of wire between B+ and the pin where the K-Line is on newer models. The radio will work fine until you connect a scan tool.



The vehicle is not affected if the K-Line is shorted to B+. The K-Line is not used for intra-vehicle communications, however, the scan tool initializes a communications session by pulling the K-Line to ground. The K-Line normally has some voltage on it, but through a high-impedance source. If the K-Line has “full” B+ on it, it can damage the scan tool output driver for the K-Line.

### B.2.2 Testing for this Problem

You can test for this problem yourself without removing the radio.




Figure B-1 16-pin OBD-II data link connector (DLC)

- 1— Chassis ground
- 2— Signal ground
- 3— K-Line
- 4— L-Line
- 5— B+



#### To test this problem with a voltmeter, such as the Snap-on® Vantage® graphing meter:

1. Measure the voltage between pins 4 and 7 of the DLC with the ignition and radio on. If the reading is below 9V, your K-Line is fine. If the reading is above 9V, the results are inconclusive and you need to proceed to the next step.
2. Put a 1K-ohm resistor between pins 4 and 7 of the DLC.
3. Use the voltmeter to measure the voltage between 4 and 7 (in parallel with the resistor). If it is under 1V, you don't have the problem. If it remains near 12V (the resistor will get hot!) you do have this problem and you will need to fix it (see the procedure for fixing this problem on page 155).



#### To test this problem without a voltmeter:

1. Temporarily place a 1K-ohm resistor between pins 4 and 7 of the DLC and ensure it is making contact with both pins (Figure B-1). If the resistor gets hot, your K-Line is shorted to B+. If it does not get hot, you do not have a problem. Do NOT install this resistor in the port. You are simply using it to check and see if the K-Line has 12V.
2. If the resistor gets hot, then pull it out and fix the problem by disconnecting the K-Line from the stereo wiring harness.



**To repair the problem:**

1. Remove the radio.
2. Make sure that the K-Line in the radio wiring harness (black 8-pin multi-connector III-T8) has been removed from the connector and taped back to the harness (Figure B-2).




Figure B-2 K-Line on the radio wiring harness black 8-pin multi-connector III-T8



**NOTE:**

Some 2002 and newer Volkswagens come with the double-DIN “Premium VI” radio. This radio does not have a K-Line connection, but rather has a CAN-high and CAN-low. Although the connector is completely different and it should not be possible to have the “Aftermarket Radio Problem” with these newer cars, if you use an aftermarket radio, it would be best to make sure that nothing is connected to these pins in the radio harness. The back of the Premium VI radio is shown in Figure B-3.




Figure B-3 Back of Premium VI radio

- 1— CAN-
- 2— CAN+

# Fuel Control Learning/ Adaptation Values

VW/Audi uses a type of fuel control called “adaptive learning.” This is defined as the ability of the engine management system to continuously modify the fuel mixture to account for changing operating conditions.

OBD-II terms for fuel control are “short-term” and “long-term” fuel trim (FT).

- **Short term** means the correction responds directly to the oxygen sensor (O2S) input.
- **Long term FT** is designed to maintain short term FT in a balanced state, equal range of control on either side of rich or lean.

The following sections explain OBD-II short and long term FT terminology applied to VW/Audi fuel control terminology. VW/Audi use Bosch Motronic engine management systems. For VW, Adaptive Learning started with the Motronic 2.9 engine management system in 1993. Each new system increased the adaptation sophistication (M2.9, M5.0, M5.9.2, M7.0, M7.1, M7.5.1). For these systems, two central fuel control terms require explanation:

- **Additive** for idle adaptation.
- **Multiplicative** for part throttle or cruise adaptation.

## C.1 Long-Term Fuel Control

Both Additive and Multiplicative adaptation are a form of long term fuel control. Each is a coarse type of FT control, allowing short term FT to maintain a midpoint balance between rich and lean.

### C.1.1 Additive Adaptation

Additive means adding or subtracting equal amounts of fuel to every fuel block cell regardless of the programmed base injection pulse value. It works very effectively for idle mixture related problems, but its effect is minimal at the higher engine speeds. For example, vacuum leaks greatly affect fuel mixture at idle but become less severe at higher RPM. The important distinction is that the amount of fuel correction is not dependent upon the original base in each fuel memory cell.

Additive adaptation indicates a fine-tuning, long-term correction or adaptation that the ECM is applying to the fuel injection pulse width. Although these minute adjustments affect the entire engine speed range, they are most noticeable at idle or during lower pulse-width operating conditions. A positive value indicates increased fuel injection duration, and a negative value indicates a decreased fuel injection duration.

When the short term correction value, reaches its upper or lower limit, the ECM resets short term correction and moves the long term FT value up or down by one count. The short term FT moves quickly, while the long term FT moves slowly. The short and long term FT continue to work together until the fuel mixture problem is corrected, or until the long term FT reaches its upper or lower limit. When the long term FT reaches its limit, the ECM sets a DTC, and usually defaults into open loop operation. The factory term “Additive Mixture Adaptation” refers to the fact that the ECM

is adding directly to the injector opening time for all memory cells. However, data is only updated under certain idle conditions. Be aware that Idle and Part Load Multiplicative work together to establish the long term FT.

### C.1.2 Multiplicative Adaptation

Multiplicative means multiplying or taking the preprogrammed cell base value and multiplying that number by either a correction factor or percent. Here, the correction amount increased or decreased in each memory block cell is dependent on each cell's base injection pulse. This form of adaptation is required to compensate for fuel control-type problems that get worse with increased engine speed (i.e., a faulty injector). Short term FT in VW/Audi language is usually called O2 regulation or O2 control. The readings are constantly changing, directly responding to oxygen sensor (O2S) input. Normal readings are usually in the  $\pm 10\%$  range with 0 as the midpoint. If it gets too far off, Long-term additive or multiplicative adjusts the window back to the midpoint (balanced state).

Multiplicative adaptation correction indicates the long-term FT correction that the ECM is applying to the air/fuel mixture during closed loop operation over the middle to upper range of engine operation. VW/Audi use the term "Multiplicative Mixture Adaptation" because it is a percent correction factor based on the individual base injection value for each memory cell. Cells are constantly updated based on feedback operation. If any cell stores an update that is beyond the neutral feedback value, a correction is then factored into the injector pulse-width calculation. To maintain the optimal air/fuel ratio of 14.7:1 for catalytic converter (CAT) efficiency, the ECM monitors the O2Ss and calculated load. From this information, the ECM calculates a percent value that indicates how much to enrich or dilute the fuel mixture. Sometimes, the ECM makes fine tuning adjustments across the complete fuel map by adjusting the IDLE (Additive) FUEL TRIM (for example, when a fine adjustment is needed across the range to compensate for fuel injector drift).

### C.1.3 Examples of Display Groups for Long Term FT Adaptive Value

Depending on the year, vehicle, engine, and engine code, you may see some combination of the following long term FT parameters:

- ADPVALUEO2(ADD)(%)
- ADPVALUEO2(IDLE)(ADD)(%)
- ADPVALUEO2(MUL)(%)
- ADPVALUEO2(P/T)(ADD)(%)
- LEARNO2(ACTUAL)(BANK1)(%)
- LEARNO2(ACTUAL)(BANK2)(%)
- LEARNO2(BANK1)
- LEARNO2(BANK1)(ADD)(%)
- LEARNO2(BANK1)(IDLE)(%)
- LEARNO2(BANK1)(MUL)(%)
- LEARNO2(BANK1)(P/T)(%)
- LEARNO2(BANK2)
- LEARNO2(BANK2)(%)

- LEARNO2(BANK2)(ADD)(%)
- LEARNO2(BANK2)(IDLE)(%)
- LEARNO2(BANK2)(MUL)(%)
- LEARNO2(BANK2)(P/T)(%)
- LEARNO2(BK1-SNS1)(IDLE)(%)
- LEARNO2(BK1-Sensible/T)(%)
- LEARNO2(BK2-SNS1)(IDLE)(%)
- LEARNO2(BK2-SNS1)(P/T)(%)
- LEARNO2(FULL)
- LEARNO2(IDLE)
- LEARNO2(IDLE)(%)
- LEARNO2(IDLE)(ADD)(%)
- LEARNO2(IDLE)(ADD)(%)
- LEARNO2(IDLE)(ms)
- LEARNO2(IDLE)(MUL)(%)
- LEARNO2(P/T)
- LEARNO2(P/T)(%)
- LEARNO2(P/T)(ADD)(%)
- LEARNO2(P/Tumult)(%)
- LEARNO2(P/T-WOT)
- LEARNO2(PART)(MUL)(%)
- LEARNVALUEMIXTUREADAPTATION
- LEARNVALUEMIXTURECORR(%)
- LEARNVALUEMIXTURECORR(ms)
- LEARNVALUEO2(P/T)(ADD)(%)
- LRNO2BEFORECAT(P/T)(ADD)(%)
- LRNO2BEFORECAT(IDLE)(ADD)(%)
- LRNO2BEFORECAT(P/T)(ADD)(%)
- LEARNVALUEO2(IDLE)(ADD)(%)
- LEARNVALUEO2(P/T)(MUL)(%)
- ADPVALUEMIXTURE(BANK1)(%)
- LRNO2BEFORECAT(IDLE)(ADD)(%)
- LEARNMIXT(BANK1)(IDLE)(%)
- LEARNMIXT(BANK1)(P/T)(%)
- LEARNMIXT(BANK1)(P/T1)(%)
- LEARNMIXT(BANK1)(P/T2)(%)
- LEARNMIXT(BANK1)(P/T3)(%)
- LEARNMIXT(BANK2)(IDLE)(%)
- LEARNMIXT(BANK2)(P/T)(%)
- LEARNMIXT(BANK2)(P/T1)(%)
- LEARNMIXT(BANK2)(P/T2)(%)
- LEARNMIXT(BANK2)(P/T3)(%)

- LEARNMIXTURE(BANK1)(%)
- LEARNMIXTURE(BANK2)(%)

Below is a typical display group, Group (32), "LEARN VALUES O2".

- LEARN VALUE O2(BK 1)(IDLE)(%)
- LEARN VALUE O2(BK 2)(IDLE)(%)
- LEARN VALUE O2(BK 1)(P/T)(%)
- LEARN VALUE O2(BK 2)(P/T)(%)

### C.1.4 Important Tips for Long Term Fuel Control

- The value typically ranges from -10 to +10. A normal operating engine should fluctuate only slightly. If more than  $\pm 7\%$ , perform a mixture diagnosis. Technicians report MAF sensor problems with readings of  $\pm 5\%$ .
- Use Basic Settings for faster adaptation relearn. Take short road test (usually 2–3 miles) with the scan tool hooked up in Basic Settings. For relearn, make sure the engine is at normal operating temperature (coolant minimum temperature of 167°F [75°C] and a maximum intake air temperature of 194°F [90°C]). For idle relearn, let the engine idle in Basic Settings for a few minutes. For road test in Basic Settings, perform multiple accelerations and decelerations, as well as a part throttle cruise. Check to see that learn values are back within normal range. If OK, clear the codes. Field technicians report faster relearn and verification of repair by not clearing codes until correct fuel control has been confirmed. Finish by setting all Readiness Codes, and then one more final road test (see "Basic Settings and Fuel Trim Accelerated Learning" on page 47).
- Some vehicles may have part throttle learning divided into 3 different parts: (P/T1, P/T2, P/T3). Check to see that each part is in proper specification.
- For most systems that have FT control using  $\pm 25\%$  maximum range, readings above or below 14 sets a DTC and turns on the MIL.

## C.2 Short-Term Fuel Control

Short term FT is usually called O2 regulation or O2 control. The readings are constantly changing, directly responding to O2S input. Normal readings usually are in the  $\pm 10\%$  range with 0 as the midpoint. If it gets too far off, Long-term additive or multiplicative adjusts the window back to the midpoint (balanced state).

### C.2.1 Examples Short Term FT O2 Regulation

Depending on the year, vehicle, engine and then engine code you may see some combination of the following short term FT parameters:

- ADPVALUEMIXTURE(BANK1)
- ADPVALUEMIXTURE(BANK2)
- ADPVALUEMIXTURE(BANK2)(%)
- ADPVALUEO2

- LEARNVALUEO2
- O2CONTROL(BANK1)(%)
- O2CONTROL(BANK2)(%)
- O2CONTROLFACTOR(BK1)
- O2CONTROLFACTOR(BK1)(%)
- O2CONTROLFACTOR(BK2)
- O2CONTROLFACTOR(BK2)(%)
- O2REGULATION(BK1-SNS1)(%)
- O2REGULATIONBEFORECAT(%)
- O2SENSOR(BK1-SNS1)(V)
- DYNAMIC FACTOR O2-SNSBEFORECAT
- O2CONTROL(BANK1)(%)
- O2CONTROL(BANK2)(%)
- O2CONTROLDEVIATION(%)
- O2INTEGRATOR

Below is a typical short term FT display group, Group O2 REGULATION BEFORE CAT

- O2 SENSOR(BANK 1,BEFORE CAT)(V)
- O2 SENSOR(BANK 2,BEFORE CAT)(V)
- O2 REGULATION (BANK 1)(%)
- O2 REGULATION (BANK 2)(%)

These parameters are equivalent to the short term FT correction during closed loop operation. This correction is based on the O2S input for a given engine load and speed. The ECM monitors engine operating conditions and calculates short-term and long-term adaptations to correct for engine wear.

The value typically range is  $\pm 10$ . A normal operating engine should see this value fluctuate by at least 2%. If it fluctuates by more than 7%, perform a fuel mixture diagnosis.



**NOTE:**

Some vehicles use a calculated value called *factor*. The parameter names are ADP VALUE O2 and DYNAMIC FACTORO2, SNS BEFORE CAT. Normal range is 0.5–1.5; 1.0  $\pm$ 0.3 is base midpoint; for 2.8L (AAA), the range is 0.80–1.20.

Positive values indicate the ECM is enriching the air/fuel mixture, and negative values indicate the ECM is leaning the mixture.

During open loop operation, the ECM runs at a base program without correction and the parameter displays a fixed 0% value. The ECM adjusts the air/fuel mixture by changing the fuel injector pulse width.

## C.2.2 Important Tips for Short-Term Fuel Control

- On some OBD-I (1991–1995) vehicles, values for short term FT, LEARN O2 (IDLE), LEARN O2 (P/T), or LEARN O2 (FULL), may be mislabeled as reading in percentage. In actuality, they are reading a numeric factor of 1.0 midpoint  $\pm$ 0.5 (0.5 to 1.5). For 2.8L AAA engine, the range is 0.80–1.20.

- Range: 0.5 - 1.5 Normal Value:  $1.0 \pm 0.3$  (0.7–1.3) is base midpoint
- For 2.0L (ABA) IDLE ADAPT: 0.87–1.2
- For 2.8L (AAA) IDLE ADAPT: 0.53–1.47
- Part Load: 0.80–1.20
- Low Load: 0.53–1.47
- Adaptation values may be erased if the car battery goes low or is disconnected.
- Additive adaptation is used mostly to correct idle mixture, however, it may also be used at higher RPM for fine adjustment (may see different additive values at different RPM). With relearn, it is normal for Additive adaptation to respond quickly. Multiplicative learning typically requires more learning time and vehicle must be driven on an extended road test under various driving conditions.
- For most systems that have FT control using  $\pm 25\%$  maximum range, readings above or below 14 sets a DTC and turn on MIL.

## C.3 Oxygen Sensor Voltage

Typical displays to view O2S voltage are either 001–004 (basic) or 026/033. You may see some combination of the following parameters:

- O2SENSOR(V)
- O2SENSOR1(V)
- O2SENSOR2(V)
- O2SENSOR(BANK1)(V)
- O2SENSOR(BANK1,AFTERCAT)(V)
- O2SENSOR(BANK1,BEFORECAT)(V)
- O2SENSOR(BANK2)(V)
- O2SENSOR(BANK2,AFTERCAT)(V)
- O2SENSOR(BANK2,BEFORECAT)(V)
- O2SENSOR(BK1-SNS1)(V)
- O2SENSORAFTERCAT(V)
- O2SENSORAFTERCATBK1(V)
- O2SENSORAFTERCATBK2(V)
- O2SENSORBEFORECAT(V)

These parameters indicate the amount of oxygen in the exhaust gas. High oxygen levels indicate a lean air/fuel mixture, while low oxygen levels indicate a rich air/fuel mixture. When the O2Ss are at operating temperature and the system is operating in closed loop, the ECM constantly adjusts the air/fuel mixture to achieve a 14.7:1 ratio. The ECM uses O2S signals to determine how rich or lean the engine is running and to correct the mixture.

## C.4 Early Vehicle Oxygen Sensor Reading

Many early vehicles, model years 1990–93, with limited display groups may not read O2S or O2 control. However, you can use Expert Mode and select display group 000. O2V reads in binary



format (0–255). There is no consistency, but Channel 5 often reads the O<sub>2</sub> signal. Look for this number to be constantly varying up and down by at least 14 digits. If Channel 5 is not active, it may be an application that only displays an O<sub>2</sub> short term FT factor. In this case, check channel 4. The O<sub>2</sub> control factor will also output a binary 0–255 number with 128 as the midpoint. Numbers less than 128 indicate a rich mixture correction. Numbers higher than 128 indicate a lean mixture correction. Look for fast fluctuations at different RPM and load conditions which indicate an active O<sub>2</sub>S (use DVOM to test O<sub>2</sub>S directly). Above is for those vehicles with display group 000 only. On vehicles with additional display groups but still not displaying O<sub>2</sub>V directly, look at the O<sub>2</sub> Factor which reads 1.0 as the base point. Higher numbers indicate correction for a mixture too lean and lower numbers indicate a correction for a mixture too rich. A typical normal range is 1.0 ±0.3.

The following sections are display examples for late model OBD-II O<sub>2</sub>S and CAT tests.

### C.4.1 Example: Motronic 2.9 (1993–1995)

The following example concerns reading engine data display Group 000.

Display group 000 has 10 channels or display fields, listed below.

1. Coolant temperature
2. Engine load
3. RPM
4. O<sub>2</sub> factor
5. Idle Adapt
6. Part throttle adapt
7. Low load adapt
8. IAC adapt
9. Not used
10. IGN timing

The display fields are output in binary numbers. To understand the binary number, visualize a clock with 0 at the top center. The number 128 is at the center bottom. The binary clock counts from 0 to 255.

The number can theoretically range from 0 to 255 with 0 as the midpoint. A number of 13 to 128 indicates that the ECM has commanded an overall lean mixture correction. A number of 128 to 243 indicates that the ECM has commanded an overall rich mixture correction.

## C.5 Late Model Oxygen Sensor Reading

Some late models are using 0–5V O<sub>2</sub>Ss. Rich is high voltage; lean is low voltage. For example, a VW 2001 2.0L with the AEG engine and the 2002 Passat W8 (BDP). Other late model vehicles may be using a Linear Air/Fuel Ratio sensor (A/F sensor) which measures the exact air/fuel mixture (not like a standard Zirconium O<sub>2</sub>S switching constantly between rich and lean). The voltage displayed (display group 33 in Table C-1 below) for these is an ECM computed value where 1.5V = 1 lambda or the ideal fuel mixture ratio of 14.7:1. Higher voltage indicates correction for a rich mixture and lower voltage indicates a correction for a lean mixture. Under normal load, the A/F sensor voltage should vary around 1.5V, which means the mixture is right at stoichiometric

or  $\lambda = 1$ . During deceleration from 3000 RPM, the mixture is lean and the A/F sensor voltage should go higher than 1.5V. Under full load acceleration, the mixture is rich and the A/F sensor voltage should go low, 1V or lower.

**Table C-1** *Display groups 31 and 33*

| Display Group | Sensor                             | Bank 1, Sensor 1    | Bank 1, Sensor 2                                    | Bank 2, Sensor 1  | Bank 2, Sensor 2                                    |
|---------------|------------------------------------|---------------------|---|-------------------|---|
| 31            | Linear oxygen sensors              | Lambda actual value | Lambda specified value                              |                   |   |
| 33            | Linear oxygen sensor control value | Control value (%)   | Sensor voltage before CAT of a broadband sensor (V) | Control value (%) | Sensor voltage before CAT of a broadband sensor (V) |



**NOTE:**

The broadband lambda probe linear Air Fuel Ratio Sensor acquires and evaluates lambda values differently to the step type zirconium O<sub>2</sub>S. The lambda value (display group 31 in Table C-1) is determined from a change of current, not from a change of voltage.

### C.5.1 Oxygen Sensor Aging Test

The O<sub>2</sub>S Aging Test is a Readiness Code test, typically display groups 34 or 35 for O<sub>2</sub>S before CAT, and display groups 36 or 43 for O<sub>2</sub>S after CAT.

Typical display Group, DIAGN AGING O<sub>2</sub> BEFORE CAT

- ENGINE SPEED(rpm)
- EXHAUST GAS TEMPERATURE
- DYNAMIC FACTOR
- DIAGNOSE STATUS

Depending on the year, vehicle, engine, and engine code, you may see some combination of the following O<sub>2</sub>S Aging Test Parameter list:

- AGINGTESTO2(BK1-SNS2)
- AGINGTESTO2(BK2-SNS2)
- AGINGTESTO2AFTERCATBK1
- AGINGTESTO2AFTERCATBK2
- AGINGTESTO2-SNSAFTERCAT
- AGINGTESTO2-SNSBEFORECAT
- DIAGNOSESTATUS
- DYNAMICFACTOR
- DYNAMICFACTORO2-SNSBEFORECAT

These parameters indicate the Readiness Code for the O<sub>2</sub>S Aging test. The test measures the O<sub>2</sub>S cycling time between a rich to lean transition back to rich transition. This measurement then translates into the aging condition of the O<sub>2</sub>S. If the specified allowable time is exceeded, DIAGNOSESTATUS will read NOT OK. A typical normal range for the cycling time period duration (DYNAMICFACTOR) is 0.1–1.8 seconds (typical functional range is 0–3.3 seconds).

### C.5.2 Oxygen Sensor Control-Dwell Time Test

Below is a typical display group example, DIAGN O2 CONTROL SYSTEM.

- ENGINE LOAD(%)
- O2 SENSOR(BANK 1, AFTER CAT)(V)
- CORR.BETW O2-SNS 1+2 BK1(ms)
- DIAGNOSE STATUS

These parameters indicate the relationship of the before CAT O2S and the after CAT O2S. The after CAT O2S has the authority to override the before the CAT O2S. The reason for this is in case the before CAT O2S performance deteriorates to the point of jeopardizing the CAT, the after CAT O2 control can take over control preventing possible CAT damage. The after CAT O2S also can correct for slight changes in the mixture if it detects displacement of the before CAT voltage curve. It takes control by holding the before CAT O2 control at its higher or lower point for a specific time (dwell time). If this time is in the positive range (i.e., 50 ms), then the mixture is shifted to the rich direction. If the time is negative (i.e., -50 ms), then the mixture is shifted to the lean direction.



**NOTE:**

If the value is above +200 ms, then there is a possible leak in the exhaust system.

### C.5.3 CAT Test Parameters

Below is a typical display group 46/47, DIAGNOSE CATALYST BANK 1.

- ENGINE SPEED(rpm)
- CATALYST TEMPERATURE
- CATALYST EFFICIENCY
- DIAGNOSE STATUS

The engine management ECM compares the voltage(s) of the upstream or before CAT O2S to the voltage(s) of the downstream or after the CAT O2S. The result is called the amplitude ratio between the two sensors and indicates the CAT test result in either percent or amplitude ratio. A good CAT amplitude ratio range is 0.00 –0.32.

Table C-2 provides O2S and fuel control display fields available in Expert Mode.

**Table C-2** Display fields for O2S and Fuel control available in Expert Mode (part 1 of 5)

| Display Group   | Sensor   | Bank 1, Sensor 1 | Bank 1, Sensor 2 | Bank 2, Sensor 1 | Bank 2, Sensor 2 |
|---|--|------------------|------------------|------------------|------------------|
| 30  | Oxygen sensor, status (2-bank system)                                | XXX <sup>1</sup> | XXX <sup>1</sup> | XXX <sup>1</sup> | XXX <sup>1</sup> |
|   | Oxygen sensor, status (1-bank system)                                | XXX <sup>1</sup> | XXX <sup>1</sup> |                  |                  |
|   | X values: (1) Control Active, (2) Sensor Ready, (3) Sensor Heater ON |                  |                  |                  |                  |
| <sup>1</sup> Condition attained = 1; Condition not attained = 0 |  |                  |                  |                  |                  |

**Table C-2** Display fields for O2S and Fuel control available in Expert Mode (part 2 of 5)

| Display Group   | Sensor   | Bank 1, Sensor 1    | Bank 1, Sensor 2                                    | Bank 2, Sensor 1     | Bank 2, Sensor 2  |
|---|--|---------------------|---|----------------------|---|
| 31  | Knock sensor voltage   | (V)                 | (V)   | (V)                  | (V)   |
|   | Oxygen sensor voltage  | (V)                 | (V)   |                      |   |
|   | Linear oxygen sensors (2-bank system)  | Lambda actual value | Lambda specified value                              | Lambda actual value  | Lambda specified value  |
|   | Linear oxygen sensors (1-bank system)  | Lambda actual value | Lambda specified value                              |                      |   |
| 32  | Oxygen sensors learning values (maximum value) (2-bank systems)                            | Idle (%)            | Partial load (%)                                    | Idle (%)             | Partial load (%)  |
|   | Oxygen sensors learning values (maximum value) (1-bank systems)                            | Idle (%)            | Partial load (%)                                    |                      |   |
| 33  | Lambda control value (2-bank system)   | Control value (%)   | Oxygen sensor voltage (V)                           | Control value (%)    | Oxygen sensor voltage (V)   |
|   | Lambda control value (1-bank system)   | Control value (%)   | Oxygen sensor voltage (V)                           |                      |   |
|   | Linear oxygen sensor control value   | Control value (%)   | Sensor voltage before CAT of a broadband sensor (V) | Control value (%)    | Sensor voltage before CAT of a broadband sensor (V)                       |
| 34  | Oxygen sensor aging test Bank 1 or Bank 3 before CAT, short trip                           | RPM (1/min.)        | Exhaust gas/ CAT temperature (°C)                   | Length of period (s) | Result (Test ON/Test OFF/ B1-S1 OK/ B1-S1 not OK/ B3-S1 OK/ B3-S1 not OK) |
|   | Oxygen sensor aging test Bank 1 or Bank 3 before CAT for linear oxygen sensors, short trip | RPM (1/min.)        | Exhaust gas/ CAT temperature (°C)                   | Dynamic factor       | Result (Test ON/Test OFF/ B1-S1 OK/ B1-S1 not OK/ B3-S1 OK/ B3-S1 not OK) |
| <sup>1</sup> Condition attained = 1; Condition not attained = 0 |  |                     |   |                      |   |

**Table C-2** Display fields for O2S and Fuel control available in Expert Mode (part 3 of 5)

| Display Group   | Sensor   | Bank 1, Sensor 1   | Bank 1, Sensor 2  | Bank 2, Sensor 1     | Bank 2, Sensor 2  |
|---|--|--------------------|---|----------------------|---|
| 35  | Oxygen sensor aging test Bank 2 or Bank 4 before CAT, short trip                           | RPM (1/min.)       | Exhaust gas/ CAT temperature (°C)   | Length of period (s) | Result (Test ON/Test OFF/ B2-S1 OK/ B2-S1 not OK/ B4-S1 OK/ B4-S1 not OK) |
|   | Oxygen sensor aging test Bank 2 or Bank 4 before CAT for linear oxygen sensors, short trip | RPM (1/min.)       | Exhaust gas/ CAT temperature (°C)   | Dynamic factor       | Result (Test ON/Test OFF/ B2-S1 OK/ B2-S1 not OK/ B4-S1 OK/ B4-S1 not OK) |
|   | Oxygen sensor aging test Bank 2 before CAT   |                    |   |                      |   |
| 36  | Oxygen sensor readiness after CAT, short trip (2-bank system)                              | Sensor voltage (V) | Result (Test ON/Test OFF/ B1-S2 OK/ B1-S2 not OK/ B3-S2 OK/ B3-S2 not OK) | Sensor voltage (V)   | Result (Test ON/Test OFF/ B2-S2 OK/ B2-S2 not OK/ B4-S2 OK/ B4-S2 not OK) |
|   | Oxygen sensor readiness after CAT, short trip (1-bank system)                              | Sensor voltage (V) | Result (Test ON/Test OFF/ B1-S2 OK/ B1-S2 not OK)                         |                      |   |
| 37  | Oxygen sensors, short trip   | Load (%)           | Oxygen sensor voltage after CAT (V)                                       | TV shift (ms)        | Result (Test ON/Test OFF/ Sys. OK/Sys. not OK)                            |
|   | Linear oxygen sensors, short trip  | Load (%)           | Oxygen sensor voltage after CAT (V)                                       | Lambda               | Result (Test ON/Test OFF/ Sys. OK/Sys. not OK)                            |
| 38  | Oxygen sensors, short trip   | Load (%)           | Oxygen sensor voltage after CAT (V)                                       | TV shift (ms)        | Result (Test ON/Test OFF/ Sys. OK/Sys. not OK)                            |
|   | Linear oxygen sensors, short trip  | Load (%)           | Oxygen sensor voltage after CAT (V)                                       | Lambda               | Result (Test ON/Test OFF/ Sys. OK/Sys. not OK)                            |
|   | Oxygen sensors (1-bank systems)  | NOT USED           |   |                      |   |
| 39  | Sensor exchange after CAT, short trip  | Air mass (g/s)     | Sensor voltage (V)  | Sensor voltage (V)   | Result (Test ON/Test OFF/ Sys. OK/Sys. not OK)                            |
| <sup>1</sup> Condition attained = 1; Condition not attained = 0 |  |                    |   |                      |   |

**Table C-2** Display fields for O2S and Fuel control available in Expert Mode (part 4 of 5)

| Display Group   | Sensor   | Bank 1, Sensor 1             | Bank 1, Sensor 2  | Bank 2, Sensor 1               | Bank 2, Sensor 2   |
|---|--|------------------------------|---|--------------------------------|--|
| 40  | Oxygen sensor heaters resistor (combined wires of heaters)       | Heater resistor ( $\Omega$ ) | Condition (Heater before CAT ON/Heater before CAT OFF)              | Heater resistor ( $\Omega$ )   | Condition (Heater before CAT ON/Heater before CAT OFF)                       |
|   | (1-bank systems)   | NOT USED                     |   |                                |  |
| 41  | Oxygen sensor heater   | Heater resistor ( $\Omega$ ) | Condition (Heater before CAT ON/Heater before CAT OFF/Sensor 1 (%)) | Heater resistor ( $\Omega$ )   | Condition (Heater before CAT ON/Heater before CAT OFF)                       |
| 42  | Oxygen sensor heaters (separate wires of heaters)                | Heater resistor ( $\Omega$ ) | Condition (Heater before CAT ON/Heater before CAT OFF/Sensor 1 (%)) | Heater resistor ( $\Omega$ )   | Condition (Heater before CAT ON/Heater before CAT OFF)                       |
| 43  | Oxygen sensor aging after CAT, linear oxygen sensors, short trip | RPM (U/min.)                 | Exhaust gas/ CAT temperature ( $^{\circ}\text{C}$ )                 | Oxygen sensor voltage (V)      | Result (Test ON/Test OFF/ B1-S2 OK/ B1-S2 not OK/ B3-S2 OK/ B3-S2 not OK)    |
| 44  | Oxygen sensor aging after CAT, short trip                        | RPM (U/min.)                 | Exhaust gas/ CAT temperature ( $^{\circ}\text{C}$ )                 | Oxygen sensor voltage (V)      | Result (Test ON/Test OFF/ B2-S2 OK/ B2-S2 not OK/ B4-S2 OK/ B4-S2 not OK)    |
|   |  |                              |   |                                |  |
| 45  |  |                              |   |                                |  |
| 46  | CAT conversion test Bank 1 or Bank 3, short trip                 | RPM (1/min.)                 | CAT temperature ( $^{\circ}\text{C}$ )                              | Measuring value CAT conversion | Result (Test ON/Test OFF/ CAT B1 OK/ CAT B1 not OK/ CAT B3 OK/ CAT B2 no OK) |
| 47  | CAT conversion test Bank 2 or Bank 4, short trip                 | RPM (1/min.)                 | CAT temperature ( $^{\circ}\text{C}$ )                              | Measuring value CAT conversion | Result (Test ON/Test OFF/ CAT B2 OK/ CAT B2 not OK/ CAT B4 OK/ CAT B4 no OK) |
|   | CAT conversion test Bank 2 (1-bank systems)                      | NOT USED                     |   |                                |  |
| <sup>1</sup> Condition attained = 1; Condition not attained = 0 |  |                              |   |                                |  |

**Table C-2** Display fields for O2S and Fuel control available in Expert Mode (part 5 of 5)

| Display Group   | Sensor  | Bank 1, Sensor 1                              | Bank 1, Sensor 2         | Bank 2, Sensor 1              | Bank 2, Sensor 2                              |
|---|---|---|--------------------------|-------------------------------|---|
| 48  | Thermal CAT diagnosis Bank 1, short trip  | Operating system BDE<br>XXXXXXXX <sup>1</sup> | Number of test steps (-) | Exothermal temp. increase (K) | Result (Test ON/Test OFF/Sys. OK/Sys. not OK) |
|   | X values: (1) With bit homogenous knock protection, (2) Not used, (3) Not used, (4) Layer CAT heating double inject., (5) Layer, (6) Homogenous layer double inject., (7) Homogenous lean, (8) Homogenous |   |                          |                               |   |
| 49  | Thermal CAT diagnosis Bank 2, short trip  | Operating system BDE<br>XXXXXXXX <sup>1</sup> | Number of test steps (-) | Exothermal temp. increase (K) | Result (Test ON/Test OFF/Sys. OK/Sys. not OK) |
|   | X values: (1) With bit homogenous knock protection, (2) Not used, (3) Not used, (4) Layer CAT heating double inject., (5) Layer, (6) Homogenous layer double inject., (7) Homogenous lean, (8) Homogenous |   |                          |                               |   |
| <sup>1</sup> Condition attained = 1; Condition not attained = 0 |   |   |                          |                               |   |

# Index

## A

- ABS systems 71
  - basic settings brake bleeding 74
- actuator tests 42
  - important notes for testing 44
- aftermarket radio problem 11, 153
- application charts
  - ABS (Audi types and system descriptions) 73
  - ABS (VW types and system descriptions) 72
  - ABS (VW) 71
  - engine (Audi) 36
  - engine (early Audi) 39
  - engine (early VW) 35
  - engine (VW) 31
  - transmission (types and descriptions) 53
  - transmissions 56
  - VW/Audi software 29

## B

- basic settings 40
  - ABS 74
  - adaptive learned values 47
  - crankshaft sensor learn 48
  - Expert Mode 19, 21
  - fuel trim accelerated learning 47
  - ignition timing 46
  - kickdown function 45
  - menu choices 45
  - problems with 49
  - standard mode 45
  - throttle body adaptation 45
  - transmission testing 62

## C

- checking for codes (test drive) 39
- coding and programming
  - VW 1996–99 mechanical keys 79

## D

- data display (ignition off) 41
- data groups (pre-selected) 42
- data parameters
  - ABS 149
  - diesel engine 135
  - gas engine 104
  - listed alphabetically 92
  - transmission 139
  - transmission Expert Mode 147
- display data groups 22

DL-16 11

## E

- early Audi engine systems 36
- early VW engine systems 35
- ECU coding 21
- ECU ID information 20
- electronic throttle 66
  - emergency running or limp-home mode 70
- electronic throttle systems 66
  - adaptation 66
  - types of 68
- engine ID codes 4
- engine systems
  - important notes for fault codes 40
  - system coverage 35
  - systems covered 31
- engine trouble codes 40
- Expert Mode 17–28
  - automatic system test 15
  - important warnings 17
  - selecting 11
  - VW/Audi software applications 29

## F

- false codes 40
- fuel control 156
  - additive adaptation 156
  - early vehicle O2S 161
  - Expert Mode display groups 163
  - late model O2S 162
  - multiplicative adaptation 157
  - O2 factor 160
  - oxygen sensor voltage 161
- fuel control learning 156
- functional tests
  - Initiate Actuator Tests 42
  - Review ECU ID 44
  - Service Interval Reset 49

## I

- Immobilizer 74
  - ECU replacement 76, 77
  - FAQ 81
  - key coding 76
  - remote key matching 80
  - sample remote key option settings 80
  - types of 74



**K**

keys  
actuator tests 21, 44  
adaptations 26  
basic settings 46, 48  
electronic throttle adaptation 66  
Personality Keys™. See Personality Keys™  
types used with immobilizer systems 74  
KW2000 protocol 26

**L**

login access numbers 27  
long-term fuel control 156

**M**

multiple code clearing 39

**P**

Personality Keys™ 11  
programming. See coding and programming

**R**

remote key option settings 80

**S**

Safety iii-iv  
safety  
information iii  
scan tool VW/Audi coverage 29  
service reset  
electronic 50  
manual 49  
service reset/preset functions 51  
short-term fuel control 159

**T**

test adapters 11  
DL-16 11  
VW-1 11  
testing  
ABS systems 71  
engine systems 31  
transmission systems 52  
transmission systems 52  
application chart 56  
basic settings 62  
emergency operation 65  
fail-safe functions 64  
important tips for fault codes 61  
series 01F, 01K 60  
series 01N 59  
series 095, 096, 01M 59  
solenoid firing 63

**V**

vehicle connectors  
VW locations 12  
VW-1 11

**W**

Work Shop Code (WSC) 20